

Gigaset

CX590 ISDN

Issued by
Gigaset Communications GmbH
Frankenstr. 2a, D-46395 Bocholt
Manufactured by Gigaset Communications GmbH
under trademark license of Siemens AG.
As of 1 Oct. 2011 Gigaset products bearing the
trademark 'Siemens' will exclusively use the trademark 'Gigaset'.

© Gigaset Communications GmbH 2009
All rights reserved. Subject to availability.
Rights of modification reserved.

www.gigaset.com

GIGASET. INSPIRING CONVERSATION.
MADE IN GERMANY

SIEMENS

Gigaset CX590 ISDN – more than just a telephone

Your ISDN connection offers you two telephone lines simultaneously.

The large TFT display, user-friendly keypad and clearly laid out menu make your phone very simple to use.

Your phone can do a whole lot more:

- ◆ Use your Gigaset as a PABX – register up to six handsets. Assign each device its own phone number (MSN).
- ◆ Configuring your Gigaset is easy thanks to the wizards – they determine the MSNs for your ISDN connection (provider-specific) and help you to register handsets and assign send and receive MSNs to the handset (→ page 16).
- ◆ You can save anniversaries, e.g., birthdays, in your phone and it will remind you of them in advance.
- ◆ Allocate important people to one of six VIP groups so you can identify important calls from the ringtone and the colour of the assigned VIP group.
- ◆ If you only want to accept calls when you can see the number, you can set your handset to only ring when the phone number is transmitted.
- ◆ You can assign important numbers to the number keys on your phone (quick dial). You can then dial the number by simply pressing a key.
- ◆ Set the display to large print to increase readability in particularly important screens (e.g., the directory and lists).
- ◆ Gigaset Green Home — be environmentally aware when using your phone. Details about our ECO DECT products can be found at www.gigaset.com/service

Further information on your phone can be found at www.gigaset.com/gigasetcx590isdn

Have fun using your new telephone!

The handset at a glance



- 1 **Display** in idle status
- 2 **Battery charge status** (→ page 15)
- 3 **Display keys** (→ page 24)
- 4 **Message key** (→ page 44)
Access to call and message lists;
Flashing: new message or new call
- 5 **End call key, on/off key**
End call, cancel function, go back one menu level (press briefly), back to idle status (press and hold), activate/deactivate handset (press and hold in idle status)
- 6 **Hash key**
Keypad lock on/off (press and hold in idle status);
toggles between upper/lower case and digits
- 7 **Mute key** (→ page 36)
Muting the microphone
- 8 **Microphone**
- 9 **Recall key**
- Consultation (flash)
- Insert a dialling pause (press and hold)
- 10 **Star key**
Activate/deactivate ringtones (press and hold);
text input: open table of special characters
- 11 **Connection socket for headset** (→ page 21)
- 12 **Key 1**
network mailbox (press and hold)
- 13 **Talk key**
Flashing: incoming call;
Accept a call; open redial list (press briefly);
start dialling (press and hold)
- 14 **Speaker key**
Switch between earpiece and speaker mode
- 15 **Control key** (→ page 23)
- 16 **Signal strength** (→ page 15)
Green: Eco Mode (→ page 53) activated

Please note

To change the display language, proceed as described on page 60.


Base



Register/
paging key
(→ page 55)

Display icons

The following icons are displayed dependent on the settings and the operating status of your telephone:



Signalling

External call (→ page 35)



Alarm clock (→ page 54)



Internal call (→ page 55)



Anniversary (→ page 42)



Contents

- Gigaset CX590 ISDN – more than just a telephone 1**
- The handset at a glance 2**
- Safety precautions 7**
- First steps 8**
 - Checking the package contents 8
 - Setting up the base 9
 - Connecting the base 9
 - Setting up the handset for use 10
 - Changing the display language 13
 - Setting the date/time 14
- Setting up the phone – installation wizard 16**
 - ISDN wizard: finding/entering the connection's MSNs 16
 - Connection wizard 17
- Connecting the headset 21**
 - What would you like to do next? 22
- Using the phone 23**
 - Control key 23
 - Display keys 24
 - Keys on the keypad 24
 - Correcting incorrect entries 24
 - Using the menus 25
 - Activating/deactivating the handset 26
 - Activating/deactivating the keypad lock 26
 - Understanding the operating steps in the user guide 27
- Menu tree 29**
- Functions during a call 32**
 - Making a call to multiple participants 32
 - Transferring calls 33
 - Dealing with a waiting external call – CW (Call Waiting) 34

Making calls	35
Making an external call	35
Ending a call	35
Accepting a call	35
Rejecting a call	35
Calling Line Identification	36
Speaker	36
Muting	36
Ringback when busy (CCBS)/when the call is not answered (CCNR)	37
Configuring settings for the next call	38
Using the directory and lists	39
Directory	39
Using the redial list	42
Using the incoming message list	43
Call lists	43
Accessing lists with the message key	44
Missed alarms list	44
Sending SMS (text messages)	45
Writing/sending an SMS	45
Receiving an SMS	47
SMS with vCard	48
Receiving notifications via SMS	49
Setting up the SMS centre	49
SMS to PABXs	50
Activating/deactivating SMS function	50
SMS troubleshooting	51
Using the network mailbox	52
Configuring fast access for the network mailbox	52
Viewing the network mailbox message	52
ECO DECT	53
Setting the alarm clock	54
Using multiple handsets	54
Registering handsets	54
De-registering handsets	55
Locating a handset ("paging")	55
Changing the base	55
Making internal calls	55
Changing the name of a handset	57
Changing a handset's internal number	57
Using a handset as a room monitor	57

- Setting the handset** 59
 - Quick access to numbers and functions 59
 - Changing the display language 60
 - Setting the display 60
 - Activating/deactivating auto answer 61
 - Changing the speaker/earpiece volume 61
 - Changing ringtones 61
 - Activating/deactivating advisory tones 62
 - Setting your own area code 63
 - Restoring the handset default settings 63

- Creating ISDN settings** 63
 - Setting up/changing/deleting ISDN numbers (MSNs) 63
 - Assigning send and receive MSNs to internal participants 64
 - Setting up a busy signal for when the MSN is being used (Busy on Busy) 65
 - Activating/deactivating call waiting – CW 65
 - Anonymous calling – withholding caller ID (CLIR) 65
 - Diverting calls 66
 - Activating/deactivating call transfer – ECT (Explicit Call Transfer) 66

- Setting the base** 67
 - Activating/deactivating music on hold 67
 - Activating repeater support 67
 - Protecting against unauthorised access 67
 - Resetting the base to the default settings 67

- Connecting the base to the PABX** 68
 - Saving an access code (outside line code) 68
 - Transferring a call -ECT (Explicit Call Transfer) 68
 - Centrex 68
 - Dialling options 69
 - Questions and answers 71
 - Authorisation 72

- Environment** 73

- Appendix** 74
 - Caring for your telephone 74
 - Contact with liquid 74
 - Specifications 74
 - Writing and editing text 75

- Accessories** 76

- Mounting the base on the wall** 78

- Index** 79

Safety precautions

Warning

Read the safety precautions and the user guide before use.

Explain their content and the potential hazards associated with using the telephone to your children.



Use only the power adapter supplied, as indicated on the underside of the base.



Use only the **recommended, rechargeable batteries** (→ page 74) as this could otherwise result in significant health risks and personal injury.



Using your telephone may affect nearby medical equipment. Be aware of the technical conditions in your specific location e.g., doctor's surgery.



Do not hold the rear of the handset to your ear when it is ringing or when speaker mode is activated. This may cause serious and permanent damage to your hearing. Your Gigaset is compatible with the majority of digital hearing aids on the market. However, perfect function with all hearing aids cannot be guaranteed.

The handset may cause an unpleasant humming or whistling noise in hearing aids or cause them to overload. If you require assistance, please contact the hearing aid supplier.



Do not install the base and charging cradle in bathrooms or shower rooms. The base and charger are not splashproof (→ page 74).



Do not use your phone in environments with a potential explosion hazard (e.g., paint shops).



If you give your phone to a third party, make sure you also give them the user guide.



Remove faulty bases from use or have them repaired by our Service department, as they could interfere with other wireless services.

Please note

Not all functions described in this user guide are available in all countries or with all network providers.

First steps

Checking the package contents



- 1 One Gigaset CX590 ISDN base
- 2 One power adapter
- 3 One Gigaset handset
- 4 One ISDN telephone cable
- 5 Two batteries
- 6 One battery cover
- 7 One belt clip
- 8 One user guide.

Setting up the base

The base is designed for use in dry rooms in a temperature range of +5°C to +45°C.

- ▶ Set up the base on a level, non-slip surface at a central point in the building or mount the base on the wall (→ page 78).

Please note

Pay attention to the range of the base.

This is up to 300 m in unobstructed outdoor areas and up to 50 m inside buildings. The range is reduced when **Eco Mode** is activated (→ page 53).


The phone's feet do not usually leave any marks on surfaces. However, due to the multitude of different varnishes and polishes used on today's furnishings, marks on the surfaces cannot be completely ruled out.

Please note:

- ◆ Never expose the telephone to the effects of heat sources, direct sunlight or other electrical devices.
- ◆ Protect your Gigaset from moisture, dust, corrosive liquids and fumes.

Connecting the base

- ▶ **First** connect the telephone jack **1** and insert the cables into the cable ducts.
- ▶ **Then** connect the power adapter **2**.



Please note:

- ◆ The power adapter must **always be connected**, as the phone will not operate without a mains connection.
- ◆ Only use the power adapter and phone cord **supplied**.

Setting up the handset for use


The display is protected by a plastic film.
Please remove the protective film!

Inserting the batteries and closing the battery cover

Warning

Only use rechargeable batteries (→ page 74) recommended by Gigaset Communications GmbH i.e., never use a conventional (non-rechargeable) battery, as this could result in significant health risks and personal injury. For example, the outer casing of the batteries could be damaged or the batteries could explode. The phone could also malfunction or be damaged as a result of using batteries that are not of the recommended type.

- ▶ Insert the batteries with the polarity in the correct direction. The polarity is indicated in/on the battery compartment.



- ▶ First insert the battery cover at the top (a).
- ▶ Then press the cover (b) until it clicks into place.

To open the battery cover, for instance to replace the batteries, insert a coin into the cavity on the casing, then pull the battery cover in an upward direction.



Attaching the belt clip

The handset has notches on each side to attach the belt clip.

- ▶ **To attach** — press the belt clip onto the back of the handset so that the protrusions on the belt clip engage with the notches.
- ▶ **To remove** — press the centre of the belt clip firmly with your right thumb, push the fingernail of your left index finger up between the clip and the housing and pull the clip in an upward direction.



Placing handset on the base.

- ▶ Place the handset in the base with its **display facing forward**.

Each handset is registered with the base at the factory. You do not need to register the handset again. If you wish to use your handset with a different base or use additional handsets with your base, you have to register the handset manually (→ page 54).

To charge the batteries, leave the handset in the base.

Please note

The handset must only be placed in the base provided for it.

Initial charging and discharging of the batteries

The correct charge level can only be displayed if the batteries are first fully charged and discharged.



▶ Place the handset in the base for **ten** hours.



▶ Then remove the handset from the base and do not replace it until the batteries are fully discharged.

Please note

- ◆ After the first battery charge **and** discharge, you can replace your handset in its base after every call.
- ◆ Always repeat the charging and discharging procedure if you remove the batteries from the handset and reinsert them.
- ◆ The batteries may warm up during charging. This is not dangerous.
- ◆ After a while, the charge capacity of the batteries will decrease for technical reasons.

Changing the display language

Change the display language if you do not understand the language currently set.




- ▶ Press right on the control key.
- ▶ Press the keys **MNO 6** and **5 JKL** **slowly** one after the other.



The display for setting languages appears and the current language (e.g., English) is selected.





- ▶ Press down on the control key  ...



... until the language you wish to use is displayed e.g., French.

- ▶ Press the **right** display key to select the language.



The selection is marked with .


- ▶ Press and hold the end call key  to return to idle status.

Setting the date/time

Set the date/time so that the correct date and time can be assigned to incoming calls, and so that you can use the alarm.

Please note


Your phone takes the date/time from the ISDN network when you make an external call.



- ▶ Press the key below **Time** to open the input field.

(If you have already set the date/time, open the input field via the menu

→ page 31.)




The submenu **Date/Time** is shown on the display.

- ▶ The active input position flashes. Enter the day, month and year as an eight-digit number via the keypad e.g., for 14/10/2010.




Press the **right** or **left** control key to change the input position, e.g., to correct an entry.



- ▶ Press **down** on the control key to switch to the time input field.

- ▶ Enter the hours and minutes as four-digit numbers via the keypad e.g., for 07:15 am. Change the input position with the control key if necessary.





- ▶ Press the key below **Save** to confirm your entries.



The display shows **Saved**. You will hear a confirmation tone and the handset will automatically return to idle status.

Display in idle status

Once the phone is registered and the time set, the idle status looks like this (example).

Displays

- ◆ Reception between the base and the handset:

- Good to poor:
- No reception:

Green: Eco Mode activated (→ page 53)


- ◆ Charge status of the batteries:

- (Empty to full)
- Flashes red: batteries almost empty
- (Charging)

- ◆ INT 1

Internal name of the handset (→ page 57)

If **Eco Mode+** (→ page 53) is activated, the icon is displayed in the top left corner of the display.



Your phone is now ready for use.

Setting up the phone – installation wizard

A few settings are needed before you start using your telephone. The installation wizard is designed to help you with this.


First start the **ISDN wizard**, and the **connection wizard** will then start automatically.

If you place the first handset in the (→ page 2)base before the MSN settings have been made, the message key begins to flash after a while.

- ▶ Press the message key  to start the ISDN wizard.

You can also access the ISDN wizard at any time via the menu (→ page 31).

Please note:

- ◆ If the installation wizard is activated, no other handset can access the **Settings** menu.
- ◆ To exit the installation wizard before the process is complete, **press and hold** the end call key . Changes that you have already saved using **OK** are retained.
- ◆ To skip a setting, press the display key **No**.

ISDN wizard: finding/entering the connection's MSNs

Several personal numbers (MSNs) were provided by the network provider when you received your ISDN connection confirmation. You can save up to ten numbers (MSNs) on your phone. If no MSN has been entered, you can do the following with the ISDN wizard:

- ◆ Assign the MSNs for your connection i.e., call them up from the exchange (automatic MSN assignment) or enter them manually.

Please note: not every ISDN provider supports automatic MSN finding. If this feature is not supported, then you must enter the MSNs for your connection manually (→ page 63).

- ◆ Set the receive MSN
- ◆ Set the send MSN



- ▶ Press the display key **Yes** to start installation.



- ▶ Press the display key **OK** to start automatic MSN finding. This process will take some time.

A corresponding message is shown in the display.



After the MSNs have been found, a list containing the MSNs is displayed.

- ▶ Press the display key **OK** to close the ISDN wizard. The display shows **ISDN installation complete**.

Please note

- ◆ If MSNs cannot be found, you will be asked to enter your MSNs manually (→ page 63).
- ◆ You can change the names of the MSNs (→ page 63).

Connection wizard

The connection wizard **starts automatically** once the ISDN wizard has finished. You can use connection wizard to assign the previously configured numbers to internal parties as well as to receive and, where necessary, send connections.

- ◆ **Receive connections** are numbers (MSNs) on which you can be called. You can assign the MSNs for internal parties as the receive connection. Incoming calls are only diverted to the internal parties to which the relevant receive connection has been assigned.


Setting up the phone – installation wizard

- ◆ **Send connections** are the numbers (MSNs) that are sent to the called party. The network provider calculates charges based on the send connections. You can assign a fixed MSN as a send connection to each internal party.
- ◆ Every MSN can be both a send and receive connection. You can assign each MSN to multiple handsets as a receive connection.


After registration/getting started, the handsets are assigned all MSNs as receive connections. The base number (usually MSN1) is assigned to the devices as a send connection.



- ▶ Press the display key **Yes** if you want to display or change the settings for the send and receive connections for internal parties (here INT 1).
- ▶ Press the display key **No** if you want to change to the next internal party.



The list of receive connections currently assigned is displayed.


Press the bottom of the control key  to scroll through the complete list if necessary.

- ▶ Press the display key **Change** if you want to change the setting for the receive connections.
- ▶ Press the display key **OK** if you do not want to change the setting.


Press **OK**, skip the next two steps and continue with setting the **send connection**.

Press **Change** to display the following:


Setting up the phone – installation wizard



If you do not want incoming calls to MSN1 to be signalled:

- ▶ Press **right** on the control key  to set to **No**.



- ▶ Press **down** on the control key  to switch to the next MSN. Select either **Yes** or **No** as described above.
- ▶ Repeat the steps for each MSN.
- ▶ Press the display key **Save** to complete the settings.

The updated list of receive connections is displayed one more time for you to check.

- ▶ Press the display key **OK** to confirm the assignment.




The current send connection is displayed.

- ▶ To change the setting, press the display key **Change**.
- ▶ Press the display key **OK** if you do not want to change the setting. Skip the following step.

Setting up the phone – installation wizard




If the phone is to make calls via a different MSN:

- ▶ Press the **right** of the control key  repeatedly, until the required MSN is displayed.



- ▶ Press the display key **Save** to save the settings.




If other handsets are registered, you are now asked to assign send and receive connections for these handsets.

- ▶ Follow these steps for each registered handset.



The display indicates briefly that the settings have been successfully completed.

- ▶ Press and **hold** the end call key  to return to idle status.

Installation is complete.

Connecting the headset










You can connect a headset with 2.5 mm jack connectors. See the relevant product page at www.gigaset.com for information on recommended headsets. The headset volume corresponds to the settings for the earpiece volume (→ page 61).

What would you like to do next?

Now you have successfully set up your Gigaset, you will definitely want to adapt it to your personal requirements. Use the following guide to quickly locate the most important topics.



If you are unfamiliar with menu-driven devices such as other Gigaset telephones, read the section "Using the phone" → page 23 first.


Information on is located here.
Setting the ringtone and volume	 page 61
Setting the earpiece volume	 page 61
Setting Eco Mode / Eco Mode+	 page 53
Preparing the telephone for SMS reception	 page 45
Operating the telephone on a PABX	 page 68
Registering existing Gigaset handsets to a base	 page 54
Transferring directory entries from existing Gigaset handsets to new handset(s)	 page 41

If you have any questions about using your phone, please read the tips on troubleshooting (→ page 71) or contact our Customer Care team (→ page 70).

Using the phone





Control key

The side of the control key that you need to press in each operating situation is marked in black below (top, bottom, right, left, centre), e.g.,  for "press right on the control key" or  for "press the centre of the control key".







The control key has a number of different functions:

When the handset is in idle status

-  Open the directory.
-  Open the main menu.
-  Open the list of handsets.
-  Call up the menu for setting the handset's call volume (→ page 61).







In the main menu

-  ,  ,  or 
- Navigate to the required function.




In submenus and lists

-  /  Scroll up/down line by line.

In input fields

Use the control key to move the cursor up , down , right  or left . Press and hold  or  to move the cursor **word by word**.

During an external call

-  Open the directory.
-  Initiate an internal consultation call.
-  Adjust the loudspeaker volume for earpiece and speaker mode.

Functions when pressing the centre of the control key

The key has different functions, depending on the operating situation.


- ◆ **In idle status** the key opens the main menu.
- ◆ **In submenus, selection and input fields**, the key takes on the function of the display keys **OK**, **Yes**, **Save**, **Select** or **Change**.

Please note

These instructions demonstrate opening the main menu by pressing the right of the control key and confirming the functions by pressing the appropriate display key. However, if you prefer, you can use the control key as described above.

Display keys



The functions of the display keys change depending on the operating situation.
Example:



Some of the important display keys are:

Options	Open a menu for further functions.
OK	Confirm selection.
< C	Delete key: delete character by character/word by word from right to left.
Back	Skip back one menu level or cancel operation.
Save	Save entry.
→→	Open the redial list.

Keys on the keypad

-  etc.
Press the key shown on the handset.
-  Enter digits or letters.

Correcting incorrect entries


You can correct incorrect characters in the input fields by using the control key to navigate to the incorrect entry. You can then:

- ◆ Delete the **character** to the left of the cursor with the display key **<C** (press and **hold** to delete the **word**)
- ◆ Insert characters at the cursor position
- ◆ Overwrite the highlighted (flashing) character e.g., when entering time and date.

Using the menus


You can access your telephone's functions by using a menu that has a number of levels.

The menu view can be expanded (**expert mode**) or restricted (**standard mode**). Standard mode is the active default setting.

Settings or functions that are only available in expert mode are marked in these instructions with the  icon.


Switching between standard mode/expert mode and the menu overview (→ page 29).


Main menu (first menu level)


- ▶ When the handset is in idle status, press the **right** control key  to open the main menu.

The main menu functions are shown in the display as icons. The icon for the selected function is highlighted in orange and the name of the associated function appears in the display header.

To access a function i.e., to open the corresponding sub-menu (next menu level):

- ▶ Use the control key  to navigate to the required function and press the display key **OK**.


Briefly press the display key **Back** or the end call key  to return to idle status.





Submenus

The functions in the submenus are displayed as lists (see the example on the right).

To access a function:


- ▶ Scroll to the function with the control key  and press **OK**.

Briefly press the display key **Back** or the end call key  to return to the previous menu level or cancel the operation.



Returning to idle status

You can return to idle status from anywhere in the menu as follows:

- ▶ Press and **hold** the end call key .

Or:

- ▶ Do not press any key: after 2 minutes, the display **automatically** returns to idle status.

Settings that have not been saved by pressing the display keys **OK**, **Yes**, **Save** or **Change** are lost.

An example of the display in idle status is shown on page 15.

Activating/deactivating the handset



With the phone in idle status, press and **hold** the end call key (confirmation tone) to deactivate the handset.
Press and **hold** the end call key again to reactivate the handset.

Please note

When the handset is activated, an animation showing the **Gigaset** logo is displayed for several seconds.

Activating/deactivating the keypad lock

The keypad lock prevents any unwanted use of the phone.



Press and **hold** the hash key in idle status to activate or deactivate the keypad lock. You will hear the confirmation tone.

If the keypad lock is activated, you will see a message when you press a key.

The keypad lock deactivates automatically when you receive a call. It is reactivated when the call is finished.

Please note

When the keypad lock is active, you cannot call emergency numbers.

Understanding the operating steps in the user guide

The operating steps are shown in abbreviated form.


Example:

The illustration:


 ▶  ▶ Eco Mode ▶ Eco Mode+ (☑ = on)

means:




- ▶ Press **right** on the control key  to open the main menu.



- ▶ Press right, left, down and up on the control key  to navigate to the **Settings** submenu.


- ▶ Press the display key **OK** to confirm your selection.



- ▶ Press down on the control key  until the **Eco Mode** menu option appears on the display.

- ▶ Press the display key **OK** to confirm your selection.




- ▶ Press down on the control key  until the **Eco Mode+** menu option appears on the display.

- ▶ Press the display key **Change** to activate/deactivate the function.



The change is effective immediately and does not need to be confirmed.






- ▶ Press the key below **Back** to skip back to the previous menu level.
Or
Press and **hold** the end call key  to return to idle status.

Menu tree

Setting standard or expert mode

The menu display can be expanded (**expert mode**) or restricted (**standard mode**).

To change these settings:

Select   **Menu View**  **Simplified** (standard mode) or **Complete** (expert mode)
 **Select** (the active mode is marked with )

Menu options that are only available in expert mode are marked with the  icon.

Open the main menu: press  **when the phone is in idle mode.**

SMS

New SMS	→ page 45					
Incoming	→ page 47					
Draft	→ page 46					
Settings		<table border="1"> <tr> <td>Service Centres</td> <td>→ page 49</td> </tr> <tr> <td>Notification</td> <td>→ page 49</td> </tr> </table>	Service Centres	→ page 49	Notification	→ page 49
Service Centres	→ page 49					
Notification	→ page 49					

Call Lists

All Calls	→ page 43
Outgoing Calls	→ page 43
Accepted Calls	→ page 43
Missed Calls	→ page 43

Voice Mail

Play Messages	→ page 52
Network Mailbox	→ page 52





 **Select Services**

Next Call	Withhold Number	→ page 38
	Keypad	→ page 38
Call Divert	Internal	→ page 66
	MSN1	→ page 66
	MSN2	
	:	
	MSN10	
Call Waiting		→ page 65
All Calls Anonymous		→ page 65
Busy on Busy		→ page 65
Transfer (ECT)		→ page 66
Ringback Off		→ page 37

 **Additional Features**

Alarm Clock	→ page 54
Room Monitor	→ page 57

 **Settings**

Date/Time	→ page 14
Audio Settings	Handset Volume → page 61
	 Advisory Tones → page 62
	Ringtones(Handset) → page 61
	Music on hold → page 67
Display	Screensaver → page 60
	Large Font → page 60
	Colour Schemes → page 60
	 Backlight → page 60
Language	→ page 60
Registration	Register Handset → page 54
	De-reg. Handset → page 55
	Select Base → page 55
 Telephony	Auto Answer → page 61
	Area Codes → page 63
	ISDN Wizard → page 63
	Send Connection → page 64
	Receive Connections → page 64
	Dialling Mode → page 69
	Access Code → page 68
 System	Handset Reset → page 63
	Base Reset → page 67
	Repeater Mode → page 67
	System PIN → page 67
Menu View	Simplified → page 29
	Complete → page 29
Eco Mode	Eco Mode → page 53
	Eco Mode+ → page 53

Functions during a call

Making a call to multiple participants

If you wish to call several participants, please initiate a consultation call first. You can then speak to the other participants either one at a time ("Call swapping", page 32) or at the same time ("Conference call", page 33).

Consultation call

There are two types of consultation call:

- ◆ **External consultation call:** you call another external participant during an external call.
- ◆ **Internal consultation call:** you call an internal participant during a consultation call.

Initiating an external consultation call

Ext.Call Press the display key.



Enter the number of the new external participant.

Please note

You can also select the second participant's phone number from the directory (→ page 39) or a call list (→ page 43).

Initiating an internal consultation call



Press the control key. The call to the first participant is put on hold.



Enter the number of the required internal participant.

Please note

You can also use to select an internal number (e.g., INT 1) and press / **OK**.

The consultation call participant does not answer

End Press the display key. You return to the first participant.

Consultation call participant's line is busy

You hear the busy tone. You can initiate ring-back (→ page 37).

- ▶ Return to the participant on hold.

The consultation call participant answers

There is now an active connection with the new participant, while the first participant is on hold.

You have the following options:

- ◆ Call swapping (→ page 32)
- ◆ Conference call (→ page 33)
- ◆ Transferring the call (→ page 33).

Call swapping

You can switch between two participants.

Prerequisite: you have set up a consultation call (→ page 32) or accepted a waiting call (→ page 34).



You switch between the two participants.

Ending a consultation call/call swapping

Options Open menu.

End Active Call

Select and press **OK**. The active call is terminated. You return to the waiting participant.

Or:



Press the end call key. The active connection is terminated. You will automatically be called by the external participant on hold.

If the active participant terminates the connection, you will hear the busy tone.

- ▶ Switch to the participant on hold.

If the participant on hold terminates the connection, the active call remains open.

Conference call

You are speaking with two participants at the same time. You can establish a conference call as follows:

- ◆ With two external participants or
- ◆ With one internal participant and one external participant.

Prerequisite: you have set up a consultation call (→ page 32) or accepted a waiting call (→ page 34).

Establishing a conference call

Conf. Press the display key.

Ending a conference call

 Press (idle status).

If at least one connection is external and ECT is activated (→ page 68), the two other conference call participants will be connected with each other. If this is not the case, all calls are terminated.

Ending a conference consultation call (→ page 32)

EndConf Press the display key.

The conference call ends; you are returned to call swap mode (→ page 32). The connection to the external participant is active.

Transferring calls

Transferring a call to another handset

You are making an **external** call and would like to transfer it to another handset.

- ▶ Set up an **internal** consultation call (→ page 32).



Press the end call key (even before the other party has answered) to transfer the call.

Transferring a call to an external number – ECT (Explicit Call Transfer)

You are making an **external** call and would like to transfer it to another external party.

Prerequisites:

- ◆ The feature is supported by your network provider.
- ◆ The ECT function has been enabled on your Gigaset (→ page 66).
- ▶ Set up an **external** consultation call (→ page 32).



Press the end call key (even before the other party has answered) to transfer the call.

Dealing with a waiting external call – CW (Call Waiting)

Prerequisite: call waiting has been set up (→ page 65).

You will hear the call waiting tone (short beep) if you receive an external call during another call. The caller's number or name will appear in the display if Calling Line Identification is enabled.

You have the following options:

Accepting the waiting call – consultation call

Accept Press the display key. You answer the waiting call and the first call is put on hold. Both parties are shown on the display; the current one is marked.

You can call swap (→ page 32), create a conference call (→ page 33) or transfer the call (→ page 33).

Rejecting the waiting call

Reject Press the display key.

You reject the call. The call is no longer signalled. The caller will hear the busy tone

Changing participants



End the current call. The waiting call becomes the "normal" call.



Press the talk key to accept the call.

Making calls

If the display backlight is deactivated (→ page 60), you can reactivate it by pressing any key. The key has no further function in this situation.

Making an external call

External calls are calls using the public telephone network.



Enter the number and press the talk key.

Or:



Press and **hold** the talk key and then enter the number.

The MSN that your phone selects depends on the send connections setting (→ page 64).

- ◆ **Individual MSN** set: the number is dialled immediately via the set MSN.
- ◆ **Select at each call** set: select the send MSN and press **Dial**.

You can also assign the "establishing a connection" function to a display key (→ page 59).

Sel. Line Press the display key.



Select the connection.

Dial

Press the display key.



Enter the number.

You can see the duration of the call while the call is in progress.

If the call costs are to be transferred, these are displayed instead of the call duration.

Please note


Dialling with the directory (→ page 39), call list (→ page 43) and redial list (→ page 42) saves you from repeatedly keying in phone numbers.

Ending a call





Press the end call key.

Accepting a call

The handset indicates an incoming call in three ways: by ringing, with a display on the screen and with the flashing talk key .

You can answer the call by:

- ▶ Pressing the talk key .
- ▶ Pressing the speaker key .

If the handset is in the base/charger and the **Auto Answer** function is activated (→ page 61), the handset automatically answers the call when you remove it from the base/charger.

To deactivate the ringtone, press the **Silence** display key. You can accept the call while it is displayed on the screen.

Rejecting a call

press the display key **Reject**.

The call is rejected for the entire MSN group.


Calling Line Identification

When you receive a call, the caller's number is displayed on the screen, if the following prerequisites are met:

- ◆ Your network provider supports CLIP, CLI.
 - CLI (Calling Line Identification): the caller's number is transmitted.
 - CLIP (Calling Line Identification Presentation): the caller's number is displayed.
- ◆ You have requested CLIP from your network provider.
- ◆ The caller has requested CLI from the network provider.

Call display with CLIP/CLI

If the caller's number is saved in your directory, the caller's name will be displayed. If you have changed the name of the MSN called (→ page 63), this will be displayed.



- 1 Ringer icon
- 2 Number or name of caller
- 3 Receive MSN that is being called

The following is displayed instead of the number:

- ◆ **External**, if no number is transmitted.
- ◆ **Unavailable**, if the caller has not requested Calling Line Identification.

Please note

If you do not wish to be disturbed by unknown callers, you can deactivate the ringtone (→ page 61).

Speaker

In speaker mode, instead of holding the handset to your ear you can put it down, for example on the table in front of you. This allows others to participate in the call.

Activating/deactivating speaker mode

Activating while dialling



Enter the number and press the speaker key.

- ▶ Inform your caller before you use the speaker function so that they know a third party may be listening.


Switching between earpiece and speaker mode



Press the speaker key.

During a call, activate or deactivate speaker mode.

If you wish to place the handset in the base/charger during a call:

- ▶ Press and hold the speaker key  while placing the handset in the base/charger and for a further 2 seconds.

For instructions on adjusting the speaker volume, see → page 61.

Muting



You can deactivate the microphone in your handset during an external call.



Press the key to mute the handset. The display shows **Microphone is off**.

Press the key again to unmute the microphone.

Please note

If the telephone is muted, only the mute key  and the end call key  will work.

Ringback when busy (CCBS)/ when the call is not answered (CCNR)

If the person you are calling does not answer or their line is busy, you can initiate ringback.

Prerequisite: the exchange supports this feature.

Activating ringback

Ringback Press the display key and wait for confirmation from the exchange.

At the time of the ringback:

- ◆ Ringback when busy – CCBS:
CCBS = Completion of calls to busy subscriber. The ringback takes place as soon as the subscriber in question terminates the current call.
- Ringback when there is no reply – CCNR:
CCNR = Completion of calls no reply. The ringback takes place as soon as the subscriber in question has made a call.

Please note:

- ◆ The ringback request is automatically cancelled after approximately 2 hours (depending on the exchange).
- ◆ If you are making a call at the time of the ringback, the ringback will be postponed until you have ended your call.
- ◆ Ringbacks are not diverted if an internal call diversion is active.

Activating ringback for external consultation calls

You want to establish an external consultation call (→ page 32). The consultation call participant's line is busy. You can activate a ringback:

Options Open menu.

Ringback Select and press **OK**.

Accepting a ringback


The handset rings and the screen displays the ringback number.

Establishing a connection

 Press the talk key.

You will hear the ringing tone. The other participant is being called. The connection is established.

Cancelling ringback

  **Ringback Off**
Select and press **OK**.




The display shows that the ringback has been cancelled or that no ringback was activated.


Configuring settings for the next call


Activating/deactivating "withhold number" for the next call

You can withhold your phone number for the next call (CLIR = Calling Line Identification Restriction).

In idle status:

  **Next Call**  **Withhold Number**
Select and press **OK**.

 Enter the number or copy from the directory.

Send Press the display key or the talk key 

The MSN that your phone selects depends on the send connections setting (→ page 64).




- ◆ **Individual MSN** set: the number is dialed automatically.
- ◆ **Select at each call** set: select the send MSN and press **Dial**.


Generally speaking, you can withhold your number for all calls (→ page 65).


Activating/deactivating the keypad function for the next call

The **Keypad** function allows you to control certain features by entering sequences of characters and digits. For keypad control (→ page 69).

You can temporarily activate keypad control for the next call.

  **Next Call**  **Keypad**
Select and press **OK**.

 Enter the phone number.

Send Press the display key or the talk key  The number is dialed.

Identifying nuisance callers – caller ID detection

Caller ID detection is used to identify annoying or threatening callers.

Prerequisite: you have requested caller ID detection from your network provider. Please contact your network provider first if you experience any problems.

Setting up caller ID detection

If you have requested caller ID detection, increase the time until the connection is terminated:


     

0 + **OK** Increase the time until the connection is terminated to 30 seconds.

Or

1 **OK** Set the time until the connection is terminated to 3 seconds.

Determining the caller

Carry out the following steps during the call or immediately after the caller has hung up. You must not press the end call key !

Options  **Identify Caller**

The caller is identified by the exchange. You will receive a list from your network provider at a later date giving the caller's number and the time and date. Your network provider will provide you with more detailed information.

Using the directory and lists

The options are:

- ◆ Directory
- ◆ Redial list
- ◆ Incoming message list
- ◆ Call lists
- ◆ Missed alarmslist.

You can create a personalised directory for your own handset. You can also send lists/entries to other handsets (→ page 41).

Directory

You can save up to 150 entries in the directory.


Please note

To quickly access a number from the directory, (quick dial), you can assign the number to a key (→ page 59).

Directory

In the **directory**, you can save:

- ◆ Up to three numbers and associated first names and surnames
- ◆ E-mail addresses
- ◆ Anniversaries with reminder
- ◆ VIP ringer with VIP icon.

Open the directory in idle status using the  key.

Length of the entries

3 numbers: each max. 32 digits
 First name and surname: each max. 16 characters
 E-mail address: max. 64 characters

Saving a number in the directory

 > <New Entry>

▶ You can enter data in the following fields:

First Name:/Surname:

Enter first names and/or surnames.




If you do not enter a name in either of the fields, the phone number is saved and displayed in place of a surname.

(For instructions on entering text and special characters, please see page 75.)

Phone (Home):/Phone (Office):/

Phone (Mobile):

Enter a number in at least one of the fields.

When scrolling through the directory, the entries are highlighted by a prefixed symbol: //.

E-mail:

Enter the e-mail address.

Anniversary


Select **On** or **Off**.

With setting **On**:

Enter **Annivers. (Date)** and **Anniversary (time)** and select reminder type: **Anniversary (tone)** → page 41.

VIP Group:

Mark directory entry as **VIP** (Very Important Person).

Each entry can be assigned to one of 6 VIP groups, which are defined by the colour of the  icon, the name of the VIP group and the corresponding ringtone.

VIP calls are identified by the ringtone.

The ringtone animation background colour changes to the VIP group colour.

Prerequisite: Calling Line Identification (→ page 36).

Save

Press the display key.

Order of directory entries

Directory entries are generally sorted alphabetically by surname. Spaces and digits take first priority. If only the first name was entered in the directory, this is incorporated into the sort order instead of the surname.

The sort order is as follows:



1. Space
2. Digits (0–9)
3. Letters (alphabetical)
4. Other characters

To get round the alphabetical order of the entries, insert a space or a digit in front of the first letter of the surname. These entries will then move to the start of the directory.



Selecting a directory entry



 Open the directory.

You have the following options:

- ◆ Use  to scroll through the entries until the required name is selected.
- ◆ Enter the first letter of the name; use the  key to scroll to the entry if necessary. The directory searches for the surname. If a surname has not been entered, the directory searches for the first name.



Dialling using the directory

  (Select entry).

 Press the talk key. (If several numbers are entered, select the required number and press the talk key  again). The number is dialled.


Managing directory entries

Viewing entries


  (Select entry).

View Press the display key. The entry is displayed.

Options Press the display key.

The following functions can be selected with :

Display Number

To edit or add to a saved number, or to save it as a new entry, press  after the number is displayed.

Delete Entry



Delete selected entry.

Copy Entry

to Internal: Send a single entry to a handset (→ page 41).

vCard via SMS: Send a single entry in vCard format via SMS.



Editing an entry

  (Select entry).


View **Edit** Press the display keys one after the other.

- ▶ Make the changes and save.



Using other functions

  (Select entry)

▶ **Options** (Open menu)

The following functions can be selected with :

Display Number

Edit or add to a saved number and then dial with  or save as a new entry; to do so, press  after the number is displayed.

Edit Entry

Edit selected entry.

Delete Entry

Delete selected entry.

Copy Entry

to Internal: Send a single entry to a handset (→ page 41).

vCard via SMS: Send a single entry in vCard format via SMS.

VIP Groups

Edit VIP group name and ringtone. To do this:

Select VIP group ▶ **Edit** ▶ Edit entry
▶ **Save**

Delete All

Delete **all** entries in the directory.

Copy All

to Internal: Send the complete list to a handset (→ page 41).

Available Memory



Display the number of entries that are still available in the directory (→ page 39).

Using quick dial keys

- ▶ Press and **hold** the required quick dial key (→ page 59).


Transferring the directory to another handset**Prerequisites:**

- ◆ The sending and receiving handsets must both be registered to the same base.
- ◆ The other handset and the base can send and receive directory entries.

 ▶  (Select entry)

▶ **Options** (Open menu)

▶ **Copy Entry / Copy All** ▶ **to Internal**

 Select the internal number of the receiving handset and press **OK**.

You can transfer several individual entries one after another by responding to the **Entry copied - Copy next entry?** prompt with **Yes**.

A successful transfer is confirmed by a message and confirmation tone on the receiving handset.

Please note:

- ◆ Entries with identical numbers are not overwritten on the receiving handset.
- ◆ The transfer is cancelled if the phone rings or if the memory of the receiving handset is full.
- ◆ Pictures and sounds assigned to entries are not transferred.

Copying the displayed number to the directory

You can copy numbers displayed in a list, e.g., the call list or the redial list, or in an SMS, to the directory.



A number is displayed:


Options ▶ **Copy to Directory**

- ▶ Complete the entry (→ page 39).

Copying a number or e-mail address from the directory



In some operating situations, you can open the directory to copy a number or email address, for example. Your handset need not be in idle status.

- ▶ Depending on the operating situation, open the directory with  or .


 Select entry (→ page 40).

Saving an anniversary in the directory

For each number in the directory, you can save an anniversary and specify when a reminder call should be made on the anniversary (default setting: **Anniversary Off**).

 ▶  (Select entry)

View **Edit** Press the display keys one after the other.

 Scroll to the **Anniversary** line.

 Select **On**.

- ▶ You can enter data in the following fields:

Annivers. (Date)

Enter day/month/year in 8-digit format.

Anniversary (time)

Enter the hour/minute for the reminder call in 4-digit format.

Anniversary (tone)

Select the reminder type.



Using the directory and lists

Save Press the display key.


Please note


A time must be specified for reminder calls. If you select a visual signal, a time is not required and is automatically set to 00.00.

Deactivating anniversaries

  (Select entry)

View **Edit** Press the display keys one after the other.


 Scroll to the **Anniversary** line.

 Select **Off**.

Save Press the display key.

Reminder call on an anniversary

In **idle status**, a reminder call is shown in the display of the handset and signalled with the selected ringtone.



You can:

SMS Write an SMS.

Off Press the display key to acknowledge and end the reminder call.


When you are on the phone, a reminder call is indicated on the handset with a **single** advisory tone.

Anniversaries that are indicated during a call and are not acknowledged are entered on the **Missed Alarms** list (→ page 44).


Using the redial list

The redial list contains the twenty numbers last dialled with the handset (max. 32 digits). If one of the numbers is in the directory, the corresponding name is displayed.

Manual redialling


 Press the key **briefly**.

 Select entry.

 Press the talk key again. The number is dialled.


When a name is displayed, you can display the corresponding phone number by pressing the display key **View**.

Managing entries in the redial list

 Press the key **briefly**.

 Select entry.

Options Open menu.

The following functions can be selected with :

Copy to Directory

Copy an entry to the directory (→ page 39).

Display Number (as in the directory, page 40)

Delete Entry (as in the directory, page 40)

Delete All (as in the directory, page 40)

Using the incoming message list

All received SMS messages are saved in the incoming message list (→ page 47).

Call lists

Prerequisite: Calling Line Identification Presentation (CLIP, page 36)

Your telephone saves various types of calls:

- ◆ Accepted calls
- ◆ Outgoing calls
- ◆ Missed calls

You can view each type of call separately or get an overview of all calls. The last

- ◆ 20 incoming calls,
- ◆ 20 missed calls,
- ◆ and 40 outgoing calls are displayed.

In idle status, open the call lists by selecting the **Calls** display key or via the menu:



List entry

New messages are displayed at the top.

Example of list entries:

All Calls	
Frank	
14.10.09, 15:40	
089563795	
14.10.09, 15:32	
...0123727859362922	
14.10.09, 15:07	
View	Options

- ◆ List type (in header)
- ◆ Status of entry
 - Bold:** new entry
- ◆ Number or name of caller
- ◆ Name of MSN to which the missed/accepted call was directed (**for** receive connection), or via which the outgoing call was dialled (**via** send connection)
- ◆ Date/time of call (if set, page 14)
- ◆ Type of entry:
 - Accepted calls ()
 - Missed calls ()
 - Outgoing calls ()

Press the talk key to call the selected caller back.

Press the **View** display key to access additional information, for example the number linked to the name

Press the **Options** display key to select the following options:

Copy to Directory

Copy the number to the directory.

Delete Entry

Delete selected entry.

Delete All

Delete all entries.


When you exit the call lists, all entries are set to the status "old", i.e., the next time you call up the list, they will no longer be shown in bold.






Accessing lists with the message key

Use the message key  to access the following lists:





- ◆ network mailbox, if your network provider supports this function and fast access is specified for the network mailbox (→ page 52).
- ◆ Incoming message list (→ page 47)
- ◆ Missed calls list
- ◆ Missed alarms list (→ page 44)

These lists display the calls and SMS messages belonging to the receive MSNs assigned to the handset.

An advisory tone sounds as soon as a **new entry** arrives in a list. The  key flashes (disappears when the key is pressed). In **idle status**, the display shows an icon for the new message:


	New message...
	...on the network mailbox
	... in the Missed Calls list
	... in the SMS list
	... in the Missed Alarms list

The number of **new** entries is displayed under the corresponding icon.

			
02	10	09	08

Please note

If calls are saved in the network mailbox, you will receive a message if the appropriate settings have been made (see your network provider user guide).

After pressing the message key , you can see all the lists containing messages and the network mailbox list.


Lists containing new messages are at the top and are in bold.

Messages & Calls	
Calls:	(3)
Missed Alarms	(1)
SMS:	(2)
Back	OK

Select a list with . To open, press **OK**.

Missed alarms list

Missed anniversaries (→ page 41) are displayed in the **Missed Alarms** list if:

- ◆ You do not accept an anniversary.
- ◆ The anniversary was signalled during a phone call.
- ◆ The handset is deactivated at the time of the anniversary.
- ◆ Open the list by pressing the **message key**  (→ page 44).

Each entry is displayed with:

- ◆ Number or name
- ◆ Date/time

for each. The most recent entry is at the head of the list.

Press the display key **Delete** to delete the selected entry.

If 10 entries are already saved in the list, the next appointment reminder will delete the oldest entry.

Sending SMS (text messages)

Your device is supplied ready for you to send text messages immediately.

Prerequisites:

- ◆ Calling Line Identification is enabled for your phone line.
- ◆ Your network provider supports SMS on the fixed network (information on this can be obtained from your network provider).
- ◆ You are registered with your service provider to send and receive SMS.
- ◆ To receive SMS messages, you must be registered with your service provider. This happens automatically when you send your first SMS.

Please note

- ◆ You can access all incoming or saved SMS messages from all handsets, regardless of which MSN the handset is assigned to.
- ◆ If your phone is connected to a PABX, please read page 50.
- ◆ The send/receive MSN must correspond to the number that is registered at your SMS centre (→ page 49).

Writing/sending an SMS

Writing an SMS



New SMS Select and press **OK**.



Write an SMS.

Please note

- ◆ For instructions on entering text and special characters, please see page 75.
- ◆ An SMS can be up to 612 characters. If there are more than 160 characters, the SMS is sent as a **linked** SMS (up to 4 SMS messages with 153 characters each). The top right of the display shows how many characters are still available and which part of a linked SMS is currently being written.

Sending an SMS



Press the talk key

Or:



Press the display key.

Send

Select and press **OK**.

SMS

Select and press **OK**.



Select the number with the local code (even if you are in that area) from the directory or enter it manually. For SMS to an SMS mailbox: put the mailbox ID at the **end** of the number.



Press the display key. The SMS is sent.

Please note

- ◆ If you are interrupted by an external call while writing an SMS, the text is automatically saved in the draft message list.
- ◆ If the memory is full, or if the SMS function on the base is being used by another handset, the operation is cancelled. An appropriate message appears in the display. Delete SMS messages you no longer require or send the SMS later.

Sending SMS (text messages)

Draft message list

You can save an SMS in the draft message list, edit it later and send it.

Saving an SMS in the draft message list

▶ You are writing an SMS (→ page 45).


Options Press the display key.

Save Entry Select and press **OK**.

Opening the outgoing list

 ▶  ▶ **Draft**


The first list entry is displayed, for example:




If the entry has been saved with the phone number, i.e., when the SMS was saved from the incoming message list, the number is displayed in the first line.

Reading or deleting SMS messages

▶ Open the draft message list and then:

 Select SMS.

Read Press the display key. The text is displayed. Scroll line by line using .

Or delete the SMS with

Options ▶ **Delete Entry** ▶ **OK**.

Writing/editing an SMS

▶ You are reading an SMS in the draft message list.

Options Open menu.

You have the following options:

Copy

Send saved SMS.

Edit

Edit the text of the saved SMS and then send (→ page 45).

Character Set

Display text in the selected character set.

Deleting the draft message list

▶ Open the draft message list and then:

Options Open menu.



Delete All Select, press **OK** and confirm with **Yes**. The list is deleted.

Sending SMS messages to an e-mail address

If your service provider supports the **SMS as e-mail** feature, you can also send your SMS messages to e-mail addresses.

The e-mail address must be at the beginning of the text. You must send the SMS to your SMS service centre's e-mail service.

 ▶  ▶ **New SMS**

 /  Copy the e-mail address from the directory or enter it directly. End the entry with a space or colon (depending on the service provider).

 Enter the SMS text.

Options Press the display key.

Send Select and press **OK**.

E-mail Select and press **OK**. If the number of the e-mail service is not entered (→ page 49), enter the number of the e-mail service.

Send Press the display key.

Sending SMS messages as a fax

You can also send an SMS to a fax machine.



Prerequisite: your network provider supports this feature.

▶ You are writing an SMS (→ page 45).

Options Press the display key.

Send Select and press **OK**.

Fax Select and press **OK**.

 /  Select number from the directory or enter it manually. Enter the number with the local code (even if you are in the same area).

Send Press the display key.

Receiving an SMS



All received text messages are saved in the incoming message list. Linked SMS messages are displayed as **one** message. If this is too long or is not transferred completely, it is split into individual messages. Since an SMS remains in the list even after it has been read, you should **regularly delete SMS messages from the list**.

- ▶ If the SMS memory is full, a message to this effect is displayed. Delete SMS messages you no longer require (→ page 47).

Incoming list

The incoming message list contains:

- ◆ All incoming SMS messages, regardless of which MSN the SMS has been sent to. The most recent SMS appears at the top of the list.
- ◆ SMS messages that could not be sent due to an error.

New SMS messages are signalled on all Gigaset C59H handsets by the  icon on the display, the flashing message key  and an advisory tone.

Opening the incoming list with the key

 Press.

The incoming list is displayed with the number of entries (example):

SMS: (2)

Bold: new entries

Normal font: old entries

Every entry in the list contains:

- ◆ The number or name of the sender
- ◆ The receive MSN to which the SMS is addressed

- ◆ The date of receipt.

0123727859362922
for MSN2
14.10.10 09:07

Opening the incoming list via the SMS menu

  Incoming

Deleting the incoming message list

All **new and old** SMS messages in the list are deleted.


- ▶ Open the incoming message list.


Options Open menu.

Delete All Select, press **OK** and confirm with **Yes**. The list is deleted.

Reading or deleting SMS messages

- ▶ Open the incoming message list, then:

 Select SMS.

Read Press the display key. The text is displayed. Scroll line by line using .

Or delete the SMS with

Options ▶ **Delete Entry** ▶ **OK**.

After you have read a new SMS, it is given the status "Old" (is no longer shown in bold).

Changing the character set

- ▶ Read the SMS

Options Press the display key.

Character Set

Text is shown in the selected character set.

Replying to or forwarding text messages

- ▶ Read the SMS

Options Press the display key.

You have the following options:

Reply

Write and send a new SMS to the sender's number (→ page 45).

Sending SMS (text messages)

Edit

Edit the text in the SMS and return it to the sender (→ page 45).

Forward

Forward the SMS to another number (→ page 45).

Copying the number to the directory

Copying the sender's number

- ▶ Open the incoming message list and select the SMS (→ page 47).

Options ▶ Copy to Directory

- ▶ Complete the entry (→ page 41).


Please note

If a mailbox identifier is attached, it is added to the directory.

Copying/dialling numbers from an SMS


- ▶ Read the SMS and scroll to the telephone number.

The digits are highlighted.

 Press the display key.

Complete the entry (→ page 41).

Or:


 Press the talk key to dial the number.

If you also want to use the number to send an SMS:

- ▶ Save the number in the directory with the local area code (local code).

If an SMS contains several numbers, the next number will be highlighted if you scroll down until the first number disappears from the display.

SMS with vCard

The vCard is an electronic business card. It is indicated by the  icon in the body of the SMS.

A vCard can include:

- ◆ Name
- ◆ Private number
- ◆ Business number
- ◆ Mobile phone number
- ◆ Birthday

Entries in a vCard can be saved to the directory individually.

Opening the vCard

- ▶ Read the SMS containing the vCard.

View Press the display key.
To return to the body of the SMS, press **Back**.

 Select the number.

Save Press the display key.

When you save a number, the directory is opened automatically. The number and name are copied. If the vCard contains a birthday, the date is copied to the directory as an anniversary.

- ▶ Edit the entry in the directory, if necessary, and save it. You will return to the vCard automatically.

Receiving notifications via SMS

You can be notified about missed calls via SMS.

Prerequisite: the caller's number (CLI) must have been transmitted in the missed call.

Notifications are sent to your mobile phone or another phone with SMS functionality.

You only need to save the telephone number to which you want to send the notification.

 ▶  ▶ **Settings** ▶ **Notification**


▶ You can enter data in the following fields:

To:

Enter the number to which the SMS should be sent.

On missed call

Select **On** if you require SMS notification.

 Press the display key.

Warning

Do **not** enter your own fixed line network number for notifying of missed calls. This can create an endless loop that will incur charges.

Setting up the SMS centre


Text messages are exchanged between SMS centres that are operated by service providers. You must enter the SMS centre in your device through which you wish to send and receive. You can receive SMS from **every** SMS centre that is entered if you have registered with your service provider.

Your SMS messages are sent via the **SMS service centre** that is entered as the **active send service centre**. However, you can activate any other SMS centre as the active send service centre to send a current message (→ page 49).

If no SMS service centre is entered, the SMS menu only contains the entry **Settings**. Enter an SMS service centre (→ page 49).

Entering/changing the SMS service centre


▶ Find out about the services and special functions offered by your service provider **before you make a new application** and/or before you delete pre-configured numbers.

 ▶  ▶ **Settings** ▶ **Service Centres**

 Select the SMS service centre (e.g., **Service Centr. 1**) and press .

▶ You can enter data in the following fields:

Active Send:

Select  if SMS messages are to be sent via the SMS centre. For the SMS centres 2 to 4, the setting only applies to the next SMS.

SMS Service Centre no.:


Enter the number of the SMS service centre and insert a star if your service provider supports personal mailboxes.

E-mail Service no.:

Enter the number of the e-mail service.

Send via:

Specify the MSN via which SMS messages should be sent.

 Press the display key.

Please note

Ask your service provider for details on entering service numbers if you wish to use personal mailboxes (prerequisite: your service provider supports this function).

Sending an SMS via another SMS centre

▶ Activate the SMS centre (2 to 4) as the active send service centre.
▶ Send the SMS.

This setting only applies to the next SMS to be sent. After that, the setting returns to **Service Centr. 1**.

SMS to PABXs

- ◆ You can only receive an SMS when **Calling Line Identification** is **forwarded** to the extension of the PABX (**CLIP**). The CLIP of the phone number for the SMS centre is evaluated in your **Gigaset**.
- ◆ Depending on your PABX, you may have to add the access code (outside line code) before the number of the SMS centre. If in doubt, test your PABX, e.g., by sending an SMS to your own number: once with the access code and once without.
- ◆ When you send SMS messages, your sender number may be sent without your extension number. If this is the case, the recipient cannot reply to you directly.

Sending and receiving SMS on ISDN PABXs is only possible via the MSN number assigned to your base.

Activating/deactivating SMS function

If you deactivate the SMS function, you cannot send or receive any further SMS messages with your phone.

The settings you have created for sending and receiving SMS messages (i.e., the numbers of the SMS service centres) and the entries in the incoming and outgoing lists are saved even after deactivation.



Open the main menu.

* Δ ←→ # | 0 + | 5 JKL | ←→ # | 2 ABC | MNO 6

Enter the digits.

0 + | OK

Deactivate the SMS function.

Or:

1 ∞ | OK

Activate the SMS function (default setting).

SMS troubleshooting

Error codes when sending

EO	Calling Line Identification permanently restricted (CLIR) or Calling Line Identification not activated.
FE	Error occurred during SMS transfer.
FD	Connection to SMS centre failed, see self-help.

Self-help with errors

The following table lists error situations and possible causes and provides notes on troubleshooting.

<p>You cannot send messages.</p> <ol style="list-style-type: none"> You have not requested the CLIP service (Calling Line Identification Presentation). <ul style="list-style-type: none"> Ask your service provider to enable this service. SMS transmission has been interrupted (e.g., by a call). <ul style="list-style-type: none"> Re-send the text message. The network provider does not support this feature. No number or an invalid number is entered for the SMS service centre set as the active send service centre. <ul style="list-style-type: none"> Enter the number (→ page 49).
<p>You receive an incomplete SMS.</p> <ol style="list-style-type: none"> Your phone's memory is full. <ul style="list-style-type: none"> Delete old SMS messages (→ page 46). The service provider has not yet sent the rest of the SMS.
<p>You have stopped receiving SMS messages.</p> <p>Call divert (divert) is set to When: All Calls or All Calls is activated for the network mailbox.</p> <ul style="list-style-type: none"> Change the call divert settings (→ page 66).

The SMS message is played back.

- The "display call number" service is not activated.
 - Ask your service provider to enable this feature (there is a charge for this).
- No agreement is in place between your mobile phone operator and your fixed line network SMS service provider.
 - Contact your network SMS service provider for information.
- Your terminal has been recorded by your SMS provider as having no fixed line network SMS functionality i.e., you are not registered with the provider.
 - Send any SMS to automatically register your telephone to receive SMS.

Messages are only received during the day.

- The terminal is recorded in your SMS provider's database as having no fixed line network SMS functionality i.e., you are not registered with the provider.
- Contact your network SMS service provider for information.
 - Send any SMS to automatically register your telephone to receive SMS.

Using the network mailbox

The network mailbox is your network provider's answering machine within the network. You can only use the network mailbox if you have **requested** it from your network provider.

Configuring fast access for the network mailbox

With fast access, you can dial the network mailbox directly.

fast access is pre-set for the network mailbox. You only need to enter the number of the network mailbox.

Configuring fast access for the network mailbox and entering the network mailbox number

  **Network Mailbox**



Enter the number for the network mailbox.

Save

Press the display key.


The setting for fast access applies to all Gigaset handsets.

Calling the network mailbox



Press and **hold**. You are connected straight to the network mailbox.



Press speaker key  if required. You will hear the network mailbox announcement.

Viewing the network mailbox message

When a message is recorded, you receive a call from the network mailbox. If you have requested Calling Line Identification, the network mailbox number is displayed. If you accept the call, the new messages are played back. If you do not accept the call, the network mailbox number is saved in the missed calls list and the message key flashes (→ page 44).

ECO DECT

You are helping to protect the environment with your Gigaset CX590 ISDN.

Reduced energy consumption

Your telephone has a power-saving adapter plug and uses less power.

Reducing radiation

The radiation from your telephone is reduced **automatically**:

- ◆ **Handset:** The closer the handset is to the base, the lower the radiation.
- ◆ **Base station:** The radiation is reduced to virtually zero when only one handset is registered and the handset is placed in the base.

You can reduce the radiation from the handset and base even more by using **Eco Mode**:

- ◆ **Eco Mode**
Reduces the radiation of the base station and handset by 80% - whether you are making a call or not. **Eco Mode** reduces the range of the base station by approx. 50%. Using **Eco Mode** always makes sense when a reduced range is sufficient.



Switching off radiation

- ◆ **Eco Mode+**
When you activate **Eco Mode+**, the radiation (DECT transmission power) of base and handset is switched off automatically in idle status. This is also true when multiple handsets are used, if the handsets support **Eco Mode+**.

Eco Mode/Eco Mode+ can be activated/deactivated independently of one another and can also be used with multiple handsets. The handset need not be placed in the base.






Eco Mode/Eco Mode+

Activate/deactivate:


  **Eco Mode**
▶ **Eco Mode/Eco Mode+**

Change Press the display key (☑ = on).

Status displays

Display icon	
	Reception strength: – Good to poor – No reception
 white	Eco Mode deactivated
 green	Eco Mode enabled
 white	Eco Mode+ enabled (displays instead of the reception strength icon when in idle status)
 green	Eco Mode and Eco Mode+ activated

Please note

- ◆ When using **Eco Mode+** you can ensure that the range of the base is sufficient by pressing and **holding** the talk key . You hear the dial tone if the base can be reached.
- ◆ When **Eco Mode+** is enabled:
 - Call setup is delayed by approx. 2 seconds.
 - Handset standby time is reduced by approx. 50%.
- ◆ Registering handsets that do not support **Eco Mode+** causes the mode to be deactivated on the base and all other handsets.
- ◆ Activating **Eco Mode** reduces the range of the base.
- ◆ **Eco Mode / Eco Mode+** and repeater support (→ page 67) cancel each other out, i.e., if you use a repeater, you cannot use **Eco Mode** and **Eco Mode+**.

Setting the alarm clock

Prerequisite: the date/time has already been set (→ page 14).

Activating/deactivating the alarm clock and setting the wake-up time

 ▶  ▶ Alarm Clock

▶ You can enter data in the following fields:

Activation:

Select **On** or **Off**.

Time:


Enter the wake-up time in 4-digit format.

Volume:

Set the volume (1–6).

Melody:

Select the melody.

 Press the display key.


In idle status, the  icon and wake-up time are displayed.

A wake-up call is signalled on the display (→ page 3) and with the selected ringer melody. The wake-up call sounds for 60 seconds. If no key is pressed, the wake-up call is repeated twice at five-minute intervals and then switched off.


During a call, the wake-up call is only signalled by a short tone.

Deactivating the wake-up call/ repeating after a pause (snooze mode)

Prerequisite: a wake-up call is sounding.

 Press the display key. The wake-up call is deactivated.

Or

 Press the display key or any key. The wake-up call is deactivated and repeats after 5 minutes. After the second repetition the wake-up call is deactivated completely.


Using multiple handsets

Registering handsets

You can register up to six handsets to your base.

A Gigaset handset can be registered on up to four bases.

Please note:

After successful registration the  message key will flash. Press this button to start the connection wizard (→ page 17) and assign the MSNs to the handset (default setting: all MSNs are used as receive MSNs and the first MSN is used as a send MSN for this handset).

You can change this assignment later (→ page 63).


Manually registering Gigaset C59H to Gigaset CX590 ISDN

You must activate manual registration of the handset on both the handset (1) and the base (2).

Once registration is complete, the handset returns to idle status. The handset's internal number is shown in the display e.g., INT 1. If not, repeat the procedure.

1) On the handset

The handset is not registered to a base.


 Press the display key.


The handset is already registered to a base:

 ▶  ▶ Registration

▶ Register Handset

If the handset is already registered to four bases:

 Select base, e.g., **Base 3** and press **OK**.

 Enter the system PIN for the base, if required, and press **OK**.

A message appears stating that the handset is searching for a base that is ready for registration.

2) On the base

Within 60 seconds, press and **hold** the register/paging key on the base (→ page 2) (for approx. 3 seconds).

Registering other handsets

You can register other Gigaset handsets and handsets for other devices with GAP functionality as follows.

On the handset

- ▶ Start to register the handset as described in its user guide.


On the base

Press and **hold** the register/paging key on the base (→ page 2) (approx. 3 sec.).


De-registering handsets

You can de-register any other registered handset from any registered Gigaset C59H handset.

-  ▶  ▶ **Registration**
- ▶ **De-reg. Handset**

 Select the internal party you wish to de-register and press **OK**.

(The handset you are currently using is highlighted with $\leftarrow\rightarrow$.)

 Enter the current system PIN and press **Save**.


Yes Press the display key.

Locating a handset ("paging")

You can locate your handset using the base.

- ▶ **Briefly** press the register/paging key on the base (→ page 2).
- ▶ All handsets will ring at the same time ("paging"), even if the ringtones are switched off.


Ending paging

- ▶ **Briefly** press the register/paging key on the base or press the talk key  on the handset.

Changing the base

If your handset is registered to more than one base, you can set it to a particular base or to the base that has the best reception (**Best Base**).


-  ▶  ▶ **Registration** ▶ **Select Base**


 Select one of the registered bases or **Best Base** and press **Select**.

Making internal calls


Internal calls to other handsets registered on the same base are free.

Calling a specific handset

 Initiate internal call.

 Enter the number of the handset.

Or:

 Initiate internal call.

 Select handset.

 Press the talk key.

Calling all handsets ("group call")

 Initiate internal call.

 Press the star key.


Or

Call All Select and

 Press the talk key.

All handsets are called.



Ending a call

 Press the end call key.

Using multiple handsets


Transferring a call to another handset

You can transfer (connect) an external call to another handset.

-  Open the list of handsets.
The external participant hears music on hold, if activated
(→ page 67).
-  Select a handset or **Call All** and press **OK**.


When the internal participant answers:

- ▶ Announce the external call, if necessary.

 Press the end call key.

The external call is transferred to the other handset.

If the internal participant does **not** answer or the line is busy, press the display key **End** to return to the external call.



When transferring a call, you can also press the end call key  before the internal party answers.

If the internal participant does not answer or the line is busy, the call will automatically return to you.

Initiating an internal consultation/conference

When you are conducting an **external** call, you can call an **internal** participant at the same time for consultation or hold a conference call between all 3 participants.

You are conducting an **external** call:

-  Open the list of handsets.
The external participant hears music on hold, if activated
(→ page 67).
-  Select handset and press **OK**.
You are connected to the internal participant.

Either:

Options Press the display key.


End Active Call


Select and press **OK**. You are reconnected with the external participant.

Or:

Conference Press the display key.
All 3 participants are connected with each other.

Ending a conference call

 Press the end call key.

If an **internal** participant presses the end call key , the other handset remains connected to the external participant.

Accepting/rejecting call waiting

If you get an **external** call while conducting an **internal** call, you will hear the call waiting tone (short tone). The caller's number will appear in the display if Calling Line Identification is enabled.

Ending an internal call, accepting an external call

Accept Press the display key.

The internal call is **ended**. You are connected to the external caller.




Rejecting the external call

Reject Press the display key.

The call waiting tone is turned off. You remain connected with the internal participant.



Changing the name of a handset

The names "INT 1", "INT 2" etc. are assigned automatically on registration. You can change these names. The name must be no more than 10 characters. The changed name is displayed in every handset's list.

-  Open the list of handsets. Your own handset is indicated by <.
-  Select the handset.
- Options** Open the menu.
- Rename** Select and press **OK**.
-  Enter the name.
- Save** Press the display key.

Changing a handset's internal number

A handset is **automatically** assigned the lowest free number when it is registered. If all the slots are occupied, number 6 is overwritten if this handset is in idle status. You can change the internal number of all the registered handsets (1–6).

-  Open the list of handsets. Your own handset is indicated by <.
- Options** Open the menu.
- Assign Handset No.** Select and press **OK**.
-  Select the number.
- Save** Press the display key to save the input.

Using a handset as a room monitor

If the room monitor is activated, the phone number saved in the system is called as soon as a set noise level is reached. You can save an internal or external number in your handset as the destination number. All of the handset keys are deactivated except for the display keys.

The room monitor call to an external number is cancelled after approximately 90 seconds. The room monitor call to an internal number (handset) is cancelled after approx. 3 minutes (depending on the base). When the room monitor is activated, all keys are locked except for the end call key. The handset's speaker is muted.

When room monitor mode is activated, incoming calls to the handset are indicated **without a ringtone** and are only shown on the display. The display and keypad are not illuminated and advisory tones are also turned off.

If you accept an incoming call, the room monitor is suspended for the duration of the call, but the function **remains** activated.

Using a handset as a room monitor

If you deactivate then reactivate the handset, the room monitor remains activated.

Caution!

- ◆ Always check the operation of the room monitor before use. For example, test its sensitivity. Check the connection if you are diverting the room monitor to an external number.
- ◆ Activating the function significantly reduces the operating time of your handset. Place the handset in the base/charger, if necessary. This ensures that the battery does not run down.
- ◆ Ideally the handset should be positioned 1 to 2 metres away from the baby. The microphone must be pointed towards the baby.
- ◆ The connection that the room monitor is diverted to must not be blocked by an activated answering machine.

Activating the room monitor and entering the destination number

☰ ▶ ★ ▶ Room Monitor

▶ You can enter data in the following fields:

Activation:

Select **On** to activate.

Alarm to:

Select **Internal** or **External**.

External number: select the number from the directory (press display key **[#]**) or enter it manually.

Internal number: press the display key **[Change]** ▶. Select the handset or **Call All** to call all registered handsets ▶ **[OK]**.


In idle status, the destination number or the internal destination number is displayed.

Sensitivity:

Select the noise level sensitivity (**Low** or **High**).

▶ Press **[Save]** to save the settings.

When the room monitor function is activated, the idle display looks like this:



Changing the destination number saved

☰ ▶ ★ ▶ Room Monitor

- ▶ Enter and save number as described in "Activating the room monitor and entering the destination number" (→ page 58).

Cancelling/deactivating the room monitor

Press the end call key **[End Call]** to cancel the call when the **room monitor is activated**.

In idle status, press the display key **[OFF]** to deactivate room monitor mode.

Deactivating the room monitor remotely

Prerequisites: the phone must support tone dialling and the room monitor is set for an external destination number.

- ▶ Accept the call from the room monitor and press keys **[9]** **[#]**.

The room monitor function will deactivate after the call ends. There are no further room monitor calls.

To reactivate the room monitor function with the same phone number:

- ▶ Reactivate and save with **[Save]** (→ page 58).

Setting the handset

Your handset comes with default settings, but you can change the settings to suit your individual requirements.

Quick access to numbers and functions

You can assign a **number from the directory** to each of the **digit keys** [0+] and [2-ABC] to [WXYZ9].

The left and right **display keys** have a default **function**. You can change the assignment (→ page 59).

You can then dial the number or start the function by simply pressing a key.

Assigning digit keys (quick dial)

Prerequisite: you have not yet assigned a number to the digit key.

- ▶ Press and **hold** the digit key
Or
Press the digit key **briefly** and press the display key **QuickDial**.

The directory opens.

- ▶ Select an entry and press **OK**.

The entry is saved to the corresponding digit key.

Please note

If you delete or edit the entry in the directory at a later date, this will not affect the assignment to the number key.

Selecting numbers/changing an assignment

Prerequisite: the digit key already has a number assigned to it.

When the handset is in idle status

- ▶ Press and **hold** the digit key:
The number is dialled immediately.

Or

- ▶ **Briefly** press the digit key.
Press the display key with the number/name (abbreviated if necessary) to select the number **or**
Press the display key **Change** to change the assignment or to delete the assignment.

Changing display key assignments

- ▶ Press and **hold** the left or right the display key.

The list of possible key assignments is opened. You can select the following:

Room Monitor

Assign the menu for setting and activating the room monitor to a key (→ page 57).

Alarm Clock

Assign a menu for setting and activating the alarm clock to a key (→ page 54).

Redial

Display the redial list.

More Functions...

More features are available:

Send Connection

Still no send MSN assigned:

Press the button to open the menu for assigning send MSNs (→ page 64).

Send MSN already assigned:

Assign the assigned send MSN to the display key.

Line Selection

Assign the list of selected MSNs to a key.

Select the send MSN for the next call from the list.

Call Lists

Display call lists (→ page 43).

Withhold Number

Restrict Calling Line Identification for the next call (→ page 38).

Call Divert


Assign the menu for setting and activating/deactivating call divert to a key (→ page 66).


- ▶ Select an entry and press **OK**.

Changing the display language

You can view the display texts in different languages.

 ▶  ▶ **Language**


The current language is indicated by .

 Select language and press **Select**.

If you accidentally choose a language you do not understand, in idle status:

 ▶  

Press the keys in sequence.


 Select the correct language and press the **right display key**.

Setting the display

Setting the screensaver

You can select a picture or the time to be displayed as a screensaver when the handset is in idle status. This replaces the idle status display. It may conceal the date, time and name.

The screensaver is not displayed in certain situations e.g., during a call or if the handset is de-registered.

If a screensaver is activated, the **Screensaver** menu option is marked with .

 ▶  ▶ **Display ▶ Screensaver**

The current setting is displayed.

▶ You can enter data in the following fields:


Activation:

Select **On** (screensaver is displayed) or **Off** (no screensaver).


Selection:

Select screensaver **or**

View Press the display key. The active screensaver is displayed.

 Select the screensaver and press **OK**.


Save Press the display key.

If the screensaver conceals the display, **briefly** press  to show the idle display.

Setting large font

You can increase the font size of the print and symbols in call lists and the directory to improve readability. Only one entry is shown at a time on the display, instead of several entries, and names are abbreviated if necessary.

 ▶  ▶ **Display ▶ Large Font**

Change Press the display key ( = on).

Setting the colour schemes

You can set the display to show a dark or a light background.

 ▶  ▶ **Display ▶ Colour Schemes**

Select **Colour Scheme 1** or **Colour Scheme 2** and press **Select**.

Setting the display backlight

Depending on whether or not the handset is in the base/charger, you can activate or deactivate the backlight. If it is activated, the display is permanently dimmed. If the display backlight is deactivated, you can reactivate it by pressing any key. The key has no further function in this situation.

 ▶  ▶ **Display ▶ Backlight**

The current setting is displayed.

▶ You can enter data in the following fields:

In Charger

Select **On** or **Off**.

Out of Charger


Select **On** or **Off**.

Please note


The **On** setting can significantly reduce the standby time of the handset.

Save Press the display key.

Activating/deactivating auto answer

If you activate this function, when you receive a call you can simply lift the handset out of the base/charger without having to press the talk key .

  **Telephony**  **Auto Answer**


Change Press the display key ( = on).


Changing the speaker/earpiece volume


You can set the volume for speaker mode and earpiece mode to five different levels.

In idle status:

 Open menu **Handset Volume**.


 Set the earpiece volume.

 Scroll to the line **Speaker**.

 Set the speaker volume.


Save Press the display key if necessary to save the setting permanently.

Setting the volume during a call:

 Press the control key.

 Select the volume.

The setting will automatically be saved after approximately 3 seconds or press the display key **Save**.

If  is assigned to another function, e.g., call swap (→ page 32):

Options Open the menu.

Volume Select and press **OK**.



Configure the setting (see above).

Please note

You can also set the call volume using the menu (→ page 31).

Changing ringtones

◆ **Volume:**

You can choose between five volumes (1–5; e.g., volume 3 = ) and the "crescendo" ringtone (6; volume increases with each ring = .

◆ **Ringtones:**

You can select from a list of pre-loaded ringtones and melodies.

You can set different ringtones for the following functions:

◆ For internal calls


◆ For every receive MSN


Setting the volume/melody


During setup (→ page 63), each receive MSN is automatically assigned a ringer. You can change this assignment.



In idle status:

  **Audio Settings**

Ringtones(Handset)  **Volume/Melodies**

 Setting the volume/melody for internal calls and anniversaries.

 Scroll to the next line.

 Set the **volume** for external calls or  Select MSN and set a **melody** for each individual MSN.


Save Press the display key to save the setting.


Activating/deactivating the ringtone for unknown calls.

You can set your handset so that it doesn't ring for calls where Calling Line Identification has been withheld. The call will only be signalled on the display.

In idle status:

  **Audio Settings**


Ringtones(Handset)  **Anon. Calls Silent**


Press **Change** to activate or deactivate the function ( = on).

Activating/deactivating the ringtone


You can deactivate the ringtone on your handset before you answer a call or when the handset is in idle status; the ringtone can be deactivated permanently or just for the current call. The ringtone cannot be re-activated while an external call is in progress.

Deactivating the ringtone permanently

 Press and **hold** the star key.

The  icon appears in the display.

Reactivating the ringer


 Press and **hold** the star key.

Deactivating the ringer for the current call


Silence Press the display key.

Activating/deactivating the alert tone

You can activate an alert tone instead of the ringtone. When you receive a call, you will hear a **short tone** ("Beep") instead of the ringtone.

 Press and **hold** the star key and **within 3 seconds**:

Beep Press the display key. A call will now be signalled by **one** short alert tone.

 appears in the display.

Activating/deactivating advisory tones

Your handset uses advisory tones to tell you about different activities and statuses. The following advisory tones can be activated/deactivated independently of each other:

- ◆ **Key Tones:** Every key press is confirmed.
- ◆ **Acknowledge tones:**
 - **Confirmation tone** (ascending tone sequence): at the end of an entry/setting and when an SMS or a new entry arrives in the call list
 - **Error tone** (descending tone sequence): for incorrect entries
 - **Menu end tone:** when you scroll to the end of a menu
- ◆ **Battery:** The battery requires charging.

In idle status:

 ▶  ▶ **Audio Settings**

▶ **Advisory Tones**

▶ You can enter data in the following fields:

Key Tones:

Select **On** or **Off**.

Confirmation:

Select **On** or **Off**.

Battery:

Select **On** or **Off**.

Save Press the display key.


Setting your own area code






Your area code (international and local area code) must be saved on the phone before you can transfer phone numbers (e.g., in vCards).

Some of these numbers are already preset.


  **Telephony**  **Area Codes**

Check that the (pre)set area code is correct.

 You can enter data in the following fields:

-  Select/change the input field.
-  Navigate in the input field.
-  Delete the number, if necessary: press the display key.
-  Enter the number.
-  Press the display key.

Example:

Area Codes	
International code:	00 - 49
Local area code:	0 - []
	Save


Restoring the handset default settings

You can reset any individual settings and changes that you have made.

The following settings are **not** affected by a reset

- ◆ Registering the handset to the base
- ◆ Date/time
- ◆ Directory entries, the call lists, the SMS lists

  **System**  **Handset Reset**

 Press the display key.

Creating ISDN settings

Please note:

- ◆ Some settings cannot be made simultaneously by multiple handsets. If this is the case, you will hear a negative acknowledge tone.
- ◆ The abbreviations in brackets after the titles indicate the ISDN feature concerned. Some features can only be used if they have been authorised by the network provider (there may be an extra charge).

Setting up/changing/deleting ISDN numbers (MSNs)

Your ISDN connection provides you with two telephone lines (B channels) that you can use simultaneously. You can set up a maximum of ten separate phone numbers (MSNs) on your phone. You are assigned these phone numbers by your network provider.

Please note

There are several ways of assigning an MSN to ISDN extension systems. For more information on this topic, refer to the user guide for your extension system.

If you have not yet stored all the numbers with the installation wizard (→ page 16), you can enter them now. You can start the ISDN wizard at any time via the menu to change the configuration.

All numbers that are stored retrospectively are automatically assigned to all registered handsets as receive MSNs.

Each new number you set up is automatically given its own ringtone melody, which you can change individually (→ page 61).

You can set up, edit and delete MSNs with the help of the ISDN wizard.

Creating ISDN settings

In idle status:

  **Telephony** ▶ **ISDN Wizard**


Yes Press the display key to launch the ISDN wizard.


OK Press the display key to confirm the info text.


A list of MSNs already set up is then displayed.


Change Press the display key to set up additional MSNs or modify the settings for an existing MSN.

Setting up a new MSN

 Select the **MSN - Name** line of an empty MSN entry.

 Enter the MSN name (max. 16 characters) (optional).

 Jump to the corresponding **MSN - Number** line.

 Enter the MSN (max. 20 digits; without area code = prefix).

- ▶ Repeat this process for other MSNs, if required.
- ▶ Press the display key **Save** to save the changes.

Once the ISDN wizard is finished, the connection wizard starts automatically. This enables you to assign send and receive connections to the internal parties.

Assigning send and receive MSNs to internal participants

If you have configured multiple MSNs for your telephone system, you can do the following for each internal participant


- ◆ Assign a send MSN to each internal party or allow them to select the connection for each external call (line selection).
- ◆ Assign one or more receive MSNs. Only calls received via the assigned MSNs are signalled on the device.


Assigning a send MSN

Prerequisite: multiple numbers have been configured.

  **Telephony** ▶ **Send Connection**

A list of internal participants is displayed.

 Select the internal participant to be assigned a new send MSN and press the **OK** display key.

 **Select at each call** or select an MSN as the send connection.

Save Press the display key to save the changes.


If you select **Select at each call**, the internal party can select which MSN is used to establish a connection every time they make a call.

Assigning receive MSNs

Prerequisite: multiple connections have been configured.


  **Telephony**
▶ **Receive Connections**

A list of internal participants is displayed.

 Select the internal participants that should be assigned new receive MSNs and press the display key **OK**.

A list containing all receive MSNs is opened.



 Select **Yes** or **No**.

 Switch to the next receive connection.

- ▶ Repeat these two steps for each MSN.
- ▶ Press the display key **Save** to save the changes.

Setting up a busy signal for when the MSN is being used (Busy on Busy)

This setting means callers hear a busy tone immediately when an external call is already being made on this MSN, regardless of the **Call Waiting** setting (→ page 65).

 ▶  ▶ **Busy on Busy**
▶ **Change** (☑ = on)

Activating/deactivating call waiting – CW

If the function is activated, you will hear a call waiting tone during an **external** call to signal that another external caller is trying to get through. If you have CLIP, the number of the waiting caller or the corresponding directory entry is shown in the display. The caller will hear the ringing tone.

When call waiting is deactivated, the caller will hear the busy tone if you are already making a call if you are the only party assigned to this connection .

Activating/deactivating call waiting

 ▶  ▶ **Call Waiting**

Status

Activate/deactivate call waiting and press **Save** .

Please note



Handling an external waiting call (→ page 34).

Anonymous calling – withholding caller ID (CLIR)

You can withhold your number (CLIR = Calling Line Identification Restriction). Your phone number will not be displayed when making outgoing calls; you are calling anonymously.

Prerequisite: the feature is supported by your network provider.

When this function is activated, the phone number is withheld for all calls from all registered handsets.

 ▶  ▶ **All Calls Anonymous**
▶ **Change** (☑ = on)

Please note

Withhold the number **for the next call only** (→ page 38).

Diverting calls

A distinction is made between

- ◆ Diverting calls **internally** and
- ◆ Diverting calls to an **external** phone connection.

Divert on an external connection – CF (Call Forwarding)

When you divert a call, the call is forwarded to another external connection. Your call divert settings can be specific to a particular connection (i.e., for every configured MSN).

 ▶  ▶ **Call Divert**

A list containing the configured and activated receive connections (MSNs) for your phone and **Internal** is displayed.

- ▶ Select the receive connection for which you want to activate or deactivate call divert, and press **OK**.
- ▶ You can enter data in the following fields:

Status

Activate/deactivate call divert.

Phone Number

Enter the number to which calls are to be diverted, and press **Save**. You can specify a different number for every MSN.

When

Select **All Calls / No Answer / When Busy**.

All Calls: Calls are diverted immediately i.e., calls for this MSN are no longer signalled on your phone.

No Answer: Calls are forwarded when no one accepts the call within several rings.

When Busy: Calls are forwarded when your line is busy.

Please note

Diverting calls to your phone numbers can incur additional costs. Please consult your provider.

Internal call divert

You can divert all external calls to a handset.

 ▶  ▶ **Call Divert ▶ Internal**

- ▶ You can enter data in the following fields:

Activation

Activate/deactivate call divert.

To Handset

Select the internal party.

Ring Delay


If you prefer to have a delay before the call is diverted, select the length of the delay (**None, 10 sec., 20 sec. or 30 sec.**).

Save

Press the display key.

Internal call divert is single-stage only, i.e., if the calls are diverted to a handset that also has call divert activated, this call divert is not activated.

Activating/deactivating call transfer – ECT (Explicit Call Transfer)

During call swapping you can connect two external callers (→ page 32) to each other by pressing the end call key . Transferring the call by replacing the receiver is not supported by all ISDN exchanges and PABXs.

 ▶  ▶ **Transfer (ECT)**

- ▶ **Change** = on

Setting the base

You set the base with a registered Gigaset C59H handset.

Activating/deactivating music on hold

  ▶ **Audio Settings**
▶ **Music on hold**

Press **Change** to activate or deactivate the music on hold (= on).

Activating repeater support

You can increase the range and signal strength of the base using a repeater. You will need to activate repeater mode. This will terminate any calls that are in progress at the time.

Prerequisite: a repeater is registered.

  ▶ **System** ▶ **Repeater Mode**

Press **Change** to activate or deactivate repeater mode (= on).

Please note

- ◆ **Eco Mode / Eco Mode+** (→ page 53) and repeater support cancel each other out, i.e., if you use a repeater, you cannot use **Eco Mode** and **Eco Mode+**.
- ◆ The encrypted transmission activated at the factory is deactivated when a repeater is registered.

Protecting against unauthorised access

Protect the system settings of the base station with a system PIN that only you know. You must enter the system PIN when you register/de-register a handset to/from the base, for example, or when you restore the default settings.

Changing the system PIN

You can change the 4-digit system PIN set on the base (default setting: **0000**) to a 4-digit PIN that only you know.

  ▶ **System** ▶ **System PIN**



Enter the current system PIN and press **OK**.



Enter your new system PIN and press **OK**.

Resetting the system PIN

If you have forgotten your system PIN, you can reset the base to the original code **0000**:

Remove the power cable from the base. Press and hold the register/paging key on the base while you reconnect the power cable to the base. Hold the key down for at least 5 seconds.

The base has now been reset and the system PIN set to **0000**.

Please note

All handsets are de-registered and must be re-registered. All settings are reset to the default settings.

Resetting the base to the default settings

When the settings are reset:

- ◆ Date/time are retained
- ◆ Handsets are still registered
- ◆ **Eco Mode** and **Eco Mode+** are deactivated,
- ◆ The system PIN is not reset.

  ▶ **System** ▶ **Base Reset**



Enter the system PIN and press **OK**.

Yes

Press the display key.

Connecting the base to the PABX

The following settings are only necessary if your PABX requires them; see the PABX user guide.

Please note

There are several ways of assigning an MSN to ISDN extension systems. For more information on this topic, please refer to the user guide for your extension system.

You cannot send or receive SMS messages on PABXs that do not support Calling Line Identification.

Saving an access code (outside line code)

You may have to enter an access code for external calls in your PABX, e.g., "0".

 ▶  ▶ **Telephony** ▶ **Access Code**

▶ You can enter data in the following fields:

Access external line with:

Enter or change access code, max. 3 digits.

For:

Call Lists


The access code prefixes the numbers dialled from the SMS list, a call list

All Calls

The access code prefixes all numbers dialled.

Off

The access code is deactivated. It does not prefix any phone number.

 **Save** Press the display key.

Transferring a call -ECT (Explicit Call Transfer)

With some ISDN PABX systems, your two participants are not connected when you press the end call key during a call transfer (→ page 33). In this case you need to activate this function (→ page 66). To do this, please refer to the operating instructions of your PABX.


Centrex

If your Gigaset CX590 ISDN is part of a Centrex system, you can use the following features:

Calling Name Identification (CNI)

When you receive incoming calls from other Centrex subscribers, the caller's number and name are shown on the display.

Message Waiting Indication (MWI)

New calls in the call list are indicated on the display with icons (→ page 44). The  message key flashes.

Dialling options

The KEYPAD function allows you to control certain features by entering sequences of characters and digits.

The KEYPAD function must be activated when you connect your Gigaset to an ISDN PABX or exchange (e.g., Centrex) that is controlled using keypad protocol. The digits/characters 0–9, * and # are sent as keypad information elements. Please ask your service provider about the information and codes you can transmit.



Setting options

You can switch between the **Auto. Tone Dial**, **Auto. Keypad** and **Dial of * and #** settings.

Auto. Tone Dial

Once normal dialling has been activated, * and # are not transmitted during dialling and, if * and # are entered, you cannot switch to the keypad.

Auto. Keypad


Once * or # have been entered, this setting automatically switches signalling during dialling to the keypad. This automatic switchover is needed to give commands to the exchange or PABX.

Dial of * and

Once Dial of * and # has been activated, the * and # characters are transmitted during dialling as commands to the exchange or PABX.

Regardless of the setting options above, after dialling or during a call, the phone automatically switches to tone dialling (DTMF) e.g., for controlling an answering machine remotely.

 ▶  ▶ **Telephony** ▶ **Dialling Mode**

 Select setting and press **Select**, e.g., **Auto. Tone Dial** (● = on).

Activating/deactivating the keypad during a call

In addition to the permanent settings described above, you can also switch temporarily to the keypad.

The setting only applies to the current external call and is automatically deactivated after the call is ended.

Depending on whether **Auto. Keypad** is activated, you may need to activate or deactivate **Keypad** during the call.

Options Open menu.

Keypad Select and press **Change** (☑ = on).

Customer Service & Assistance

Do you have any questions? As a Gigaset customer, you can find help quickly in this User Manual and in the service section of our Gigaset online portal www.gigaset.com/service.

Please register your phone online right after purchase.

This enables us to provide you with even better service regarding questions or a warranty claim. In order to contact our customer service via email, please use the email contact form our Gigaset online portal after selecting your home country.

Our representatives are also available on the telephone hotlines for consultation.

Australia 1300 780 878
Austria 0043 1 311 3046
Bahrain 97 31 73 11 173
Belgium 078 15 66 79
Bosnia Herzegovina 033 276 649
Brazil 4003 3020
(grandes cidades e regiões metropolitanas -
Custo de uma ligação local)
..... 0800 888 3020
(demais localidades - Gratuito)
Bulgaria +359 2 9710666
(0.50 евро на минута от всички държави за
стационарни телефони. За обаждания от
мобилен телефон може да има други цени).
Canada 1-866 247-8758
China 0 21 400 670 6007 (RMB 0.11)
Croatia 01 2456 555 (0,23 Kn)
Czech Republic +420 23303 2727
Denmark +45 (0) 35 25 86 00
Finland 09 231 134 25
France +33 170 706 181
Coût d'un appel local depuis une ligne fixe
France Télécom.
Germany 01805 333 222
Der Anruf kostet Sie aus den deutschen Fest-
netzen 0,14 € pro Minute. Anrufe aus den deut-
schen Mobilfunknetzen kosten höchstens 0,42
€ pro Minute.
Greece 801-1000 500
(Χρέωση 0,0026 € το λεπτό για το σταθερό
δίκτυο της Ελλάδας. Για κλήσεις από κινητό
ίσως ισχύουν άλλες χρεώσεις)
Hong Kong 2763 0203
..... 2389 7285
Hungary 06 14 71 24 44 (27 Ft)
India Please refer to your
..... local warranty card
Indonesia (62-21) 5673813
..... (62-21) 888856000
Ireland 18 50 77 72 77
Italy 199.15.11.15
(€ cent 8,36 + IVA al minuto da telefono fisso
della rete Telecom Italia senza scatto alla ris-
posta mentre per le chiamate effettuate attra-

verso la rete di altri operatori fissi o mobili con-
sultate le tariffe del vostro operatore)
Jordan 00962 6 5625460/1/2
Kuwait +965 -22458737/22458738
Lebanon +9611240259/
..... +9611236110
Luxembourg +352 8002 3811
Malaysia +603-8076 9696
Malta +390 2360 46789 (0,10 €)
Mexico
..... 01800 999 4442738 (01800 999 GIGASET)
Netherlands 0900-3333102
(0,25 € per minuut (vast net). Voor oproepen uit
het mobiele netwerk kunnen andere prijzen
gelden.)
New Zealand 0800 780 878
Norway 22 70 84 00
(Oppstartskost 89 øre + 15 øre pr minutt fra
fasttelefon linje. For samtaler fra mobil vil det
gjelde egne priser.)
Oman +968 709281 Ext. 49/21/75
Poland 0 801 140 160
Portugal (351) 808 781 223
(custo de uma chamada local)
Romania +40 021 204 9130
Russia 8 (495) 2281312
Serbia 0800 222 111
Singapore 6735 9100
Slovak Republic 02 59 68 22 66 (4,428 sk)
Slovenija 0 14 74 63 36
South Africa +2711 46 13 181
Spain 902 103935
Sweden 08-750 99 11
Switzerland 0848 212 000
Taiwan 02 266 24343
Turkey 0216 459 98 59
Ukraine +380-44-451-71-72
United Arab Emirates +97144458255/
..... +97144458254
United Kingdom 0 84 53 67 08 12
USA 1-866 247-8758
Vietnam 1900 545 416



Please have your record of purchase ready when calling.

Replacement or repair services are not offered in countries where our product is not sold by authorised dealers.

Questions and answers

If you have any queries about using your telephone, visit our website at www.gigaset.com/service for assistance 24/7.

The table below contains a list of common problems and possible solutions.

<p>The display is blank.</p> <ol style="list-style-type: none"> The handset is not activated. <ul style="list-style-type: none"> Press and hold the end call key . The battery is empty. <ul style="list-style-type: none"> Charge the battery or replace it (→ page 10). 	<p>The handset does not ring.</p> <ol style="list-style-type: none"> The ringtone is deactivated. <ul style="list-style-type: none"> Activate the ringtone (→ page 62). Call divert set to "All Calls". <ul style="list-style-type: none"> Deactivate call divert (→ page 66). The phone only rings if the phone number has been transferred. <ul style="list-style-type: none"> Activate the ringer for unknown calls (→ page 61). MSN is not assigned to internal subscriber or is incorrect. <ul style="list-style-type: none"> Specify receive MSN (→ page 64).
<p>The display shows "Not possible".</p> <p>The ISDN jack may not be plugged in.</p> <ul style="list-style-type: none"> Plug in the ISDN jack. <p>The message appears when attempting to activate the Eco Mode+: A handset is registered to the base that does not support Eco Mode+.</p>	<p>The handset does not ring as set.</p> <p>The MSN is assigned a different ringer melody.</p> <ul style="list-style-type: none"> Assign a melody for MSN on the handset (→ page 61).
<p>Not all menu items are displayed.</p> <p>The menu view is restricted (standard mode).</p> <ul style="list-style-type: none"> Activate the expanded menu view (expert mode) (→ page 29). 	<p>The handset does not ring after setting up the ISDN phone number (MSN).</p> <p>The local area code has been saved with the MSN.</p> <ul style="list-style-type: none"> Save MSN without the local area code.
<p>"No Base" flashes on the display.</p> <ol style="list-style-type: none"> The handset is outside the range of the base. <ul style="list-style-type: none"> Move the handset closer to the base. <p>The base's range is reduced because Eco Mode is activated.</p> <ul style="list-style-type: none"> Deactivate Eco Mode (→ page 53) or move the handset closer to the base. The base is not activated. <ul style="list-style-type: none"> Check the base power adapter (→ page 9). 	<p>Some of the ISDN functions do not work as specified.</p> <p>The ISDN functions are not active.</p> <ul style="list-style-type: none"> Check with your network provider.
<p>"Please register handset" flashes on the display.</p> <p>The handset has not been registered with the base or has been de-registered.</p> <ul style="list-style-type: none"> Register the handset (→ page 54). 	<p>You cannot hear a ringtone/dialling tone from the fixed line network.</p> <p>The ISDN cable may be faulty.</p> <ul style="list-style-type: none"> Replace the ISDN cable.
	<p>Error tone sounds after system PIN prompt.</p> <p>You have entered the wrong system PIN.</p> <ul style="list-style-type: none"> Reset the system PIN to 0000 (→ page 67).
	<p>Forgotten system PIN.</p> <ul style="list-style-type: none"> Reset the system PIN to 0000 (→ page 67).
	<p>The other party cannot hear you.</p> <p>You have pressed the mute button . The handset is "muted".</p> <ul style="list-style-type: none"> Unmute the microphone (→ page 36).
	<p>The number of the caller is not displayed although CLIP has been set.</p> <p>Calling Line Identification is not enabled.</p> <ul style="list-style-type: none"> The caller should ask the network provider to enable Calling Line Identification (CLI).

You hear an error tone when keying an input

(a descending tone sequence).

Action has failed/invalid input.

- › Repeat the process.
Read the display and refer to the user guide if necessary.

You cannot listen to messages on the network mailbox.

Your PABX is set to pulse dialling.

- › Set your PABX to tone dialling.

Exclusion of liability

Some displays may contain pixels (picture elements) which remain activated or deactivated. As a pixel is made up of three sub-pixels (red, green, blue), it is possible that pixel colours may vary.

This is completely normal and does not indicate a fault.

Authorisation

This device is intended for the ISDN telephone connection in your network.

Country-specific requirements have been taken into consideration.

We, Gigaset Communications GmbH, declare that this device meets the essential requirements and other relevant regulations laid down in Directive 1999/5/EC.

A copy of the 1999/5/EC Declaration of Conformity is available at this Internet address:

www.gigaset.com/docs

CE 0682

Environment

Our environmental mission statement

We, Gigaset Communications GmbH, bear social responsibility and are actively committed to a better world. Our ideas, technologies and actions serve people, society and the environment. The aim of our global activity is to secure sustainable life resources for humanity. We are committed to a responsibility for our products that encompasses their entire life cycle. Evaluating the environmental impact of products, including their manufacture, procurement, distribution, utilisation, service and disposal, begins during product and process design.

Further information on environmentally friendly products and processes is available on the Internet at www.gigaset.com.

Environmental management system



Gigaset Communications GmbH is certified in accordance with the international standards EN 14001 and ISO 9001.

ISO 14001 (Environment): certified since September 2007 by TÜV SÜD Management Service GmbH.

ISO 9001 (Quality): certified since 17/02/1994 by TÜV SÜD Management Service GmbH.

Ecological energy consumption

The use of ECO DECT (→ page 53) saves energy and makes an active contribution towards protecting the environment.

Disposal

Batteries should not be disposed of in general household waste. Observe the local waste disposal regulations, details of which can be obtained from your local authority.

All electrical and electronic equipment must be disposed of separately from general household waste using the sites designated by local authorities.



If a product displays this symbol of a crossed-out rubbish bin, the product is subject to European Directive 2002/96/EC.

The appropriate disposal and separate collection of used equipment serve to prevent potential harm to the environment and to health. They are a precondition for the re-use and recycling of used electrical and electronic equipment.

For further information on disposing of your used equipment, please contact your local authority or your refuse collection service.

Appendix

Caring for your telephone

- ▶ Wipe the device with a **damp cloth** or an **antistatic cloth**. Do not use solvent or a microfibre cloth.

Never use a dry cloth as this can cause static.

Contact with liquid

If the device comes into contact with liquid:

1. **Unplug the power supply** and/or **remove the battery** from the handset **immediately**.
2. Allow the liquid to drain from the device.
3. Pat all parts dry. Place the device (handset with the battery compartment open and the keypad facing down) in a dry, warm place **for at least 72 hours** (not in a microwave, oven etc.).
4. **Do not switch on the device again until it is completely dry.**

When it has fully dried out, you will normally be able to use it again.

Specifications

Technology:

Nickel-metal-hydride (NiMH)

Size: AAA (Micro, HR03)

Voltage: 1.2 V

Capacity: 550 - 1000 mAh

The device is supplied with two approved batteries.

Handset operating times/charging times

This Gigaset can charge batteries up to a capacity of 1000 mAh. Using special high-performance batteries or batteries with high capacities is not recommended for cordless phones.

The operating time of your Gigaset depends on the capacity and age of the batteries and the way it is used. (All times are maximum possible times).

	Capacity (mAh) approx.			
	550	700	800	1000
Standby time (hours) *	160/ 48	185/ 56	210/ 64	260/ 79
Talktime (hours)	10	12	13	17
Operating time for 1.5 hours of calls per day (hours) **				
- Without Eco Mode+	85	100	115	140
- With Eco Mode+	50	60	70	85
Charging time in base (hours)	7.5	8.5	10	12
Charging time in charger (hours)	6.5	7.5	8.5	10.5

* Without/with display backlight
(With Eco Mode+, the standby time is reduced by approx. 50%)

** Without display backlight
(Setting the display backlight → page 60)

Due to the constant progression in battery development, the list of recommended batteries in the FAQ section of the Gigaset Customer Care pages is updated regularly:
www.gigaset.com/service

Base power consumption

In standby mode *	approx. 1.1 W
Base in standby mode **	approx. 0.7 W
During a call	approx. 0.8 W

* Charged handset in base

** Handset not in base

General specifications

DECT standard	Supported
GAP standard	Supported
No. of channels	60 duplex channels
Radio frequency range	1880 – 1900 MHz
Duplex method	Time division multiplexing, 10 ms frame length
Channel grid	1728 kHz
Bit rate	1152 kbit/s
Modulation	GFSK
Language code	32 kbit/s
Transmission power	10 mW, average power per channel
Range	up to 300 m outdoors, up to 50 m indoors
Base power supply	230 V ~/50 Hz
Ambient conditions for operation	+5°C to +45°C, 20% to 75% relative humidity

Writing and editing text

The following rules apply when writing a text message:

- ◆ Each key between [0+] and [WXYZ9] is assigned several letters and characters.
- ◆ Control the cursor with . Press and **hold** or to move the cursor **word by word**.
- ◆ Characters are inserted at the cursor position.
- ◆ Press the star key to display the table of special characters. Select the required character and press the display key **Insert** to insert the character at the cursor position.
- ◆ Press and **hold** [0+] to [WXYZ9] to enter digits.
- ◆ Press display key to delete the **character** to the left of the cursor. Press and **hold** to delete the **word** to the left of the cursor.
- ◆ The first letter of the name of directory entries is automatically capitalised, followed by lower case letters.

Writing an SMS/names

Press the relevant key several times to enter letters/characters.

If you press and **hold** a key, the corresponding digit is inserted.

Standard characters

	1x	2x	3x	4x	5x	6x	7x	8x	9x	10x
	¹⁾ 1	²⁾ 1								
	a	b	c	2	ä	á	à	â	ã	ç
	d	e	f	3	ë	é	è	ê		
	g	h	i	4	ï	í	ì	î		
	j	k	l	5						
	m	n	o	6	ö	ñ	ó	ò	ô	õ
	p	q	r	s	7	ß				
	t	u	v	8	ü	ú	ù	û		
	w	x	y	z	9	ÿ	ý	æ	ø	å
	.	,	?	!	0					

- 1) Space
- 2) Line break

Setting upper/lower case or digits

Press the hash key **briefly** to switch from "Abc" mode to "123", from "123" to "abc" and from "abc" to "Abc" (uppercase: first letter uppercase, all others lowercase). Press the hash key **before** entering the letter.

You can see in the display whether upper case, lower case or digits is selected.

Accessories

Gigaset handsets

Upgrade your Gigaset to a cordless PABX:

Gigaset S79H handset

- ◆ Illuminated graphic colour display (65k colours)
- ◆ Illuminated keypad
- ◆ Large font for call lists and directory
- ◆ Brilliant sound quality in speaker mode: 4 adjustable handsfree profiles
- ◆ Polyphonic ringer melodies
- ◆ Directory for approx. 500 entries
- ◆ Caller pictures, slideshow and screensaver (analogue and digital clock)
- ◆ PC interface, e.g., for managing directory entries, ringtones and screensavers
- ◆ Headset socket
- ◆ ECO-DECT
- ◆ Calendar with appointment scheduler
- ◆ Night mode with time-controlled ringtone deactivation
- ◆ No interruptions from anonymous calls
- ◆ Room monitor
- ◆ SMS with up to 640 characters

www.gigaset.com/gigaset79h



Gigaset C59H handset

- ◆ Illuminated graphic colour display (65k colours)
- ◆ Illuminated keypad
- ◆ Speaker
- ◆ Polyphonic ringer melodies
- ◆ Directory for approx. 150 entries
- ◆ SMS (prerequisite: CLIP available)
- ◆ Headset socket
- ◆ Room monitor

www.gigaset.com/gigasetc59h



Gigaset SL400 handset

- ◆ Genuine metal frame and keypad
- ◆ High-quality keypad illumination
- ◆ 1.8" TFT colour display
- ◆ Bluetooth® and mini USB
- ◆ Directory for up to 500 vCards
- ◆ Talk/standby time of up to 14 hours/230 hours
- ◆ Large font for call lists and directory
- ◆ Brilliant sound quality in speaker mode: 4 adjustable handsfree profiles
- ◆ Caller pictures, slideshow and screensaver (analogue and digital clock)
- ◆ Silent alert, download ringer melodies
- ◆ ECO-DECT
- ◆ Calendar with appointment scheduler
- ◆ Night mode with time-controlled ringtone deactivation
- ◆ No interruptions from anonymous calls
- ◆ Room monitor
- ◆ SMS with up to 640 characters

www.gigaset.com/gigaset400



Gigaset SL78H handset

- ◆ Illuminated graphic colour display (256k colours)
- ◆ Illuminated keypad
- ◆ Speaker
- ◆ Polyphonic ringer melodies
- ◆ Directory for approx. 500 entries
- ◆ Caller picture
- ◆ SMS (prerequisite: CLIP available)
- ◆ PC interface, e.g., for managing directory entries, ringtones and screensavers
- ◆ Room monitor

www.gigaset.com/gigaset78h



Mounting the base on the wall

Gigaset repeater

You can use the Gigaset repeater to increase the reception range between your Gigaset handset and the base.

www.gigaset.com/gigasetrepeater



Compatibility

You can find more information about the handset functions in connection with the individual Gigaset bases at:


www.gigaset.com/compatibility

All accessories and batteries are available from your phone retailer.



Use only original accessories. This will avoid possible health risks and personal injury, and also ensure that all the relevant regulations are complied with.

Mounting the base on the wall



Approx. 2.5 mm



Index

A

- Access code
 - for PABX..... 68
- Access protection 67
- Accessories 76
- Acknowledge tones 62
- Activating
 - advisory tones 62
 - call waiting 65
 - handset 26
 - keypad lock 26
 - ring delay 61
 - room monitor 58
 - withholding phone numbers..... 65
- Adapter plug
 - power saving 53
- Advisory tones 62
- Alarm clock 54
- Alert tone 62
- Anniversary 41
 - deactivating 42
 - missed 44
 - saving in directory 41
- Anonymous call off..... 61
- Answering machine list 44
- Area code
 - setting own area code 63
- Assigning number key..... 59
- Authorisation 72
- Automatic
 - ring delay 35, 61

B

- Base
 - changing 55
 - connecting 9
 - connecting to PABX 68
 - restoring default settings 67
 - setting 67
 - setting up 9
 - system PIN 67
- Battery
 - charging 2, 3, 12
 - display 2, 3
 - icon 2, 3
 - inserting 10
 - tone 62

- Best base 55
- Birthday, see Anniversary
- Busy on Busy 65

C

- Call
 - accepting 35
 - diverting 66
 - ending 35
 - external 35
 - internal 55
 - rejecting 35
 - transferring..... 33, 68
 - transferring (connecting) 56, 57
- Call duration..... 35
- Call lists 43
- Call swapping..... 32
- Call waiting
 - accepting 34
 - activating/deactivating..... 65
 - internal call..... 56
 - rejecting 34
- Caller ID detection (ISDN) 38
- Calling
 - anonymous 65
 - external 35
 - internal 55
- Calling Line Identification 35, 36
- Caring for your telephone..... 74
- CCBS 37
- CCNR 37
- Changing
 - destination number
 - (room monitor) 58
 - display language..... 13, 60
 - earpiece volume 61
 - internal number of handset..... 57
 - name of handset..... 57
 - ringtone 61
 - speaker volume..... 61
 - system PIN 67
- Changing the system PIN 67
- Character set 46, 47, 75
- Charge status indicator 2, 3
- CLI, CLIP..... 36
- Colour scheme..... 60
- Conference (internal) 56
- Confirmation tone 62
- Connecting
 - base to PABX 68

Index

Connecting headset	21
Consultation call	
internal/external	32
Consultation call (internal)	56
Control key	2, 23
Correcting incorrect entries	24
Customer Care	70
Customer Service & Assistance	70
CW	34, 65

D

Deactivating	
advisory tones	62
call waiting	65
handset	26
keypad lock	26
ring delay	61
room monitor	58
withholding phone numbers	65
Deactivating radiation	53
Delete key	24
Deleting	
characters	24
De-registering (handset)	55
Destination number	
(room monitor)	58

Dialling

using quick dial	41, 59
using the directory	40

Directory	39
copying number from text	41
managing entries	40
opening	23
order of entries	40
saving anniversary	41
saving entry	39
saving sender's (SMS) number	48
sending entry/list to handset	41
using to enter numbers	41

Display

backlight	60
changing display language	13, 60
colour scheme	60
directory memory	41
in idle status	15, 25
missed anniversaries	44
network mailbox message	52
number (CLI/CLIP)	35, 36
screensaver	60
setting	60

Display icons	3
Display keys	2, 24
assigning	59
Disposal	73
Diverting (calls)	66
Draft message list (SMS)	46

E

Earpiece mode	36
Earpiece volume	61
ECO DECT	53
Eco Mode	53
Eco Mode+	53
ECT	33, 68
activating/deactivating	66
E-mail address	46
copying from directory	41
End call key	2, 35
Ending	
call	35
Entry	
saving (network mailbox)	52
selecting from directory	40
Environment	73
Error tone	62
Expert mode	29, 71

F

Fast access	
network mailbox	52
Fax (SMS)	46

G

General troubleshooting	71
Group call	55

H

Handset

activating/deactivating	26
advisory tones	62
changing internal number	57
changing name	57
changing number	57
changing to best reception	55
changing to different base	55
colour scheme	60
contact with liquid	74
de-registering	54, 55
display backlight	60
display language	13, 60
earpiece volume	61

idle status	25
large font	60
list	23
muting	36
paging	55
registering	54
registering to different base	55
restoring to default settings	63
screensaver	60
searching for	55
setting	59
setting up	10
speaker volume	61
transferring a call	33, 56
using multiple	54
using room monitor	57
Handset operating time	
in room monitor mode	58
Hash key	2, 26
Headset socket	21
Hearing aids	7
Help	71
I	
Icon	
alarm clock	54
display	3
for new messages	44
keypad lock	26
new SMS	47
ringtone	62
Idle status	
returning to	25
Idle status (display)	15, 25
Incoming list (SMS)	47
Incorrect entries (correction)	24
Initiating a conference	33
Installation wizard	16
Internal	
conference	56
consultation	56
making calls	55
Internal call	55
call waiting	56
ISDN settings	63
ISDN wizard	16

K

Key 1 (fast access)	2
Keypad lock	26
Keys	
assigning function or number	59
control key	2, 23
delete key	24
display keys	2, 24
end call key	2, 35
fast access	2
hash key	2, 26
message key	2
mute key	2
on/off key	2
quick dial	41
recall key	2
speaker key	2
star key	2
talk key	2, 35

L

Language	
display	13, 60
Large font	60
Linking, see SMS	
List	
answering machine	44
call lists	43
handsets	23
missed calls	43
network mailbox	44
SMS draft message list	46
SMS incoming list	47
SMS list	44
Locating	
handset	55
Lock	
activating/deactivating keypad lock ..	26

Index

M

- Making calls
 - accepting a call 35
 - external 35
 - internal 55
 - multiple participants 32
- Manual redial 42
- Medical equipment 7
- Memory
 - directory 41
- Menu
 - end tone 62
 - opening 23
 - tree 29
 - using 25
- Menu view
 - expert mode 29, 71
 - standard mode 29, 71
- Message key
 - opening list 47
 - opening lists 44
- Messages
 - key 2
- Microphone 2
- Missed calls 43
- MSNs 16
- Music on hold 67
- Mute key 2
- Muting the handset 36

N

- Name
 - of handset 57
- Network mailbox 52
- Number
 - as destination for room monitor 58
 - copying from directory 41
 - copying from SMS 48
 - copying to directory 41
 - displaying caller's number
(CLIP) 35, 36
 - entering network mailbox number 52
 - entering with directory 41
 - saving in directory 39

O

- On/off key 2
- Order in directory 40
- Outside line code 68

P

- PABX
 - connecting base 68
 - saving access code 68
 - SMS 50
- Package contents 8
- Paging 55
- Paging button 2
- PIN change
 - system PIN 67
- Power adapter 7
- Power consumption 74
- Power saving adapter plug 53
- Protecting phone against access 67

Q

- Questions and answers 71
- Quick dial 39, 59

R

- Radiation
 - deactivating 53
 - reducing 53
- Range 9
- Recall key 2
- Receive MSN 16
- Receiving notifications via SMS 49
- Reception booster, see Repeater
- Redial 42
- Reducing energy consumption 53
- Reducing radiation 53
- Register key 2
- Registering (handset) 54
- Rejecting
 - call 35
- Reminder call 42
- Repeater 67
- Ring delay 61
- Ringback
 - accepting 37
 - activating 37
 - cancelling 37
 - checking 37
 - setting up when MSN busy 65
 - when busy/no reply 37
- Ringtone
 - changing 61
 - setting melody 61
 - setting volume 61
- Room monitor 57

- S**
- Saving (access code)..... 68
 - Screensaver..... 60
 - Searching directory 40
 - Send MSN 16
 - Sending
 - directory entry to handset 41
 - Sensitivity (room monitor) 58
 - Setting melody 61
 - Setting the date..... 14, 31
 - Setting the time..... 14, 31
 - Setting up
 - base9
 - handset 10
 - Setting up busy signal 65
 - Signal tone, see Advisory tones
 - SMS..... 45
 - active send 49
 - answering or forwarding 47
 - deleting..... 46, 47
 - draft message list 46
 - forwarding 47
 - incoming list..... 47
 - linked 45
 - notification via SMS 49
 - reading 46, 47
 - receiving 47
 - saving number..... 48
 - self help with error messages 51
 - sending as fax 46
 - sending to e-mail address 46
 - to PABXs 50
 - troubleshooting 51
 - vCard 48
 - writing 45, 75
 - SMS centre
 - changing number..... 49
 - setting 49
 - SMS list..... 44
 - Snooze mode..... 54
 - Sound, see Ringtone
 - Speaker 36
 - key2
 - Specifications..... 74
 - Standard mode 29, 71
 - Star key2
 - System settings 67
- T**
- Talk key 2, 35
 - Text message, see SMS
 - Troubleshooting (SMS) 51
- V**
- vCard (SMS)..... 48
 - Viewing network mailbox message 52
 - VIP group (directory entry)..... 39, 40
 - Volume
 - earpiece..... 61
 - handset speaker volume..... 61
 - ringtone 61
 - speaker 61
- W**
- Warning tone, see Advisory tones
 - Warranty 72
 - Withholding
 - phone number display 65
 - Withholding number 65
 - Withholding number display 65
 - Withholding phone number display 65
 - Withholding phone numbers 65
 - Writing (SMS) 45
 - Writing and editing text 75