



HONDA GX690 WORKSHOP MANUAL

How to use this manual

A Few Words About Safety

SERVICE INFORMATION

The service and repair information contained in this manual is intended for use by qualified, professional technicians. Attempting service or repairs without the proper training, tools, and equipment could cause injury to you and/or others. It could also damage this Honda product or create an unsafe condition.

This manual describes the proper methods and procedures for performing service, maintenance, and repairs. Some procedures require the use special tools. Any person who intends to use a replacement part, service procedure or a tool that is not recommended by Honda, must determine the risks to their personal safety and the safe operation of this product.

If you need to replace a part, use Honda Genuine parts with the correct part number or an equivalent part. We strongly recommend that you do not use replacement parts of inferior quality.

For Your Customer's Safety

Proper service and maintenance are essential to the customer's safety and the reliability of this product. Any error or oversight while servicing this product can result in faulty operation, damage to the product, or injury to others.

▲ WARNING

Improper service or repairs can create an unsafe condition that can cause your customer or others to be seriously hurt or killed.

Follow the procedures and precautions in this manual and other service materials carefully.

For Your Safety

Because this manual is intended for the professional service technician, we do not provide warnings about many basic shop safety practices (e.g., Hot parts-wear gloves). If you have not received shop safety training or do not feel confident about your knowledge of safe servicing practice, we recommend that you do not attempt to perform the procedures described in this manual.

Some of the most important general service safety precautions are given below. However, we cannot warn you of every conceivable hazard that can arise in performing service and repair procedures. Only you can decide whether or not you should perform a given task.

▲ WARNING

Failure to properly follow instructions and precautions can cause you to be seriously hurt or killed.

Follow the procedures and precautions in this manual carefully.

Important Safety Precautions

Make sure you have a clear understanding of all basic shop safety practices and that you are wearing appropriate clothing and using safety equipment. When performing any service task, be especially careful of the following:

- Read all of the instructions before you begin, and make sure you have the tools, the replacement or repair parts, and the skills required to perform the tasks safely and completely.
- Protect your eyes by using proper safety glasses, goggles, or face shields anytime you hammer, drill, grind, or work around pressurized air, pressurized liquids, springs or other stored-energy components. If there is any doubt, put on eye protection.
- Use other protective wear when necessary, for example gloves or safety shoes. Handling hot or sharp parts can cause severe burns or cuts. Before you grab something that looks like it can hurt you, stop and put on gloves.
- Protect yourself and others whenever you have engine-power equipment up in the air. Anytime you lift this product with a hoist, make sure that the hoist hook is securely attached to the product.

Make sure the engine is off before you begin any servicing procedures, unless the instruction tells you to do otherwise. This will help eliminate several potential hazards:

- Carbon monoxide poisoning from engine exhaust. Be sure there is adequate ventilation whenever you run the engine.
- Burns from hot parts. Let the engine and exhaust system cool before working in those areas.
- Injury from moving parts. If the instruction tells you to run the engine, be sure your hands, fingers and clothing are out of the way.

Gasoline vapors and hydrogen gasses from battery are explosive. To reduce the possibility of a fire or explosion, be careful when working around gasoline or batteries.

- Use only a nonflammable solvent, not gasoline, to clean parts.
 - Never store gasoline in an open container.
 - Keep all cigarettes, sparks, and flames away from the battery and all fuel-related parts.
-

CONTENTS

| | |
|----------------------------|-----------|
| SPECIFICATIONS | 1 |
| SERVICE INFORMATION | 2 |
| MAINTENANCE | 3 |
| TROUBLESHOOTING | 4 |
| COVER | 5 |
| FUEL SYSTEM | 6 |
| GOVERNOR SYSTEM | 7 |
| CHARGING SYSTEM | 8 |
| IGNITION SYSTEM | 9 |
| STARTING SYSTEM | 10 |
| OTHER ELECTRICAL | 11 |
| MUFFLER | 12 |
| LUBRICATION SYSTEM | 13 |
| CYLINDER | 14 |
| CRANKCASE | 15 |
| TECHNICAL FEATURES | 16 |
| WIRING DIAGRAMS | 17 |
| INDEX | |

How to use this manual

INTRODUCTION

This manual covers the service and repair procedures for Honda GX630/630R/660/660R/690/690R.

All information contained in this manual is based on the latest product information available at the time of printing. We reserve the right to make changes at anytime without notice.


No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, by any means, electronic, mechanical, photocopying, recording, or otherwise, without prior written permission of the publisher. This includes text, figures, and tables.

As you read this manual, you will find information that is preceded by a **NOTICE** symbol. The purpose of this message is to help prevent damage to this Honda product, other property, or the environment.

SAFETY MESSAGES

Your safety, and the safety of others, are very important. To help you make informed decisions, we have provided safety messages and other safety information throughout this manual. Of course, it is not practical or possible to warn you about all the hazards associated with servicing these products. You must use your own good judgement.

You will find important safety information in a variety of forms, including:

- Safety Labels – on the product.
- Safety Messages – preceded by a safety alert symbol  and one of three signal words, DANGER, WARNING, or CAUTION. These signal words mean:

 DANGER You WILL be KILLED or SERIOUSLY HURT if you don't follow instructions.

 WARNING You CAN be KILLED or SERIOUSLY HURT if you don't follow instructions.

 CAUTION You CAN be HURT if you don't follow instructions.

- Instructions – how to service these products correctly and safely.

ALL INFORMATION, ILLUSTRATIONS, DIRECTIONS AND SPECIFICATIONS INCLUDED IN THIS PUBLICATION ARE BASED ON THE LATEST PRODUCT INFORMATION AVAILABLE AT THE TIME OF APPROVAL FOR PRINTING. Honda Motor Co., Ltd. RESERVES THE RIGHT TO MAKE CHANGES AT ANY TIME WITHOUT NOTICE AND WITHOUT INCURRING ANY OBLIGATION WHATSOEVER. NO PART OF THIS PUBLICATION MAY BE REPRODUCED WITHOUT WRITTEN PERMISSION. THIS MANUAL IS WRITTEN FOR PERSONS WHO HAVE ACQUIRED BASIC KNOWLEDGE OF MAINTENANCE ON Honda products.

© Honda Motor Co., Ltd.
SERVICE PUBLICATION OFFICE

Date of Issue: June 2009









SERVICE RULES

- Use genuine Honda or Honda-recommended parts and lubricants or their equivalents. Parts that do not meet Honda's design specifications may damage the unit.
- Use the special tools designed for the product.
- Install new gaskets, O-rings, etc. when reassembling.
- When torquing bolts or nuts, begin with larger-diameter or inner bolts first and tighten to the specified torque diagonally, unless a particular sequence is specified.
- Clean parts in cleaning solvent upon disassembly. Lubricate any sliding surfaces before reassembly.
- After reassembly, check all parts for proper installation and operation.
- Many screws used in this machine are self-tapping. Be aware that cross-threading or overtightening these screws will strip the threads and ruin the hole.

Use only metric tools when servicing this unit. Metric bolts, nuts and screws are not interchangeable with non-metric fasteners. The use of incorrect tools and fasteners will damage the unit.

SYMBOLS

The symbols used throughout this manual show specific service procedures. If supplementary information is required pertaining to these symbols, it would be explained specifically in the text without the use of the symbols.

| | |
|---|--|
|  | Replace the part(s) with new one(s) before assembly. |
|  | Use the recommend engine oil, unless otherwise specified. |
|  | Use molybdenum oil solution (mixture of the engine oil and molybdenum grease in a ratio of 1:1). |
|  | Use multi-purpose grease (lithium based multi-purpose grease NLGI #2 or equivalent). |
|  | Use water resistant molybdenum disulfide grease (containing more than 3% molybdenum disulfide, NLGI #2 or equivalent). Example: UNILITE M No.2 manufactured by KYODO YUSHI, Japan |
|  | Apply a locking agent. Use a medium strength locking agent unless otherwise specified. |
|  | Apply sealant. |
|  | Use automatic transmission fluid. |
| (O x O) (O) | Indicates the diameter, length, and quantity of metric bolts used. |
| page 1-1 | Indicates the reference page. |

How to use this manual

ABBREVIATIONS

Throughout this manual, the following abbreviations are used to identify the respective parts or systems

| Abbrev. term | Full term |
|--------------|---|
| ACG | Alternator |
| API | American Petroleum institute |
| Approx. | Approximately |
| Assy. | Assembly |
| ATDC | After Top Dead Center |
| ATF | Automatic Transmission Fluid |
| ATT | Attachment |
| BAT | Battery |
| BDC | Bottom Dead Center |
| BTDC | Before Top Dead Center |
| BARO | Barometric Pressure |
| CKP | Crankshaft Position |
| Comp. | Complete |
| CMP | Camshaft Position |
| CYL | Cylinder |
| DLC | Data Link Connector |
| EBT | Engine Block Temperature |
| ECT | Engine Coolant Temperature |
| ECM | Engine Control Module |
| EMT | Exhaust Manifold Temperature |
| EOP | Engine Oil Pressure |
| EX | Exhaust |
| F | Front or Forward |
| GND | Ground |
| HO2S | Heated Oxygen sensor |
| IAC | Idle Air Control |
| IAT | Intake Air Temperature |
| I.D. | Inside diameter |
| IG or IGN | Ignition |
| IN | Intake |
| INJ | Injection |
| L. | Left |
| MAP | Manifold Absolute Pressure |
| MIL | Malfunction Indicator Lamp |
| O.D. | Outside Diameter |
| OP | Optional Part |
| PGM-FI | Programmed-Fuel Injection |
| P/N | Part Number |
| Qty | Quantity |
| R. | Right |
| SAE | Society of Automotive Engineers |
| SCS | Service Check Signal |
| STD | Standard |
| SW | Switch |
| TDC | Top Dead Center |
| TP | Throttle Position |
| VTEC | Variable Valve Timing & Valve Lift Electronic Control |

| | | | | | | | |
|----|--------|---|-------|----|------------|----|-------------|
| BI | Black | G | Green | Br | Brown | Lg | Light green |
| Y | Yellow | R | Red | O | Orange | P | Pink |
| BU | Blue | W | White | Lb | Light blue | Gr | Gray |



1. SPECIFICATIONS

| | | | |
|--|-----|---|------|
| SERIAL NUMBER LOCATION | 1-2 | DIMENSIONAL DRAWINGS | 1-7 |
| DIMENSIONS AND WEIGHTS SPECIFICATIONS | 1-2 | PTO DIMENSIONAL DRAWINGS | 1-9 |
| ENGINE SPECIFICATIONS | 1-3 | ENGINE MOUNT DIMENSIONAL DRAWING | 1-11 |
| PERFORMANCE CURVES | 1-4 | | |




SPECIFICATIONS

SERIAL NUMBER LOCATION

The engine serial number (1) is stamped on the crankcase.

Refer to it when ordering parts or making technical inquiries.



DIMENSIONS AND WEIGHTS SPECIFICATIONS

| Model | GX630 | GX630R | GX660 | GX660R | GX690 | GX690R |
|------------------------------|-------|--------|--|--------|-------|--------|
| Overall length | | | Q type: 405 mm (15.9 in) V type: 426 mm (16.8 in) S type: 396 mm (15.6 in) T type: 429 mm (16.9 in) B type: 442 mm (17.4 in) DEN type: 371 mm (14.6 in) | | | |
| Overall width | | | 410 mm (16.1 in) | | | |
| Overall height | | | 438 mm (17.2 in) | | | |
| Dry weight | | | Q, S types: 44.4 kg (97.9 lbs) V, T types: 44.6 kg (98.3 lbs) B type: 45.0 kg (99.2 lbs) DEN type: 44.3 kg (97.7 lbs) | | | |
| Operating weight | | | Q, S types: 46.0 kg (101.4 lbs) V, T types: 46.2 kg (101.9 lbs) B type: 46.6 kg (102.7 lbs) DEN type: 45.9 kg (101.2 lbs) | | | |
| Maximum angle of inclination | | | Forward and backward: 20° Left and right: 20° | | | |

ENGINE SPECIFICATIONS


| Model | GX630 | GX630R | GX660 | GX660R | GX690 | GX690R |
|--|---|--------|--|--------|--|--------|
| Description code | GCBBK | GCBEK | GCBCK | GCBFK | GCBDK | GCBGK |
| Type | 4 stroke, overhead valve, 90° V-twin cylinder | | | | | |
| Displacement | 688.0 cm ³ (41.97 cu-in) | | | | | |
| Bore x stroke | 78.0 x 72.0 mm (3.07 x 2.83 in) | | | | | |
| Net power (SAE J1349)* | 15.5 kW (21.1 PS) / 3,600 min ⁻¹ (rpm) | | 16.0 kW (21.8 PS) / 3,600 min ⁻¹ (rpm) | | 16.5 kW (22.4 PS) / 3,600 min ⁻¹ (rpm) | |
| Continuous rated power | 12 kW (16.3 PS) / 3,600 min ⁻¹ (rpm) | | 12.5 kW (17.0 PS) / 3,600 min ⁻¹ (rpm) | | 13 kW (17.7 PS) / 3,600 min ⁻¹ (rpm) | |
| Maximum net torque (SAE J1349)* | 48.3 N·m (4.93 kgf·m, 35.6 lbf·ft) / 2,500 min ⁻¹ (rpm) | | 48.3 N·m (4.93 kgf·m, 35.6 lbf·ft) / 2,500 min ⁻¹ (rpm) | | 48.3 N·m (4.93 kgf·m, 35.6 lbf·ft) / 2,500 min ⁻¹ (rpm) | |
| Maximum rpm (at no load) | 3,850 ± 150 min-1 (rpm) | | | | | |
| Compression ratio | 9.3 ± 0.2 | | | | | |
| Fuel consumption (at continuous rated power) | 6.0 Liters (1.59 US gal, 1.32 Imp gal) / h | | 6.3 Liters (1.66 US gal, 1.39 Imp gal) / h | | 6.7 Liters (1.77 US gal, 1.47 Imp gal) / h | |
| Ignition system | C.D.I.(Capacitor Discharge Ignition) type magneto | | | | | |
| Ignition timing | B.T.D.C. 9° / 1,000 min-1 (rpm) | | | | | |
| Spark advancer type | Electronic type | | | | | |
| Spark advancer performance | B.T.D.C. 9° – 23° | | | | | |
| Spark plug | ZFR5F (NGK) | | | | | |
| Lubrication system | Forced feed | | | | | |
| Oil capacity | Without oil filter replacement: 1.5 Liters (1.59 US qt, 1.32 Imp qt) With oil filter replacement: 1.7 Liters (1.80 US qt, 1.50 Imp qt) | | | | | |
| Recommended oil | SAE 10W-30 API service classification SE or later | | | | | |
| Cooling system | Forced air | | | | | |
| Starting system | Starter motor | | | | | |
| Stopping system | Ignition primary circuit open | | | | | |
| Carburetor | 2 barrel horizontal type, butterfly valve | | | | | |
| Air cleaner | Dual type | | | | | |
| Governor | Mechanical centrifugal | | | | | |
| Breather system | Reed valve type, PCV (Positive Crankcase Ventilation) type | | | | | |
| Fuel used | Unleaded gasoline with a pump octane rating 86 or higher | | | | | |

*: The power rating of the engine indicated in this document is the net power output tested on a production engine for the engine model and measured in accordance with SAE J1349 at 3,600 rpm (net power) and at 2,500 rpm (max net torque). Mass production engines may vary from this value. Actual power output for the engine installed in the final machine will vary depending on numerous factors, including the operating speed of the engine in application, environmental conditions, maintenance, and other variables.


SPECIFICATIONS

PERFORMANCE CURVES

GX630/GX630R




GX660/GX660R







SPECIFICATIONS

GX690/GX690R



DIMENSIONAL DRAWINGS


Unit: mm (in)




SPECIFICATIONS

HIGH MOUNT MUFFLER TYPE

Unit: mm (in)




SIDE MOUNT MUFFLER TYPE




PTO DIMENSIONAL DRAWINGS

MOUNT PART

Unit: mm (in)



Q TYPE





MEMO





2. SERVICE INFORMATION

| | | | |
|--------------------------------|-----|-----------------------|------|
| MAINTENANCE STANDARDS | 2-2 | TOOLS | 2-6 |
| TORQUE VALUES | 2-4 | HARNESS ROUTING | 2-8 |
| LUBRICATION & SEAL POINT | 2-5 | TUBE ROUTING | 2-13 |



SERVICE INFORMATION

MAINTENANCE STANDARDS

Unit: mm (in)

| Part | Item | Standard | Service limit | |
|-----------------|---|--|---------------------------------|-------------------|
| Engine | Maximum speed (at no load) | GX630: 3,850 ± 150 min ⁻¹ (rpm) GX630R: 3,850 ± 150 min ⁻¹ (rpm) 3,150 ± 150 min ⁻¹ (rpm) (QYD, VEP4, VXF types only) 3,200 ± 150 min ⁻¹ (rpm) (VXD8, VXE1 types only) GX660: 3,850 ± 150 min ⁻¹ (rpm) GX660R: 3,850 ± 150 min ⁻¹ (rpm) 3,200 ± 150 min ⁻¹ (rpm) (VXE1 type only) GX690: 3,850 ± 150 min ⁻¹ (rpm) GX690R: 3,850 ± 150 min ⁻¹ (rpm) 3,200 ± 150 min ⁻¹ (rpm) (VXE type only) | — | |
| | Idle speed | 1,400 ± 150 min ⁻¹ (rpm) | — | |
| | Cylinder compression | 0.5 – 0.7 MPa (5.09 – 7.14 kgf/cm ² , 73 – 102 psi) / 500 min ⁻¹ (rpm) | — | |
| Cylinder | Sleeve I.D. | 78.000 – 78.015 (3.0709 – 3.0715) | 78.150 (3.0768) | |
| Piston | Skirt O.D. | 77.985 – 77.995 (3.0703 – 3.0707) | 77.850 (3.0650) | |
| | Piston-to-cylinder clearance | 0.005 – 0.030 (0.0002 – 0.0012) | 0.10 (0.004) | |
| | Piston pin bore I.D. | 18.002 – 18.008 (0.7087 – 0.7090) | 18.042 (0.7103) | |
| Piston pin | Pin O.D. | 17.994 – 18.000 (0.7084 – 0.7087) | 17.95 (0.707) | |
| | Piston pin-to-piston pin bore clearance | 0.002 – 0.014 (0.0001 – 0.0006) | 0.08 (0.003) | |
| Piston rings | Ring side clearance | Top | 0.050 – 0.080 (0.0020 – 0.0031) | 0.15 (0.006) |
| | | Second | 0.050 – 0.080 (0.0020 – 0.0031) | 0.15 (0.006) |
| | Ring end gap | Top | 0.200 – 0.350 (0.0079 – 0.0138) | 1.0 (0.04) |
| | | Second | 0.200 – 0.350 (0.0079 – 0.0138) | 1.0 (0.04) |
| | | Oil (side rail) | 0.20 – 0.70 (0.008 – 0.028) | 1.0 (0.04) |
| | Ring width | Top | 1.140 – 1.155 (0.0449 – 0.0455) | 1.120 (0.0441) |
| Second | | 1.140 – 1.155 (0.0449 – 0.0455) | 1.120 (0.0441) | |
| Connecting rod | Small end I.D. | 18.006 – 18.018 (0.7089 – 0.7094) | 18.07 (0.711) | |
| | Big end I.D. | 44.988 – 45.012 (1.7712 – 1.7721) | 45.050 (1.7736) | |
| | Big end oil clearance | 0.005 – 0.039 (0.0002 – 0.0015) | 0.070 (0.0028) | |
| | Big end side clearance | 0.2 – 0.4 (0.008 – 0.016) | 1.000 (0.0394) | |
| Crankshaft | Crank pin O.D. | 44.973 – 44.983 (1.7706 – 1.7710) | 44.920 (1.7685) | |
| | Main journal O.D. | 39.984 – 40.000 (1.5742 – 1.5748) | 39.930 (1.5720) | |
| | Thrust washer thickness | 0.95 – 1.05 (0.037 – 0.041) | 0.8 (0.03) | |
| Crankcase | Camshaft bearing I.D. | 17.016 – 17.027 (0.6699 – 0.6704) | 17.06 (0.672) | |
| | Main journal I.D. | 40.025 – 40.041 (1.5758 – 1.5764) | 40.06 (1.577) | |
| | Crankshaft axial clearance | 0.05 – 0.45 (0.002 – 0.018) | 1.0 (0.04) | |
| Crankcase cover | Camshaft bearing I.D. | 17.016 – 17.027 (0.6699 – 0.6704) | 17.06 (0.672) | |
| | Main journal I.D. | 40.025 – 40.041 (1.5758 – 1.5764) | 40.06 (1.577) | |

SERVICE INFORMATION

| Part | Item | Standard | Service limit | |
|-------------------------------|-------------------------------------|----------|--|--------------------|
| Valves | Valve clearance | IN | 0.08 ± 0.02 | — |
| | | EX | 0.10 ± 0.02 | — |
| | Valve stem O.D. | IN | 5.475 – 5.490 (0.2156 – 0.2161) | 5.400 (0.2126) |
| | | EX | 5.435 – 5.450 (0.2140 – 0.2146) | 5.300 (0.2087) |
| | Valve guide I.D. | IN/EX | 5.500 – 5.512 (0.2165 – 0.2170) | 5.560 (0.2189) |
| | Guide-to-stem clearance | IN | 0.010 – 0.037 (0.0004 – 0.0015) | 0.110 (0.0043) |
| | | EX | 0.050 – 0.077 (0.0020 – 0.0030) | 0.130 (0.0051) |
| | Valve seat width | | 1.0 – 1.2 (0.04 – 0.05) | 2.1 (0.08) |
| | Valve spring free length | | 38.3 (1.51) | 36.8 (1.45) |
| Valve spring perpendicularity | | 2° max. | — | |
| Camshaft | Cam height | IN | 29.506 – 29.706 (1.1617 – 1.1695) | 29.36 (1.156) |
| | | EX | 29.410 – 29.610 (1.1579 – 1.1657) | 29.26 (1.152) |
| | Camshaft O.D. | | 16.982 – 17.000 (0.6686 – 0.6693) | 17.100 (0.6732) |
| Valve lifter | Valve lifter I.D. | | 6.010 – 6.040 (0.2366 – 0.2378) | 6.070 (0.2390) |
| | Valve lifter shaft O.D. | | 5.970 – 6.000 (0.2350 – 0.2362) | 5.940 (0.2339) |
| Rocker arm | Rocker arm I.D. | | 6.000 – 6.018 (0.050 – 0.077) | 6.043 (0.2379) |
| | Rocker arm shaft O.D. | | 5.960 – 5.990 (0.2346 – 0.2358) | 5.953 (0.2344) |
| | Rocker arm shaft bearing I.D. | | 6.000 – 6.018 (0.050 – 0.077) | 6.043 (0.2379) |
| Oil pump | Oil pressure | | 2.8 kgf/cm ² (39.8 psi) / 2,000 min ⁻¹ (rpm) and more | — |
| | Tip clearance | | 0.15 (0.006) | 0.30 (0.012) |
| | Outer rotor-to-housing clearance | | 0.150 – 0.210 (0.0059 – 0.0083) | 0.30 (0.012) |
| | Outer rotor-to-pump cover clearance | | 0.04 – 0.09 (0.002 – 0.004) | 0.11 (0.004) |
| Carburetor | Main jet | | GX630/630R: #102 (No.1 cylinder) #105 (No.2 cylinder) GX660/660R: #112 (No.1 / No.2 cylinder) GX690/690R: #118 (No.1 / No.2 cylinder) | — |
| | Pilot screw opening | | GX630/630R: 2 turns out (No.1 cylinder) 1 - 7/8 turns out (No.2 cylinder) GX660/660R: 1 - 3/4 turns out (No.1 cylinder) 1 - 7/8 turns out (No.2 cylinder) GX690/690R: 1 - 7/8 turns out (No.1 cylinder) 1 - 3/4 turns out (No.2 cylinder) | — |
| | Float height | | 15.5 (0.61) | — |
| Spark plug | Gap | | 0.7 – 0.8 (0.028 – 0.031) | — |
| Ignition Coil | Air gap | | 0.2 – 0.6 (0.01 – 0.02) | — |
| Starter motor | Brush length | | 10 (0.4) | 6 (0.2) |
| | Mica depth | | — | 0.2 (0.01) |
| Charge coil | Resistance | 2.7A | 1.95 - 2.93 Ω | — |
| | | 17A | 0.18 - 0.28 Ω | — |
| | | 26A | 0.17 - 0.25 Ω | — |

SERVICE INFORMATION

TORQUE VALUES

ENGINE TORQUE VALUES

| Item | Tread Dia. (mm) | Torque values | | |
|-----------------------------|------------------------|---------------|-------|--------|
| | | N·m | kgf·m | lbf·ft |
| Cylinder nut | M10 x 1.25 | 37 | 3.8 | 27 |
| Oil drain plug bolt | M20 x 1.5 | 45 | 4.5 | 33 |
| Oil filter cartridge | M20 x 1.5 | 12 | 1.2 | 9 |
| Connecting rod bolt | M7 x 1.0 | 22 | 2.2 | 16 |
| Tappet adjusting nut | M5 x 0.5 | 7.5 | 0.75 | 5.5 |
| Governor arm nut | M6 x 1.0 | 11 | 1.1 | 8 |
| Flywheel nut | M20 x 1.5 | 235 | 24 | 173 |
| Fuel pump cover screw | M5 tapping screw | 4 | 0.4 | 3.0 |
| Fan cover protector screw | M4 special screw | 1.7 | 0.17 | 1.3 |
| Fan cover screw | M6 x 1.0 special screw | 4.4 | 0.45 | 3.2 |
| Fuel pump screw | M6 x 1.0 | 3 | 0.3 | 2.2 |
| Oil pressure switch | PT1/8 | 9 | 0.9 | 6.6 |
| Sealing bolt | PT1/8 | 9 | 0.9 | 6.6 |
| Air cleaner wing nut | M6 x 1.0 | 0.8 | 0.08 | 0.6 |
| Starter motor terminal nut | M8 x 1.25 | 9 | 0.9 | 6.6 |
| Breather valve screw | M3 x 0.5 | 1 | 0.1 | 0.7 |
| Hour meter screw | M3 tapping screw | 0.8 | 0.08 | 0.6 |
| Switch box bracket screw | M5 tapping screw | 4 | 0.4 | 3.0 |
| Combination switch nut | M22 x 1.0 | 4.9 | 0.5 | 3.6 |
| Fuel cut solenoid | - | 8.8 | 0.90 | 6.5 |
| Screen grid cover bolt | M6 x 1.0 | 8.5 | 0.85 | 6.3 |
| Screen grid cover nut | M6 x 1.0 | 8.5 | 0.85 | 6.3 |
| Screen grid cover stud bolt | M6 x 1.0 | 12 | 1.2 | 9 |
















STANDARD TORQUE VALUES

| Item | Tread Dia. (mm) | Torque values | | |
|-----------------------------|-----------------|---------------|-------|--------|
| | | N·m | kgf·m | lbf·ft |
| Screw | 4 mm | 2 | 0.2 | 1.5 |
| | 5 mm | 4 | 0.4 | 3.1 |
| | 6 mm | 9 | 0.9 | 6.6 |
| Bolt and nut | 4 mm | 3 | 0.4 | 2.5 |
| | 5 mm | 5 | 0.5 | 3.8 |
| | 6 mm | 10 | 1.0 | 7 |
| | 8 mm | 22 | 2.2 | 16 |
| | 10 mm | 34 | 3.5 | 25 |
| | 12 mm | 54 | 5.5 | 40 |
| Flange bolt and nut | 5 mm | 5 | 0.5 | 3.9 |
| | 6 mm | 12 | 1.2 | 9 |
| | 8 mm | 27 | 2.7 | 20 |
| | 10 mm | 39 | 4.0 | 29 |
| SH (Small head) flange bolt | 6 mm | 9 | 0.9 | 7 |

LUBRICATION & SEAL POINT

| Location | Material | Remarks | | |
|--|---|---------|-------------------------------------|--|
| Crankshaft pin, journal and gear | Engine oil | | | |
| Crankcase bearing | | | | |
| Crankcase cover bearing | | | | |
| Piston outer surface and piston pin hole | | | | |
| Piston pin outer surface | | | | |
| Piston ring | | | | |
| Cylinder inner surface | | | | |
| Connecting rod big and small end bearing | | | | |
| Connecting rod bolt threads and seating surface | | | | |
| Camshaft cam profile, bearing, decompressor and gear | | | | |
| Valve lifter shaft and slipper | | | | |
| Valve stem seal contact area of seal lip | | | | |
| Valve stem sliding surface and stem end | | | | |
| Valve spring | | | | |
| Push rod end | | | | |
| Rocker arm bearing and slipper | | | | |
| Tappet adjusting screw and nut threads and seating surface | | | | |
| Rocker arm shaft | | | | |
| Crankshaft thrust washer | | | | |
| Flywheel nut threads and seating surface | | | | |
| Oil pump gear outer surface, rotor and shaft | | | | |
| Governor weight holder gear and journal | | | | |
| Governor holder shaft | | | | |
| Governor slider | | | | |
| Governor arm shaft | | | | |
| Cylinder nut and bolt threads and seating surface | | | | |
| Oil seal outer surface | | | Multi-purpose grease | |
| Oil filter cartridge O-ring | | | | |
| Oil seal lip | | | | |
| O-ring | | | Liquid sealant (Threebond®1207B) | |
| Cylinder | | | | |
| Crankcase cover | | | | |
| Breather cover | Liquid sealant (Threebond®1207B, 1141G, 1215) | | | |
| Oil pressure switch | | | | |
| Sealing bolt | | | | |

SERVICE INFORMATION**TOOLS**


| | | |
|---|--|--|
| <p>Float level gauge 07401-0010000</p>  | <p>Oil pressure gauge attachment 07406-0030000</p>  | <p>Oil pressure gauge set 07506-3000000</p>  |
| <p>Tappet adjusting wrench 3 mm 07708-0030400</p>  | <p>Pilot 17 mm 07746-0040400</p>  | <p>Driver handle 15 x 135L 07749-0010000</p>  |
| <p>Seat cutter 27.5 mm 07780-0010200</p>  | <p>Seat cutter 33 mm 07780-0010800</p>  | <p>Flat cutter 30 mm 07780-0012200</p>  |
| <p>Flat cutter 33 mm 07780-0012900</p>  | <p>Interior cutter 30 mm 07780-0014000</p>  | <p>Interior cutter 26 mm 07780-0014500</p>  |
| <p>Cutter holder 5.5 mm 07981-VA20101</p>  | <p>Valve guide reamer 5.510 mm 07984-2000001</p>  | <p>Cleaning brush 07998-VA20100</p>  |

SERVICE INFORMATION


Oil seal driver attachment 60 mm
07GAD-PG40100




Oil filter wrench 64 mm
07HAA-PJ70100



Clutch center holder
07JMB-MN50301







Pilot screw wrench (D)
07KMA-MS60101






SERVICE INFORMATION

HARNESS ROUTING

FRONT VIEW




FRONT VIEW (AUTO THROTTLE TYPE)





SERVICE INFORMATION

TOP VIEW (AUTO THROTTLE TYPE)




SIDE VIEW (REMOTE CONTROL TYPE)




TUBE ROUTING

TOP VIEW




FRONT VIEW



SERVICE INFORMATION

RIGHT SIDE VIEW



3. MAINTENANCE

| | | | |
|----------------------------------|-----|---|------|
| MAINTENANCE SCHEDULE..... | 3-2 | SPARK PLUG REPLACEMENT..... | 3-7 |
| ENGINE OIL LEVEL CHECK..... | 3-3 | SPARK ARRESTER CLEANING..... | 3-7 |
| ENGINE OIL CHANGE..... | 3-4 | IDLE SPEED CHECK/ADJUSTMENT..... | 3-8 |
| OIL FILTER REPLACEMENT..... | 3-4 | VALVE CLEARANCE CHECK/ ADJUSTMENT..... | 3-8 |
| AIR CLEANER CHECK/CLEANING..... | 3-5 | COMBUSTION CHAMBER CLEANING..... | 3-10 |
| AIR CLEANER REPLACEMENT..... | 3-6 | FUEL FILTER REPLACEMENT..... | 3-10 |
| SPARK PLUG CHECK/ADJUSTMENT..... | 3-6 | FUEL TUBE CHECK..... | 3-11 |

MAINTENANCE

MAINTENANCE SCHEDULE

| REGULAR SERVICE PERIOD (2) | | Each use | First month or 20 hrs. | Every 6 months or 100 hrs. | Every year or 300 hrs. | Every 2 years or 500 hrs. | Refer to page |
|----------------------------|---|--------------|--------------------------------------|----------------------------|------------------------|---------------------------|---------------|
| ITEM | Perform at every indicated month or operating hour interval, whichever comes first. | | | | | | |
| · | Engine oil | Check level | ○ | | | | 3-3 |
| | | Change | | ○ | ○ | | |
| · | Engine oil filter | Replace | Every 200 hours | | | | 3-4 |
| · | Air cleaner | Check | ○ | | | | 3-5 |
| | | Clean | | | ○ (1) | | 3-5 |
| | | Replace | | | | ○* | 3-6 |
| · | Spark plug | Check-adjust | | ○ | | | 3-6 |
| | | Replace | | | | ○ | 3-7 |
| | Spark arrester (applicable types) | Clean | | ○ | | | 3-7 |
| · | Idle speed | Check-adjust | | | ○ | | 3-8 |
| · | Valve clearance | Check-adjust | | | ○ | | 3-8 |
| · | Combustion chamber | Clean | After every 1,000 hours | | | | 3-10 |
| · | Fuel filter | Replace | | | ○ | | 3-10 |
| · | Fuel tube | Check | Every 2 years (Replace if necessary) | | | | 3-11 |

· : Emission related items

*: Replace inner filter (paper) only.

(1) Service more frequently when used in dusty areas.

(2) For commercial use, log hours of operation to determine proper maintenance intervals.

ENGINE OIL LEVEL CHECK

Place the engine on a level surface.


Start the engine and allow it to warm up for 1 to 2 minutes.

Remove the oil level dipstick (1), and wipe it clean.

Insert the oil level dipstick into the oil level pipe (2).

Remove the oil level dipstick and check oil level shown on the tip of the level dipstick.

If the oil level is near or below the lower level mark (3) on the oil level dipstick, remove the oil filler cap (4) from the head cover and fill with recommended oil to the upper level mark (5) of the level dipstick.




Oil is a major factor affecting performance and service life. Use 4 - stroke automotive detergent oil.

SAE 10W - 30 or 5W - 30 is recommended for general use. Use a full synthetic 5W - 30 for starting/operating temperatures between 15°C and -5°C. Other viscosities shown in the chart may be used when the average temperature in your area is within the recommended range.

RECOMMENDED OIL:

SAE 10W-30 API service classification SE or later

Tighten the oil filler cap and install the oil level dipstick securely.



MAINTENANCE

ENGINE OIL CHANGE

Drain the oil in the engine while the engine is warm. Warm oil drains quickly and completely.

Place the engine on a level surface and place a suitable container under the drain plug bolt (1).

Remove the oil filler cap (2) from the head cover (3) and the drain plug bolt to drain the oil into a suitable container.

Please dispose of used motor oil in a manner that is compatible with the environment. We suggest you take used oil in a sealed container to your local recycling center or service station for reclamation. Do not throw it in the trash, pour it into the ground, or down a drain.

⚠ CAUTION

Used engine oil contains substances that have been identified as carcinogenic.

If repeatedly left in contact with the skin for prolonged periods, it may cause skin cancer.


Wash your hands thoroughly with soap and water as soon as possible after contact with used engine oil.

Install a new drain plug washer (4) and tighten the drain plug bolt to the specified torque.

TORQUE: 45 N·m (4.5 kgf·m, 33 lbf·ft)

Fill with recommended oil to the upper level mark of the oil level dipstick (page 3-3).

Tighten the oil filler cap and install the oil level dipstick securely.



OIL FILTER REPLACEMENT

Drain the engine oil.

Remove the oil filter (1) using the special tool (2).

TOOLS:

Oil filter wrench 64 mm (2) 07HAA-PJ70100

Apply a light coat of grease to the O-ring (3) of the new oil filter.


Install the new oil filter and tighten to the specified torque.

TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)

Fill with recommended oil to the upper level mark of the oil level dipstick (page 3-3).

Start the engine and warm up for 1 to 2 minutes.

Check the oil level and if necessary, fill the recommended oil to the upper mark of the oil level dipstick (page 3-3).



AIR CLEANER CHECK/CLEANING

A dirty air filter will restrict air flow to the carburetor, reducing engine performance. If the engine is operated in dusty areas, clean the air cleaner more often than specified in the MAINTENANCE SCHEDULE.

NOTICE


Operating the engine without the air filters or with the filter installed loosely will allow dirt to enter the engine, causing rapid engine wear. Install the air filters securely.

Remove the air cleaner cover (1).


Remove the wing nut (2) and air filter assembly (3)(4).

Separate the air filters into the inner filter (Paper) (3) and the outer filter (Foam) (4).

Carefully check both filters for holes or tears and replace if damaged.



Clean the outer filter (1) in warm soapy water (2), rinse and allow to dry thoroughly, or clean with a non-flammable solvent (2) and allow to dry thoroughly. Dip the filter in clean engine oil (3) and squeeze out all the excess oil. Excess oil will restrict air flow through the foam element and may cause the engine to smoke at startup.



Tap the inner filter (1) lightly several times on a hard surface to remove excess dirt or blow compressed air lightly (207 kPa (2.11 kgf/cm², 30 psi) or less) through the paper filter from the inside out. Never try to brush the dirt off; brushing will force dirt into the fibers.


Wipe dirt from the inside of the air cleaner case and the air cleaner cover, using a rag.

Check the air cleaner case packing for deterioration or damage. Make sure the air cleaner packing installed securely.

Attach the outer filter on the inner element, and then install the air filter assembly and tighten the wing nut securely.

TORQUE: 0.8 N·m (0.08 kgf·m, 0.6 lbf·ft)

Install the air cleaner cover.



MAINTENANCE

AIR CLEANER REPLACEMENT

Remove the air cleaner cover (page 3-5).

Remove the wing nut and air cleaner filters (page 3-5).

Wipe dirt from the inside of the air cleaner case and the air cleaner cover, using a rag.

Check the air cleaner case packing for deterioration or damage. Make sure the air cleaner packing installed securely.

Install a new air cleaner filters and tighten the wing nut securely.

TORQUE: 0.8 N·m (0.08 kgf·m, 0.6 lbf·ft)


Install the air cleaner cover.

SPARK PLUG CHECK/ADJUSTMENT

⚠ CAUTION

If the engine has been running, the engine will be very hot.
Allow it to cool before proceeding.

Remove the spark plug cap (1), and then remove the spark plug (2) using a spark plug wrench (3).




Visually check the spark plug. Replace the plug if the insulator (1) is cracked or chipped.

Remove carbon or other deposits with wire brush.

Check the sealing washer (2) for damage.

Replace the spark plug if the sealing washer is damaged (page 3-7).



Measure the plug gap with a wire-type feeler gauge. If the measurement is out of the specification, adjust by bending the side electrode.


PLUG GAP: 0.7 – 0.8 mm (0.028 – 0.031 in)

Install the spark plug finger-tight to seat the washer, and then tighten 1/8 – 1/4 turn with a spark plug wrench.

NOTICE

A loose spark plug can become very hot and can damage the engine. Overtightening can damage the threads in the cylinder block.

Install the spark plug cap securely.



SPARK PLUG REPLACEMENT

⚠ CAUTION

If the engine has been running, the engine will be very hot.
Allow it to cool before proceeding.

Remove the spark plug cap, and then remove the spark plug using a spark plug wrench (page 3-6).

Verify the new spark plug gap is correct (page 3-6).

Install a new spark plug finger-tight to seat the washer, and then tighten 1/2 turn with a spark plug wrench.

SPARK PLUG: ZFR5F (NGK)

NOTICE

A loose spark plug can become very hot and can damage the engine. Overtightening can damage the threads in the cylinder block.

Install the spark plug cap securely.

SPARK ARRESTER CLEANING


⚠ CAUTION

The muffler becomes very hot during operation and remains hot for a while after stopping the engine. Be careful not to touch the muffler while it is hot. Allow it to cool before proceeding.


Remove the flange bolts (1) and muffler protector (2) (side mount type only).

Remove the tapping screw/s (3) and spark arrester (4).

HIGH MOUNT TYPE:



SIDE MOUNT TYPE:




MAINTENANCE

Clean the carbon deposits from the spark arrester screen (1) with a wire brush.

Check the spark arrester screen for damage. If the screen is damaged, replace the spark arrester.

Reinstall the spark arrester to the muffler.

Install the muffler protector (side mount type only).




IDLE SPEED CHECK/ADJUSTMENT

Start the engine and allow it to warm up to normal operating temperature.

Turn the pan screw (1) of the control to obtain the specified idle speed.

IDLE SPEED: $1,400 \pm 150 \text{ min}^{-1}$ (rpm)




VALVE CLEARANCE CHECK/ADJUSTMENT

Remove the four flange bolts (1) and the each valve cover (2).


Remove the fan cover protector or screen grid (page 5-2).

Disconnect the spark plug caps (3) from the spark plugs.




Set the piston of the No.1 cylinder at the top dead center of the cylinder compression stroke (both valves fully closed) by rotating the flywheel (1) clockwise slowly. When the No.1 piston is at the top dead center of the compression stroke, the "T" mark (2) on the cooling fan will align with the right side alignment mark (3) on the fan cover.

If the exhaust valve is opened, rotate the flywheel and align the "T" mark on the cooling fan with the alignment mark on the fan cover again.



Insert a thickness gauge between the valve rocker arm (1) and valve stem (2) to measure the valve clearance.

VALVE CLEARANCE:
IN: 0.08 ± 0.02 mm
EX: 0.10 ± 0.02 mm



Set the piston of the No.2 cylinder at the top dead center of the cylinder compression stroke (both valves fully closed) by rotating the flywheel (1) 270 degrees clockwise slowly. When the No.2 piston is at the top dead center of the compression stroke, the "T" mark (2) on the cooling fan will align with the left side alignment mark (3) on the fan cover.

Insert a thickness gauge between the valve rocker arm and valve stem to measure the valve clearance.

VALVE CLEARANCE:
IN: 0.08 ± 0.02 mm
EX: 0.10 ± 0.02 mm

If adjustment is necessary, proceed as follows.

Hold the tappet adjusting screw (1) and loosen the tappet adjusting nut (2).

TOOL:

Tappet adjusting wrench 3 mm (3) 07708-0030400

Turn the tappet adjusting screw to obtain the specified clearance.

VALVE CLEARANCE:
IN: 0.08 ± 0.02 mm
EX: 0.10 ± 0.02 mm



Hold the tappet adjusting screw and retighten the tappet adjusting nut to the specified torque.

TORQUE: 7.5 N·m (0.75 kgf·m, 5.5 lbf·ft)


Recheck the valve clearance, and if necessary, readjust the clearance.

Check the valve cover packing for damage or deterioration and install it on the valve cover.

Attach the cylinder valve cover to the cylinder and tighten the flange bolts securely.



(1)
 To decrease valve clearance: screw in.
 To increase valve clearance: screw out.



MAINTENANCE

COMBUSTION CHAMBER CLEANING

Remove the cylinder (page 14-2).

Prepare a cylinder of a thick paper or equivalent material (1), which diameter is as large as to fit against the inner wall of the cylinder, and insert the paper into the cylinder.

Attach the cleaning brush (special tool) (2) to an electric drill and clean any carbon deposits from the combustion chamber.


TOOL:

Cleaning brush (2)

07998-VA20100

NOTICE

- Do not remove valves from the cylinder while cleaning the combustion chamber.
- Be sure to insert a thick paper into the cylinder to protect the inner wall of the cylinder during clearing of the combustion chamber.
- Do not press the cleaning brush with force against the combustion chamber.




FUEL FILTER REPLACEMENT

⚠ WARNING

Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Keep heat, sparks and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.

Check the fuel filter (1) for water accumulation or sediment. If necessary replace it.




Install the commercially available tube clamps (1) on the fuel tubes (2) on both sides of the fuel filter (3).

Disconnect the fuel tube from the fuel filter to remove the fuel filter.

Install a new fuel filter with the arrow mark toward the carburetor side.

Check the connecting parts for any sign of fuel leakage.



FUEL TUBE CHECK

⚠ WARNING


Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Keep heat, sparks and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.

Remove the air cleaner case (page 6-3).

Check the fuel tube (1) for deterioration, cracks or signs of leakage. If necessary replace it.

Install the air cleaner case (page 6-3).





MEMO





4. TROUBLESHOOTING

BEFORE TROUBLESHOOTING..... 4-2 **TRUBLESHOOTING**4-2




TROUBLESHOOTING

BEFORE TROUBLESHOOTING


- Use a known-good battery for troubleshooting.
- Check that the connectors are connected securely.
- Check the sufficient fresh fuel in the fuel tank.
- Read the circuit tester's operation instructions carefully, and observe the instructions during inspection.
- Disconnect the battery cable before continuity inspection.

TROUBLESHOOTING

GENERAL SYMPTOMS AND POSSIBLE CAUSES




HARD STARTING



TROUBLESHOOTING

ENGINE DOES NOT STOP WHEN COMBINATION SWITCH IS TURNED OFF





5. COVER

FAN COVER REMOVAL/INSTALLATION..... 5-2


LOWER SHROUD REMOVAL/
INSTALLATION.....5-5




COVER

FAN COVER REMOVAL/INSTALLATION

FAN COVER PROTECTOR TYPE




SCREEN GRID/SCREEN GRID COVER TYPE



COVER

FRONT PTO/SCREEN GRID TYPE



LOWER SHROUD REMOVAL/ INSTALLATION



Remove the fan cover (page 5-2).

L. LOWER SHROUD

HIGH TENSION CORD GROMMET

INSTALLATION:

Align the grommet (1) with the cutout in the L. lower shroud (2) as shown.





R. LOWER SHROUD

HIGH TENSION CORD GROMMET

INSTALLATION:

Clamp the high tension cord (1) to the inside of the R. lower shroud (2) and align the grommet (3) with the cutout in the shroud as shown.





MEMO




6. FUEL SYSTEM

| | | | |
|--|------------|--|------------|
| SYSTEM DIAGRAM | 6-2 | CARBURETOR DISASSEMBLY/ ASSEMBLY | 6-6 |
| FUEL SYSTEM TROUBLESHOOTING | 6-2 | PILOT SCREW REMOVAL/ INSTALLATION | 6-7 |
| AIR CLEANER REMOVAL/ INSTALLATION | 6-3 | CARBURETOR BODY CLEANING | 6-7 |
| FUEL PUMP REMOVAL/INSTALLATION | 6-4 | CARBURETOR INSPECTION | 6-8 |
| CARBURETOR REMOVAL/ INSTALLATION | 6-5 | | |


FUEL SYSTEM

SYSTEM DIAGRAM




FUEL SYSTEM TROUBLESHOOTING

FUEL DOES NOT REACH CARBURETOR



AIR CLEANER REMOVAL/ INSTALLATION




FUEL SYSTEM

FUEL PUMP REMOVAL/INSTALLATION

⚠ WARNING

Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Keep heat, sparks and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.



CARBURETOR REMOVAL/ INSTALLATION

⚠ WARNING

Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Keep heat, sparks and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.

Remove the air cleaner (page 6-3).



Attach a commercially available tube clamp to the fuel tube.

Disconnect the fuel tube from the carburetor.


Loosen the carburetor drain screw and drain the float chamber completely.

FUEL TUBE GROMMET STAY

INSTALLATION:
Install the fuel tube grommet stay (1) in contact with each projection (2) of stay and inlet manifold (3).



REMOVAL:
Unhook the throttle return spring (1) from the carburetor throttle linkage (2). Then push off the carburetor throttle linkage to unsnap from the governor rod (3). Disconnect the governor rod from the throttle linkage.



FUEL SYSTEM

CARBURETOR DISASSEMBLY/ ASSEMBLY

⚠ WARNING

Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Keep heat, sparks and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.

⚠ CAUTION


To prevent serious eye injury, always wear safety goggles or other eye protection when using compressed air.

Before disassembly, clean the outside of the carburetor.

PILOT JET

ASSEMBLY:



- Before installing, clean thoroughly with low compressed air (207 kPa (2.11 kgf/cm², 30 psi) or less).
- Lightly lubricate the O-ring (1) to ensure easy installation into the carburetor body.



STOP SCREW


ASSEMBLY:

Set the float (1) and float pin (2) to the carburetor body (3). Tighten the stop screw (4) to secure the float pin as shown.



MAIN NOZZLE

ASSEMBLY:
Before installing, clean thoroughly with low compressed air (207 kPa (2.11 kgf/cm², 30 psi) or less).



MAIN JET

ASSEMBLY:
Before installing, clean thoroughly with low compressed air (207 kPa (2.11 kgf/cm², 30 psi) or less).

MAIN JET NUMBER:
GX630/GX630R:
L side (No.1 CYLINDER) #102
R side (No.2 CYLINDER) #105
GX660/GX660R: #112
GX690/GX690R: #118

MAIN JET NUMBER



PILOT SCREW REMOVAL/ INSTALLATION

Remove/install the pilot screw (1) using the special tool (2).

TOOL:
PILOT SCREW WRENCH (D) (2) 07KMA-MS60101

PILOT SCREW OPENING:
GX630/GX630R:

L side (No.1 cylinder): 2 turns out

R side (No.2 cylinder): 1 - 7/8 turns out

GX660/GX660R:


L side (No.1 cylinder): 1 - 3/4 turns out

R side (No.2 cylinder): 1 - 7/8 turns out

GX690/GX690R:

L side (No.1 cylinder): 1 - 7/8 turns out

R side (No.2 cylinder): 1 - 3/4 turns out



CARBURETOR BODY CLEANING

CAUTION

To prevent serious eye injury, always wear safety goggles or other eye protection when using compressed air.


NOTICE

- Some commercially available chemical cleaners are very caustic. These cleaners may damage plastic or parts such as the O-ring, the float and the float seat of the carburetor. Check the container for instructions. If you are in doubt, do not use these products to clean a Honda carburetor.
- High air pressure may damage the carburetor body. Use low air pressure (207 kPa (2.11 kgf/cm², 30 psi) or less) when cleaning passages and ports.

Clean the carburetor body with non-flammable solvent.

Clean thoroughly the following passages and ports with low compressed air.

- Pilot jet hole (1)
- Main air jet (2)
- Main nozzle holder (3)
- Pilot air jet (4)
- Bypass ports (5)
- Pilot outlet ports (6)
- Internal vent port (7)



FUEL SYSTEM

CARBURETOR INSPECTION

FLOAT LEVEL HEIGHT


Place the carburetor (1) in the position as shown and measure the distance between the float (2) top and carburetor body when the float just contacts the seat without compressing the valve spring.

TOOL:

Float level gauge (3) 07401-0010000

FLOAT HEIGHT: 15.5 mm (0.61 in)

If the measured float height is out of specification, check the float valve and the float valve spring (see below). If the float valve and the float valve spring are normal, replace the float.




FLOAT VALVE

Check a worn float valve (1).

Check the float valve and valve seat (2) for contamination.

Check for wear or a weak spring (3).

After installation, check the operation of float valve.




FUEL CUT SOLENOID

Remove the fan cover (page 5-2).

Disconnect the wire harness (1) from the fuel cut solenoid (2).

Apply 12V battery voltage between the terminal of the fuel cut solenoid (3) and engine ground and check the solenoid operating noise.

If the fuel cut solenoid does not operate, replace the fuel cut solenoid (page 6-6).




7. GOVERNOR SYSTEM

| | | | |
|---|------------|---|-------------|
| GOVERNOR ARM/CONTROL REMOVAL/ INSTALLATION | 7-2 | AUTO THROTTLE SOLENOID/GOVERNOR ARM INSTALLATION | 7-6 |
| MAXIMUM SPEED ADJUSTMENT | 7-3 | CONTROL BOX REMOVAL/ INSTALLATION | 7-8 |
| GOVERNOR ARM INSTALLATION (Without auto throttle type) | 7-3 | THROTTLE CABLE INSTALLATION | 7-9 |
| GOVERNOR SPRING INSTALLATION | 7-4 | CHOKE CABLE INSTALLATION | 7-9 |
| AUTO THROTTLE SOLENOID REMOVAL ... | 7-5 | CONTROL BOX DISASSEMBLY/ ASSEMBLY | 7-10 |

GOVERNOR SYSTEM

GOVERNOR ARM/CONTROL REMOVAL/INSTALLATION

Remove the air cleaner (page 6-3).




MAXIMUM SPEED ADJUSTMENT

Start the engine and allow it to warm up to normal operating temperature.

Turn the pan screw (1) of the control to obtain the specified maximum speed.

MAXIMUM SPEED: $3,850 \pm 150 \text{ min}^{-1}$ (rpm)
 $3,150 \pm 150 \text{ min}^{-1}$ (rpm)
 (GX630R QYD, VEP4, GX660R VXF types only)
 $3,200 \pm 150 \text{ min}^{-1}$ (rpm)
 (GX630R VXD8, VXE1, GX660R VXE1, GX690R VXE types only)



GOVERNOR ARM INSTALLATION (Without auto throttle type)

Install the governor arm (1) on the governor arm shaft (2) by aligning the cutout.

Tighten the governor arm nut (3).

TORQUE: 11 N·m (1.1 kgf·m, 8 lbf·ft)


Connect the governor rod (4) and throttle return spring (5) to the governor arm and carburetor.

Loosen the governor sub arm nut (6).

Rotate the governor arm counterclockwise to fully open the carburetor throttle valve.

Rotate the governor sub arm (7) counterclockwise as far as it will go.

Hold the governor arm and governor sub arm, tighten the governor sub arm nut securely.



GOVERNOR SYSTEM


GOVERNOR SPRING INSTALLATION

Hook the governor spring (1) to the throttle lever (2) of the control.

Refer to the table below to confirm the governor spring position on the governor arm (3).

- The engine type is stamped on the crankcase near the engine serial number (page 1-2).

| Model | Type | Spring position |
|--------|-----------------------------------|-----------------|
| GX630 | All types | 1 |
| GX630R | Except QYD, VEP4, VXD8, VXE1, VXF | 1 |
| | QYD, VEP4, VXD8, VXE1, VXF | 2 |
| GX660 | All types | 1 |
| GX660R | Except VXE1 | 1 |
| | VXE1 | 2 |
| GX690 | All types | 1 |
| GX690R | Except VXE | 1 |
| | VXE | 2 |




AUTO THROTTLE SOLENOID REMOVAL

Remove the air cleaner case (page 6-3).

Disconnect the choke rod from the control (page 7-2).

Unhook the governor spring and start spring from the governor arm (page 7-2).



GOVERNOR SYSTEM


AUTO THROTTLE SOLENOID/ GOVERNOR ARM INSTALLATION

Install the governor arm (1) on the governor arm shaft (2) by aligning the cutout.

Tighten the governor arm nut (3).


TORQUE: 11 N·m (1.1 kgf·m, 8 lbf·ft)

Connect the governor rod (4) and throttle return spring (5) to the governor arm and carburetor.



Install the auto throttle solenoid (1) and solenoid plate (2) on the solenoid stay (3) and loosely tighten the two special cap nuts (4).

Install the solenoid stay on the control (5) and tighten the two bolts (6).




GOVERNOR SYSTEM

Route the auto throttle solenoid harness on the upper shroud loosely (page 2-9).

Install the control (1) on the cylinders and tighten the three bolts (2).

Hook the governor spring and start spring to the governor arm (page 7-4).



Rotate the governor arm (1) to fully open the throttle valve (2).

Slowly rotate the auto throttle solenoid (3) so the distance between the auto throttle lever (4) and the pin (5) of the governor sub arm (6) is in the specified clearance.

Do not rotate the governor sub arm during this procedure.


CLEARANCE: 0 – 1 mm (0 – 0.04 in)

Tighten the special cap nuts (7) to secure the auto throttle solenoid.

Check the clearance between the auto throttle lever and the governor sub arm pin.

Take up the slack of the auto throttle solenoid harness and route the crankcase (page 2-9).

Rotate the governor arm to fully open the throttle valve and be sure that the pin on the governor sub arm is not touching to the auto throttle lever.




GOVERNOR SYSTEM

CONTROL BOX REMOVAL/ INSTALLATION

Disconnect the throttle cable and the choke cable from the control.

Disconnect the combination switch terminals and connector from the starter motor and regulator/rectifier.



THROTTLE CABLE INSTALLATION

Connect the throttle cable (1) to the throttle lever (2) of the control.

Move the throttle lever (3) on the control box (4) to throttle off position.


Pull the throttle cable and be sure not to slack it.
Set the throttle cable to the cable holder (5) of the control as shown.

Tighten the recessed bolt (6) on the cable holder to secure the throttle cable.

Move the throttle lever of the control box to throttle off position and be sure there is free play of the throttle position.

Move the throttle lever of the control box to full throttle position and be sure the throttle lever of the control touches the maximum speed adjusting screw.

Secure the choke cable to the oil level pipe with the wire band.



CHOKE CABLE INSTALLATION

Install the choke cable (1) on the control box bracket (2).

Pull the choke knob (3) of the control box (4) to the fully closed position.

Hook the choke cable to the choke lever (5) of the control.

Pull the choke cable until the choke lever of the control touches with the control to fully close the carburetor choke valve.


Set the choke cable to the cable holder (6) of the control and be sure not to slack it.

Tighten the recessed bolt (7) on the cable holder to secure the choke cable.

Push the choke knob of the control box fully and be sure the choke lever of the control returns to the original position.

Pull the choke knob of the control box until it clicks and be sure the choke lever of the control touches the control base.


Secure the choke cable to the oil level pipe with the wire band.



GOVERNOR SYSTEM

CONTROL BOX DISASSEMBLY/ ASSEMBLY

Remove the control box (page 7-8).




8. CHARGING SYSTEM


| | | | |
|---|------------|--|------------|
| SYSTEM DIAGRAM | 8-2 | CHARGE COIL REMOVAL/ INSTALLATION | 8-6 |
| CHARGING SYSTEM TROUBLESHOOTING | 8-3 | CHARGE COIL INSPECTION | 8-7 |
| COOLING FAN/FLYWHEEL REMOVAL/ INSTALLATION | 8-4 | REGULATOR/RECTIFIER SYSTEM INSPECTION | 8-7 |
| | | REGULATOR/RECTIFIER INSPECTION | 8-8 |

CHARGING SYSTEM SYSTEM DIAGRAM


2.7 A CHARGE COIL TYPE



17 A CHARGE COIL TYPE




26 A CHARGE COIL TYPE



CHARGING SYSTEM TROUBLESHOOTING

BATTERY DAMAGED OR WEAK



CHARGING SYSTEM

COOLING FAN/FLYWHEEL REMOVAL/ INSTALLATION

REMOVAL

Remove the following parts.



- Fan cover (page 5-2)
- L./R. lower shroud (page 5-5)
- Ignition coil (page 9-4)

Hold the flywheel (1) with the special tool (2) and remove the special nut (3).

TOOL:


Clutch center holder (2)

07JMB-MN50301



REMOVAL:

Hold the flywheel (1) with a commercially available strap wrench (2) and use a commercially available flywheel puller (3) to remove the flywheel.



INSTALLATION

Clean the tapered part of the crankshaft (1) and flywheel (2) of dirt, oil, grease and other foreign material before installation. Be sure there are no metal parts or other foreign material on the magnet part of the flywheel.

Set the special woodruff key in the key groove of the crankshaft securely.

Install the flywheel on the crankshaft.

NOTICE

The flywheel may push the key out of its slot; check after installation.

Attach the cooling fan (3) by aligning the holes (4) with projections (5) as shown.

Attach the cooling fan setting plate (1) to the cooling fan (2) by aligning the claws of the cooling fan setting plate with the projections of the cooling fan

Rotate the cooling fan setting plate clockwise to touch the claw of the cooling fan setting plate with projections of the cooling fan.



Apply a light coat of oil to the threads and the seating surface of the special nut (3) and loosely tighten the nut.

Hold the flywheel with special tool (4), tighten the special nut to the specified torque.

TOOL:

Clutch center holder (4) 07JMB-MN50301



TORQUE: 235 N·m (24 kgf·m, 173 lbf·ft)



CHARGING SYSTEM


CHARGE COIL REMOVAL/ INSTALLATION

Remove the flywheel (page 8-4).



HARNESS BRACKET

INSTALLATION:
Be sure not to pinch the charge coil wire (1) with the harness bracket (2).



CHARGE COIL INSPECTION

Disconnect the charge coil connector/s.

Measure the resistance between the terminals of the charge coil.

Resistance:

2.7 A: 1.95 - 2.93 Ω

17 A: 0.18 - 0.28 Ω


26 A: 0.17 - 0.25 Ω

Check for continuity between each terminal and engine ground.


There should be no continuity.

If the measured resistance is not within the range specification or if any wire has continuity to engine ground, replace the charge coil (page 8-6).

2.7 A / 17 A TYPES:




26 A TYPE:



REGULATOR/RECTIFIER SYSTEM INSPECTION

Disconnect the regulator/rectifier connector (1) and check the regulator/rectifier connector terminals (wire harness side) as follows:

| Item | Terminal | Specification |
|-----------------------|----------------------|---------------------------------|
| Battery charging line | White (+) and ground | Battery voltage should register |
| Charge coil line | Gray and ground | 2.7A: 1.95 - 2.93 Ω |
| | | 17A: 0.18 - 0.28 Ω |
| | | 26A: 0.17 - 0.25 Ω |
| Ground line | Black and ground | Continuity should exist |



CHARGING SYSTEM

REGULATOR/RECTIFIER INSPECTION

Disconnect the regulator/rectifier connector/s.

Measure the resistance between the terminals and be sure that the measurements are within the specifications in the table below.

- Use a following range of recommended analog multimeter.
 - SP-15D (SANWA): kΩ range
 - TH-5H (KOWA): R x 100 range

2.7 A:

Unit: Ω

| | | (+ probe) | | |
|-----------|------|-----------|------|-----|
| | | CHG1 | CHG2 | BAT |
| (-) probe | CHG1 | — | ∞ | ∞ |
| | CHG2 | ∞ | — | ∞ |
| | BAT | 1k – 10k | ∞ | — |

17 A:

Unit: Ω

| | | (+ probe) | | |
|-----------|-------|-----------|----------|-----------|
| | | ACG1 | ACG2 | BAT |
| (-) probe | ACG1 | — | ∞ | 290 – 22k |
| | ACG2 | ∞ | — | 290 – 22k |
| | BAT | ∞ | ∞ | — |
| | SENSE | 80k – ∞ | 80k – ∞ | 120k – ∞ |
| | CHG.M | 150k – ∞ | 150k – ∞ | 300k – ∞ |
| | GND | ∞ | ∞ | ∞ |

| | | (+ probe) | | |
|-----------|-------|-----------|-----------|------------|
| | | SENSE | CHG.M | GND |
| (-) probe | ACG1 | ∞ | ∞ | ∞ |
| | ACG2 | ∞ | ∞ | ∞ |
| | BAT | ∞ | ∞ | ∞ |
| | SENSE | — | 2k – 150k | 8k – 150k |
| | CHG.M | 300 – 30k | — | 20k – 300k |
| | GND | ∞ | ∞ | — |


26 A:

Unit: Ω


| | | (+ probe) | | |
|-----------|------|------------|------------|------------|
| | | ACG1 | ACG2 | ACG3 |
| (-) probe | ACG1 | — | 30k – 420k | 30k – 420k |
| | ACG2 | 30k – 420k | — | 30k – 420k |
| | ACG3 | 30k – 420k | 30k – 420k | — |
| | BAT | 30k – 420k | 30k – 420k | 30k – 420k |
| | LAMP | ∞ | ∞ | ∞ |
| | GND | 30k – 950k | 30k – 950k | 30k – 950k |

| | | (+ probe) | | |
|-----------|------|-----------|------------|------------|
| | | BAT | LAMP | GND |
| (-) probe | ACG1 | ∞ | ∞ | ∞ |
| | ACG2 | ∞ | ∞ | ∞ |
| | ACG3 | ∞ | ∞ | ∞ |
| | BAT | — | 30k – 340k | 15k – 190k |
| | LAMP | ∞ | — | ∞ |
| | GND | 400 – 25k | 30k – 420k | — |


2.7 A TYPE:



17 A TYPE:



26 A TYPE:




9. IGNITION SYSTEM


| | | | |
|---|-----|---|-----|
| SYSTEM DIAGRAM | 9-2 | IGNITION COIL REMOVAL/ INSTALLATION..... | 9-4 |
| IGNITION SYSTEM TROUBLESHOOTING..... | 9-2 | SPARK TEST | 9-5 |


IGNITION SYSTEM

SYSTEM DIAGRAM

IGNITION SYSTEM
TROUBLESHOOTING

NO SPARK AT SPARK PLUG






IGNITION SYSTEM

IGNITION COIL REMOVAL/ INSTALLATION

REMOVAL

Remove the following parts:

- Fan cover (page 5-2).
- L./R. lower shroud (page 5-5).



INSTALLATION

Attach the ignition coil (1) and loosely tighten the two flange bolts (2).

Insert the thickness gauge (3) of proper thickness between the ignition coil and the flywheel (4).


**IGNITION COIL AIR GAP:
0.2 – 0.6 mm (0.01 – 0.02 in)**

NOTICE

Adjust the ignition coil air gap equally at both side.

Push the ignition coil firmly against the flywheel and tighten the flange bolts.

Remove the thickness gauge.



SPARK TEST


Inspect the following before spark test.

- Faulty spark plug
- Loose spark plug cap
- Water in the spark plug cap (Leaking the ignition coil secondary voltage)
- Check the ignition coil connection

Disconnect the spark plug cap (1) from the spark plug (2).

Connect a known-good spark plug (3) to the spark plug cap and ground the spark plug to the head cover bolt (4).

Crank the engine by operating the starter motor several seconds and check whether sparks jump across the electrode.



NOTICE

Do not operate the starter motor for more than 5 seconds at a time. When operating the starter motor several times in a row, wait 10 – 20 seconds between operation to recover the battery voltage.



MEMO




10. STARTING SYSTEM

| | | | |
|--|------|--|------|
| SYSTEM DIAGRAM | 10-2 | STARTER MOTOR DISASSEMBLY/ ASSEMBLY | 10-4 |
| STARTING SYSTEM TROUBLESHOOTING | 10-2 | STARTER MOTOR INSPECTION | 10-5 |
| STARTER MOTOR REMOVAL/ INSTALLATION | 10-3 | BRUSH REPLACEMENT | 10-8 |


STARTING SYSTEM

SYSTEM DIAGRAM




STARTING SYSTEM TROUBLESHOOTING

STARTER MOTOR DOES NOT OPERATE



STARTER MOTOR REMOVAL/ INSTALLATION


Disconnect the starter motor wires from the starter motor.



STARTING SYSTEM

STARTER MOTOR DISASSEMBLY/ ASSEMBLY

DISASSEMBLY



ASSEMBLY

Attach the pinion drive lever (1) to the magnetic switch (2). Set the pinion drive lever to the overrunning clutch (3) of the armature.


Install the magnetic switch and armature to the drive housing (4) and tighten the flange nuts to secure the magnetic switch.

Install the yoke (5) to the drive housing.

Install the brush holder (6) to the yoke, and set the brushes (7) and brush springs (8) to the brush holder. Install the brush holder insulator (9).

Install the commutator end frame (10) by aligning the brush terminal grommet (11) with the cutout of the commutator end frame.

Tighten the through bolts to secure the drive housing and commutator end frame.

**STARTER MOTOR INSPECTION****PERFORMANCE TEST**

Measure starter performance while cranking the engine.

STARTER MOTOR PERFORMANCE:**UNDER LOAD:**

CRANKING VOLTAGE: 9 V

CRANKING CURRENT: 150 A

ENGINE CRANKING SPEED: 1,950 min⁻¹ (rpm) min.

NO LOAD:

CRANKING VOLTAGE: 11.5 V

CRANKING CURRENT: 50 A max.

- To get accurate results, the test must be operated in the normal ambient temperature.
- Battery: 55B24 (12 V 36 AH/5 HR)
- Battery cable: 15 sq x 1.5 m (4.9 ft) each for battery positive cable and battery negative cable.

If the measurement is out of specification, disassemble and inspect the starter motor.


STARTING SYSTEM

MAGNETIC SWITCH

Check the continuity between the terminals of the magnetic switch.

There should be no continuity between the terminals.

If there is continuity, replace the magnetic switch (page 10-4).




BRUSH LENGTH

Measure the brush length.

STANDARD: 10 mm (0.4 in)

SERVICE LIMIT: 6 mm (0.2 in)

If brush length is less than the service limit, replace the brush (page 10-8).



BRUSH CONTINUITY CHECK


Check for continuity between the positive (+) brushes (1) and negative (-) brushes (2).

There should be continuity between both the positive brushes.

There should be continuity between both the negative brushes.

There should be no continuity between both the positive and negative brushes.

If the correct continuity is not obtained, replace the yoke (page 10-4).




OVERRUNNING CLUTCH

Hold the armature (1) as shown and check that the overrunning clutch (2) turns clockwise and slides smoothly. If necessary, apply oil or replace the overrunning clutch (page 10-4).

Check the pinion gear (3) for wear or damage and replace the over running clutch if necessary (page 10-4).

If the pinion gear is worn or damaged, the flywheel ring gear must be inspected.




MICA DEPTH

Clean the commutator, and then measure the mica depth.


SERVICE LIMIT: 0.2 mm (0.01 in)

If the measurement is less than the service limit, replace the armature (page 10-4).



ARMATURE CONTINUITY CHECK - COMMUTATOR SEGMENTS


Check for continuity between segments. If an open circuit (no continuity) exists between any two segments, replace the armature (page 10-4).



ARMATURE CONTINUITY CHECK - COMMUTATOR TO CORE

Check for continuity between the commutator segments and the armature coil core.


Replace the armature if continuity exists between any of the commutator segments and the armature coil core (page 10-4).



ARMATURE CONTINUITY CHECK - COMMUTATOR TO SHAFT

Check for continuity between the commutator and the armature shaft.

Replace the armature if continuity exists between any of the commutator segments and the armature shaft (page 10-4).




STARTING SYSTEM


BRUSH REPLACEMENT

Cut off the brush lead (1) at the point shown and remove the brush (2).

Remove the remaining brush lead and deposited solder from the terminal.




Hold a new brush (1) in the same direction of the removed brush and put a new plate (2) over the new brush and terminal (3) and press it using a pair of pliers as shown.



Solder the plate on the terminal.



- Before soldering, heat the pressed part of the plate well to make sure solder reaches the end of the pressed part.
- Prevent solder from flowing down the brush lead.
- Do not allow solder to run down onto the field winding of the yoke.
- File the brush so that the brush and commutator can fit using an emery paper #500 or #600.




11. OTHER ELECTRICAL

| | | | |
|--------------------------------------|------|--|------|
| COMPONENT LOCATION | 11-2 | AUTO THROTTLE SOLENOID INSPECTION | 11-3 |
| OIL LEVEL SWITCH INSPECTION | 11-3 | COMBINATION SWITCH INSPECTION | 11-4 |
| OIL PRESSURE SWITCH INSPECTION | 11-3 | HOUR METER INSPECTION | 11-5 |

OTHER ELECTRICAL COMPONENT LOCATION



AUTO THROTTLE SOLENOID



OIL LEVEL SWITCH INSPECTION


Disconnect the engine wire harness from the oil level switch.

Check continuity between the switch terminals.
There should be no continuity when the engine is full of oil.

Drain the engine oil completely (page 3-4).
Check continuity between the switch terminals.
There should be continuity.

Check continuity between the switch terminals while filling the engine oil.
The ohmmeter reading should go from continuity to no continuity as the oil is filled.

If the correct continuity is not obtained, replace the oil level switch (page 15-4).




OIL PRESSURE SWITCH INSPECTION

With the combination switch OFF, check continuity between the switch terminal and switch body.
There should be continuity.

Start the engine and check continuity between the switch terminal and switch body.
There should be no continuity.

If the correct continuity is not obtained, replace the oil pressure switch (page 13-3).




AUTO THROTTLE SOLENOID INSPECTION

Disconnect the auto throttle solenoid terminals.

Apply 12V battery voltage and check the auto throttle solenoid lever operation.

OPERATING LEVER ANGLE: 24° – 26°

If the auto throttle solenoid is not operate or the operating angle is out of specification, replace the auto throttle solenoid (page 7-6).




OTHER ELECTRICAL

COMBINATION SWITCH INSPECTION

Remove the combination switch (page 7-10).

Check continuity between the terminals at each switch position.

If the correct continuity is not obtained, replace the combination switch (page 7-10).



Disconnect the charge coil connectors and combination switch 4P connector (1). Remove the combination switch 4P connector, and open the wire harness clip (2) to remove the wire harness.


Remove the special screw (3) and the control cover (4).

Remove the blade fuse (5) from the fuse box (6).

Visually inspect the blade fuse.

Check continuity between the blades of the fuse.

If there is not continuity, replace the blade fuse.




HOUR METER INSPECTION

Remove and disconnect the hour meter 4P connector (1).

Apply a 9 V battery voltage between the PULSE terminal (Yellow) and GND terminal (Green).
The hour meter should start counting time.

Apply a 4.5 V battery voltage between the LED terminal (Blue) and GND terminal (Green).
The oil indicator should come on.





MEMO



12. MUFFLER

HIGH MOUNT MUFFLER REMOVAL/
INSTALLATION..... 12-2

SIDE MOUNT MUFFLER REMOVAL/
INSTALLATION..... 12-3

EXHAUST PIPE STUD BOLT
REPLACEMENT.....12-5

HIGH MOUNT MUFFLER MOUNTING STUD
BOLT REPLACEMENT.....12-5

MUFFLER

HIGH MOUNT MUFFLER REMOVAL/ INSTALLATION

⚠ CAUTION

The muffler becomes very hot during operation and remains hot for a while after stopping the engine. Be careful not to touch the muffler while it is hot. Allow it to cool before proceeding.

MUFFLER PROTECTOR

INSTALLATION:
Make sure the "HOT" mark
on the protector is
in an upward direction.

BOLT(6 x 8 mm) (6)

HOT MARK

MUFFLER

BOLT(8 x 20 mm) (2)


NUT(8 mm) (6)

TAPPING SCREW(4 x 6 mm)

NEW

EXHAUST
PIPE GASKET

SPARK ARRESTER




SIDE MOUNT MUFFLER REMOVAL/ INSTALLATION

⚠ CAUTION

The muffler becomes very hot during operation and remains hot for a while after stopping the engine. Be careful not to touch the muffler while it is hot. Allow it to cool before proceeding.


REMOVAL



MUFFLER

INSTALLATION

Make marks on the exhaust pipe (1) in the positions as shown.



Install the muffler band (1) to the muffler (2) and insert the exhaust pipe (3) into the muffler to mark A.


Install the two exhaust muffler gaskets (4) and exhaust pipe to the cylinders, then slide the exhaust pipe to mark B.

Tighten the three bolts (5) to secure the muffler.

Tighten the four nuts (6) to secure the exhaust pipe.

Tighten the muffler band.

Install the muffler protector (outside) (7) and tighten the four bolts (8).




EXHAUST PIPE STUD BOLT REPLACEMENT

Thread two nuts onto the stud bolt and tighten them together, then use a wrench to turn the stud bolt out.

Install new stud bolts.

SPECIFIED LENGTH: 22 mm (0.87 in)



HIGH MOUNT MUFFLER MOUNTING STUD BOLT REPLACEMENT


Thread two nuts onto the stud bolt and tighten them together, then use a wrench to turn the stud bolt out.

Install new stud bolts.

SPECIFIED LENGTH:

No.1 cylinder: 60 mm (2.36 in)

No.2 cylinder: 45 mm (1.77 in)





MEMO




13. LUBRICATION SYSTEM

| | | | |
|----------------------------------|------|--------------------------|------|
| LUBRICATION SYSTEM DIAGRAM | 13-2 | OIL PUMP INSPECTION..... | 13-4 |
| OIL PRESSURE TEST | 13-3 | | |

LUBRICATION SYSTEM

LUBRICATION SYSTEM DIAGRAM




OIL PRESSURE TEST


Check the engine oil level (page 3-3).

Remove the oil pressure switch (1) or sealing plug (2).

FRONT MOUNT
TYPE:



SIDE MOUNT
TYPE:



Install the special tools (1)(2).

TOOLS:

Oil pressure gauge attachment (1) 07406-0030000

Oil pressure gauge set (2) 07506-3000000

TORQUE: 9 N·m (0.9 kgf·m, 6.6 lbf·ft)

NOTICE

Tighten the oil pressure gauge attachment to the specified torque. Do not overtighten the attachment to avoid damaging the crankcase threads.

Start the engine and allow it to warm up for 10 minutes.

While the engine is at idle, measure the oil pressure.


OIL PRESSURE:

2.8 kgf/cm² (39.8 psi) / 2,000 min⁻¹ (rpm) and more


If the oil pressure is less than the specification, inspect the oil pump (page 13-4).

Remove the special tools.

FRONT MOUNT TYPE:



SIDE MOUNT TYPE:



LUBRICATION SYSTEM


Clean the oil pressure switch or sealing bolt threads, and apply liquid sealant (Threebond 1207B, 1141G,1215) to the threads as shown. Tighten the oil pressure switch or sealing bolt to the specified torque.

TORQUE: 9 N·m (0.9 kgf·m, 6.6 lbf·ft)

NOTICE

Do not apply liquid sealant to the tip of the threads.

Tighten the oil pressure switch or sealing bolt to the specified torque. Do not overtighten the attachment to avoid damaging the crankcase threads.



OIL PUMP INSPECTION

OIL PUMP TIP CLEARANCE

Remove the crankcase cover (page 15-2).


Remove the oil pump cover (page 15-7).

Measure the oil pump rotor tip clearance.

STANDARD: 0.15 mm (0.006 in)

SERVICE LIMIT: 0.30 mm (0.012 in)

If the measurement is more than the service limit, replace the inner rotor and outer rotor (page 15-7).



OUTER ROTOR-TO-HOUSING CLEARANCE

Remove the crankcase cover (page 15-2).


Remove the oil pump cover (page 15-7).

Measure the oil pump outer rotor-to-housing clearance.

**STANDARD: 0.150 – 0.210 mm
(0.0059 - 0.0083 in)**

SERVICE LIMIT: 0.30 mm (0.012 in)

If the measurement is more than the service limit, replace the outer rotor (page 15-7).



OUTER ROTOR-TO-PUMP COVER CLEARANCE

Remove the crankcase cover (page 15-2).

Remove the oil pump cover (page 15-7).


Remove the oil pump O-ring (page 15-7).

Measure the oil pump outer rotor-to-pump cover clearance.

STANDARD: 0.04 – 0.09 mm (0.002 – 0.004 in)

SERVICE LIMIT: 0.11 mm (0.004 in)

If the measurement is more than the service limit, replace the outer rotor (page 15-7).



14. CYLINDER

| | | | |
|--|-------------|--|--------------|
| CYLINDER/PISTON REMOVAL | 14-2 | PISTON DISASSEMBLY/ASSEMBLY..... | 14-6 |
| PISTON INSTALLATION | 14-3 | CYLINDER/PISTON INSPECTION | 14-6 |
| CYLINDER INSTALLATION | 14-3 | VALVE SEAT RECONDITIONING..... | 14-13 |
| CYLINDER DISASSEMBLY/ASSEMBLY.... | 14-5 | CYLINDER STUD BOLT REPLACEMENT..... | 14-14 |


CYLINDER

CYLINDER/PISTON REMOVAL

Set the piston at the top dead center of the cylinder compression stroke (page 3-8).

Remove the following parts:

- Air cleaner (page 6-3)
- Carburetor (page 6-5)
- Muffler (page 12-2), (page 12-3)
- Control and governor arm (page 7-2)
- Fan cover (page 5-2)
- L./R. lower shroud (page 5-5)
- Ignition coil (page 9-4)
- Starter motor (page 10-3)
- Oil level pipe (page 15-2).
- Head cover (page 3-8).



PISTON INSTALLATION

Position the connecting rod of the cylinder near top dead center by rotating the crankshaft slowly.


Install the piston (1) on the connecting rod (2) with triangle mark (3) of the piston pointing toward the flywheel side as shown.

Apply oil to the piston pin (4) outer surface, connecting rod small end and piston pin bore.

Install the piston pin through the piston and connecting rod.

Install new piston pin clips (5) into the grooves in the piston pin hole.

- Make sure the piston pin clips are seated securely.
- Do not align the piston pin clip end gap (6) with the piston cutout (7).




CYLINDER INSTALLATION

Clean the mating surfaces of the cylinder and crankcase of old liquid gasket, oil and other foreign material.


Loosely install the fan cover and set the piston near top dead center by rotating the crankshaft slowly (page 3-8).

Apply a bead ($\Phi 1.0 - 1.5$ mm ($\Phi 0.04 - 0.06$ in)) of liquid gasket (Threebond TB1207B) to the mating surface of the cylinder as shown.

No.1 CYLINDER:



No.2 CYLINDER:



CYLINDER

Apply grease to the oil passage packing (1).
Install the dowel pins (2) and oil passage packing on the crankcase.

Apply oil to the cylinder inner surface, piston outer surface and piston rings.


Install the cylinder (3) over the piston (4) while compressing the piston rings with your fingers.

Apply a light coat of oil to the threads and the seating surface of the four flange nuts (5) and tighten them to the specified torque.

TORQUE: 37 N·m (3.8 kgf·m, 27 lbf·ft)

- Assemble the cylinder within 3 minutes after applying liquid gasket.
- Wait for 30 minutes after assembly before filling with oil and starting the engine.


Apply oil to the both end of the two push rods (6) and insert them into the cylinder.



Apply oil to the bearing and slipper of the rocker arms (1) and install them to the cylinder.

Apply oil to the rocker arm shaft (2) and insert into the cylinder in the direction as shown.

Install the head cover (page 3-8).




CYLINDER DISASSEMBLY/ASSEMBLY

Remove the cylinder (page 14-2).

VALVE SPRING RETAINER

DISASSEMBLY:
Push down and slide the valve spring retainer (1) to the side so that the valve stem (2) slips through the hole at side of the valve spring retainer.
Do not remove the valve spring retainer while the cylinder is installed to the crankcase, or the valve will drop into the cylinder.



ENGINE HANGER

BOLT (8 x 16 mm)

VALVE SPRING

VALVE STEM SEAL (Seal lip)

VALVE GUIDE CLIP

CYLINDER

INLET VALVE

ASSEMBLY:
Do not interchange with the exhaust valve.
The inlet valve is larger than the exhaust valve.

EXHAUST VALVE

ASSEMBLY:
Do not interchange with the inlet valve.
The exhaust valve is smaller than the inlet valve.

CYLINDER



PISTON DISASSEMBLY/ASSEMBLY

Remove the piston (page 14-2).

PISTON RING SET

ASSEMBLY:

The top ring (1) and second ring (2) are not interchangeable. Install the top ring and second ring on the piston with the mark side facing up. Check that the piston rings rotate smoothly after installing them. Space the piston ring end gaps 120 degrees apart, and do not align the ring end gaps with the piston pin bore.



CYLINDER/PISTON INSPECTION

CYLINDER COMPRESSION CHECK

Start the engine and warm up to normal operating temperature.

Turn the fuel valve lever of the application to the OFF position, and then loosen the carburetor drain screw to drain the float chamber.

Remove the spark plug cap from the spark plug.

Remove the spark plug using a spark plug wrench.

Operate the starter motor to expel unburned gas.

Attach a compression gauge (1) to the spark plug hole.

Operate the starter motor to measure stable cylinder compression.

NOTICE

Do not operate the starter motor for more than 5 seconds at a time. When operating the starter motor several times in a row, wait 10 – 20 seconds between operation to recover the battery voltage.

CYLINDER COMPRESSION:

0.5 – 0.7 MPa (5.09 – 7.14 kgf/cm², 73 – 102 psi) / 500 min⁻¹ (rpm)




CYLINDER SLEEVE I.D.

Measure and record the cylinder I.D. at three levels in both the "X" axis (perpendicular to crankshaft) and the "Y" axis (parallel to crankshaft). Take the maximum reading to determine cylinder wear and taper.

STANDARD: 78.000 – 78.015 mm
(3.0709 – 3.0715 in)

SERVICE LIMIT: 78.150 mm (3.0768 in)

If the measurement is more than the service limit, replace the cylinder (page 14-5).



VALVE SEAT WIDTH

Remove the carbon deposits from the combustion chamber (page 3-10).

Inspect each valve face for irregularities.

If necessary, replace the valve (page 14-5).

Apply a light coat of Prussian Blue or erasable felt-tipped marker ink to the each valve seat.

Using a valve lapper, insert the valve, and snap it closed against its seat several times. Be sure the valve does not rotate on the seat. The transferred marking compound will show any area of the valve face that is not concentric.

Measure the valve seat width of the cylinder.


STANDARD: 1.0 – 1.2 mm (0.04 – 0.05 in)

SERVICE LIMIT: 2.1 mm (0.08 in)

If the measurement is more than the service limit, recondition the valve seat (page 14-13).

Check whether the valve seat contact area of the valve is too high.

If the valve seat is too high, recondition the valve seat (page 14-13).



VALVE GUIDE I.D.

Ream the valve guide (1) to remove any carbon deposits before measuring.


TOOL:

Valve guide reamer 5.510 mm (2) 07984-2000001

NOTICE

Turn the special tool (Valve guide reamer) clockwise, never counterclockwise.

Continue to rotate the special tool while removing it from the valve guide.




CYLINDER

Measure and record each valve guide I.D.

STANDARD: 5.500 – 5.512 mm
(0.2165 – 0.2170 in)
SERVICE LIMIT: 5.560 mm (0.2189 in)

If the measured valve guide I.D. is more than the service limit, replace the cylinder (page 14-5).



VALVE STEM O.D.


Inspect each valve for bending or abnormal stem wear.

If necessary, replace the valve (page 14-5).

Measure and record each valve stem O.D.

STANDARD:
IN: 5.475 – 5.490 mm (0.2156 – 0.2161 in)
EX: 5.435 – 5.450 mm (0.2140 – 0.2146 in)
SERVICE LIMIT:
IN: 5.400 mm (0.2126 in)
EX: 5.300 mm (0.2087 in)

If the measurement is less than the service limit, replace the valve (page 14-5).



GUIDE-TO-STEM CLEARANCE

Subtract each valve stem O.D. from the corresponding valve guide I.D. to obtain the stem-to-guide clearance.

STANDARD:
IN: 0.010 – 0.037 mm (0.0004 – 0.0015 in)
EX: 0.050 – 0.077 mm (0.0020 – 0.0030 in)
SERVICE LIMIT:
IN: 0.110 mm (0.0043 in)
EX: 0.130 mm (0.0051 in)

If the calculated clearance is more than the service limit, replace the following:


- Valve (page 14-5)
- Cylinder (page 14-5)

VALVE SPRING FREE LENGTH

Measure the valve spring free length.

STANDARD: 38.3 mm (1.51 in)
SERVICE LIMIT: 36.8 mm (1.45 in)

If the measured length is less than the service limit, replace the valve spring (page 14-5).




VALVE SPRING PERPENDICULARITY

Measure the valve spring perpendicularity.

STANDARD: 2° max.


If the measured perpendicularity is more than the specification, replace the valve spring (page 14-5).

**PUSH ROD RUNOUT**

Check both ends of the push rod for wear.

Check the push rod for straightness.

If necessary, replace the push rod (page 14-2).


**ROCKER ARM I.D.**

Measure the rocker arm I.D.

STANDARD: 6.000 – 6.018 mm
(0.050 – 0.077 in)

SERVICE LIMIT: 6.043 mm (0.2379 in)

If the measurement is more than the service limit, replace the rocker arm (page 14-4).


**ROCKER ARM SHAFT O.D.**

Measure the rocker arm shaft O.D.

STANDARD: 5.960 – 5.990 mm
(0.2346 – 0.2358 in)

SERVICE LIMIT: 5.953 mm (0.2344 in)

If the measurement is less than the service limit, replace the rocker arm shaft (page 14-4).



CYLINDER


ROCKER ARM SHAFT BEARING I.D.

Measure the rocker arm shaft bearing I.D.

STANDARD: 6.000 – 6.018 mm
(0.050 – 0.077 in)

SERVICE LIMIT: 6.043 mm (0.2379 in)

If the measurement is more than the service limit, replace the cylinder (page 14-5).




PISTON SKIRT O.D.

Measure and record the piston O.D. at a point 10 mm (0.4 in) from the bottom of the skirt and 90 degrees to the piston pin bore.

STANDARD: 77.985 – 77.995 mm
(3.0703 – 3.0707 in)

SERVICE LIMIT: 77.850 mm (3.0650 in)

If the measurement is less than the service limit, replace the piston (page 14-6).



PISTON-TO-CYLINDER CLEARANCE


Subtract the piston skirt O.D. from the cylinder sleeve I.D. to obtain the piston-to-cylinder clearance.

STANDARD: 0.005 – 0.030 mm
(0.0002 – 0.0012 in)

SERVICE LIMIT: 0.10 mm (0.004 in)

If the calculated clearance is more than the service limit, replace the piston (page 14-6) and recheck the clearance.

If the clearance is still more than the service limit with the new piston, replace the cylinder (page 14-5).




PISTON PIN BORE I.D.

Measure and record the piston pin bore I.D. of the piston.

STANDARD: 18.002 – 18.008 mm
(0.7087 – 0.7090 in)

SERVICE LIMIT: 18.042 mm (0.7103 in)

If the measurement is more than the service limit, replace the piston (page 14-6).


**PISTON PIN O.D.**

Measure and record the piston pin O.D. at three points (both ends and middle). Take the minimum reading to determine piston pin O.D.

STANDARD: 17.994 – 18.000 mm
(0.7084 – 0.7087 in)

SERVICE LIMIT: 17.95 mm (0.707 in)

If the measurement is less than the service limit, replace the piston pin (page 14-3).

**PISTON PIN-TO-PISTON PIN BORE CLEARANCE**

Subtract the piston pin O.D. from the piston pin bore I.D. to obtain the piston pin-to-piston pin bore clearance.

STANDARD: 0.002 – 0.014 mm
(0.0001 – 0.0006 in)

SERVICE LIMIT: 0.08 mm (0.003 in)

If the calculated clearance is more than the service limit, replace the piston pin (page 14-3) and recheck the clearance.

If the clearance is still more than the service limit with the new piston pin, replace the piston (page 14-6).

PISTON RING SIDE CLEARANCE

Measure the clearance between each piston ring and ring groove of the piston using feeler gauge.

STANDARD:

Top: 0.050 – 0.080 mm (0.0020 – 0.0031 in)

Second: 0.050 – 0.080 mm (0.0020 – 0.0031 in)

SERVICE LIMIT:

Top: 0.15 mm (0.06 in)


Second: 0.15 mm (0.06 in)

If any of the measurements is more than the service limit, inspect the piston ring width. If necessary replace the piston rings (top, second, oil) as a set (page 14-6) and reinspect the clearance.

If any of the measurements is still more than the service limit with the new piston rings, replace the piston (page 14-6).

If the piston ring width is normal, replace the piston (page 14-6) and reinspect the clearance.

If necessary replace the piston rings (top, second, oil) as a set (page 14-6) and reinspect the clearance.



CYLINDER

PISTON RING WIDTH

Measure each piston ring width.

STANDARD:

Top: 1.140 – 1.155 mm (0.0449 – 0.0455 in)


Second: 1.140 – 1.155 mm (0.0449 – 0.0455 in)

SERVICE LIMIT:

Top: 1.120 mm (0.0441 in)

Second: 1.120 mm (0.0441 in)

If any of the measurements is less than the service limit, replace the piston rings (top, second, oil) as a set (page 14-6).



PISTON RING END GAP

Before inspection, check whether the cylinder sleeve I.D. is within the specification.

Set the piston ring into the cylinder sleeve using the piston head.

Measure each piston ring end gap using a feeler gauge.

STANDARD:

Top: 0.200 – 0.350 mm (0.0079 – 0.0138 in)

Second: 0.200 – 0.350 mm (0.0079 – 0.0138 in)

Oil (side rail): 0.20 – 0.70 mm (0.008 – 0.028 in)


SERVICE LIMIT:

Top: 1.0 mm (0.04 in)

Second: 1.0 mm (0.04 in)

Oil (side rail): 1.0 mm (0.04 in)

If any of the measurements is more than the service limit, replace the piston rings (top, second, oil) as a set (page 14-6).




CONNECTING ROD SMALL END I.D.

Measure the connecting rod small end I.D.

STANDARD: 18.006 – 18.018 mm
(0.7089 – 0.7094 in)

SERVICE LIMIT: 18.07 mm (0.711 in)

If the measurement is more than the service limit, replace the connecting rod (page 15-4).



VALVE SEAT RECONDITIONING


Valve seat cutters/grinders or equivalent valve seat refacing equipment are recommended to correct worn valve seats.

Using a 45° cutter remove enough material to produce a smooth and concentric seat.

TOOLS:

Cutter holder 5.5 mm (1) 07981-VA20101
Seat cutter 33 mm (45° IN) (2) 07780-0010800
Seat cutter 27.5 mm (45° EX) (2) 07780-0010200

Turn the cutter clockwise, never counterclockwise. Continue to turn the cutter as you lift it from the valve seat.



Use the 32° and 60° cutters to adjust the valve seat so that it contacts the middle of the valve face.

The 32° cutter removes material from the top edge.

TOOLS:

Cutter holder 5.5 mm 07981-VA20101
Flat cutter 33 mm (32° IN) 07780-0012900
Flat cutter 30 mm (32° EX) 07780-0012200

The 60° cutter removes material from the bottom edge.

TOOLS:

Cutter holder 5.5 mm 07981-VA20101
Interior cutter 30 mm (60° IN) 07780-0014000
Interior cutter 26 mm (60° EX) 07780-0014500

Be sure that the width of the finished valve seat is within specification.

Make a light pass with 45° cutter to remove any possible burrs at the edge of the seat.

TOOLS:


Cutter holder 5.5 mm 07981-VA20101
Seat cutter 33 mm (45° IN) 07780-0010800
Seat cutter 27.5 mm (45° EX) 07780-0010200

After resurfacing the seats, inspect for even valve seating.

Apply Prussian Blue compound or erasable felt-tipped marker ink to the valve seat. Insert the valve, and snap it closed against its seat several times. Be sure the valve does not rotate on the seat.

The seating surface, as shown by the transferred marking compound, should have good contact all the way around.

Thoroughly clean the cylinder to remove any cutting residual.



CYLINDER


Lap the valves into their seats, using a commercially available valve lapper (1) and lapping compound.

After lapping, wash all residual compound off the cylinder and valve.

NOTICE

To avoid severe engine damage, be sure to remove all lapping compound from the engine before reassembly.

Adjust the valve clearance after reassembly (page 3-8).



CYLINDER STUD BOLT REPLACEMENT


Thread two nuts onto the stud bolt and tighten them together, then use a wrench to turn the stud bolt out.

Install new stud bolts.

SPECIFIED LENGTH:

Upper side (1): 40.5 mm (1.59 in)

Lower side (2): 30.5 mm (1.20 in)



15. CRANKCASE


| | | | |
|---|------|--|-------|
| CRANKCASE COVER REMOVAL/ INSTALLATION..... | 15-2 | VALVE LIFTER DISASSEMBLY/ ASSEMBLY..... | 15-8 |
| CRANKSHAFT/CONNECTING ROD/ CAMSHAFT/VALVE LIFTER REMOVAL/ INSTALLATION..... | 15-4 | CRANKCASE COVER/CRANKCASE/ CRANKSHAFT/CONNECTING ROD/ CAMSHAFT/VALVE LIFTER INSPECTION..... | 15-8 |
| CAMSHAFT INSTALLATION..... | 15-5 | CRANKSHAFT OIL SEAL REPLACEMENT (CRANKCASE COVER SIDE)..... | 15-13 |
| BREATHER DISASSEMBLY/ ASSEMBLY..... | 15-5 | CRANKSHAFT/GOVERNOR ARM SHAFT OIL SEAL REPLACEMENT (CRANKCASE SIDE)..... | 15-14 |
| BREATHER COVER INSTALLATION..... | 15-6 | | |
| GOVERNOR/OIL PUMP/OIL FILTER DISASSEMBLY/ASSEMBLY..... | 15-7 | | |

CRANKCASE


CRANKCASE COVER REMOVAL/ INSTALLATION

REMOVAL

Drain the engine oil (page 3-4).




REMOVAL:
Insert a screwdriver into the recess (1) as shown and remove the crankcase cover from the crankcase.



INSTALLATION

Clean the mating surfaces of the crankcase cover and crankcase of old liquid gasket, oil and other foreign material.


Apply a bead ($\Phi 1.0 - 1.5$ mm ($\Phi 0.04 - 0.06$ in)) of liquid gasket (Threebond TB1207B) to the mating surface of the crankcase cover as shown.



Apply grease to the O-ring (1).
Install the two dowel pins (2) and O-ring to the crankcase.

Apply a light coat of oil to the main journal part of the crankshaft and crankcase cover (3).
Install the crankcase cover and tighten the nine flange bolts (4) securely.

- Assemble the crankcase cover within 3 minutes after applying liquid gasket.
- Wait for 30 minutes after assembly before filling with oil and starting the engine.




CRANKCASE

CRANKSHAFT/CONNECTING ROD/ CAMSHAFT/VALVE LIFTER REMOVAL/ INSTALLATION

Remove the following:


- Flywheel (page 8-4)
- Cylinder (page 14-2)
- Crankcase cover (page 15-2)



CAMSHAFT INSTALLATION


Open the valve lifters in the crankcase.

Install the camshaft (1) to the crankcase (2) by aligning the punch marks (3) on the camshaft and the crankshaft (4) (marked on the timing gear).



BREATHER DISASSEMBLY/ ASSEMBLY

Remove the charge coil (page 8-6).




CRANKCASE

BREATHER COVER INSTALLATION


Clean the mating surfaces of the breather cover and crankcase of old liquid gasket, oil and other foreign material.

Apply a bead ($\Phi 1.0 - 1.5$ mm ($\Phi 0.04 - 0.06$ in)) of liquid gasket (Threebond TB1207B) to the mating surface of the crankcase as shown.




Install the breather cover (1) and tighten the three flange bolts (2) securely.

- Be sure not to catch the breather filter between the breather cover and crankcase.
- Assemble the breather cover within 3 minutes after applying liquid gasket.
- Wait for 30 minutes after assembly before filling with oil and starting the engine.




GOVERNOR/OIL PUMP/OIL FILTER DISASSEMBLY/ASSEMBLY

Remove the crankcase cover (page 15-2).



CRANKCASE**VALVE LIFTER DISASSEMBLY/
ASSEMBLY**

Remove the valve lifter (page 15-4).

**CRANKCASE COVER/CRANKCASE/
CRANKSHAFT/CONNECTING ROD/
CAMSHAFT/VALVE LIFTER
INSPECTION****CRANKSHAFT AXIAL CLEARANCE**

Remove the connecting rods (page 15-4).


Reinstall the crankcase cover.

Measure the crankshaft axial clearance.

STANDARD: 0.05 – 0.45 mm (0.002 – 0.018 in)

SERVICE LIMIT: 1.0 mm (0.04 in)

If the measurement is more than the service limit, inspect the crankshaft thrust washer (page 15-10).




MAIN JOURNAL I.D.: CRANKCASE COVER SIDE

Measure the main journal I.D. of the crankcase cover.

STANDARD: 40.025 – 40.041 mm
(1.5758 – 1.5764 in)

SERVICE LIMIT: 40.06 mm (1.577 in)

If the measurement is more than the service limit, replace the crankcase cover (page 15-7).


**MAIN JOURNAL I.D.: CRANKCASE SIDE**

Measure the main journal I.D. of the crankcase.

STANDARD: 40.025 – 40.041 mm
(1.5758 – 1.5764 in)

SERVICE LIMIT: 40.06 mm (1.577 in)

If the measurement is more than the service limit, replace the crankcase (page 15-4).


**CAMSHAFT BEARING I.D.: CRANKCASE COVER SIDE**

Measure the camshaft bearing I.D. of the crankcase cover.

STANDARD: 17.016 – 17.027 mm
(0.6699 – 0.6704 in)

SERVICE LIMIT: 17.06 mm (0.672 in)

If the measurement is more than the service limit, replace the crankcase cover (page 15-7).


**CAMSHAFT BEARING I.D.: CRANKCASE SIDE**

Measure the camshaft bearing I.D. of the crankcase.

STANDARD: 17.016 – 17.027 mm
(0.6699 – 0.6704 in)

SERVICE LIMIT: 17.06 mm (0.672 in)

If the measurement is more than the service limit, replace the crankcase (page 15-4).



CRANKCASE


CRANK PIN O.D.

Measure the crank pin O.D. of the crankshaft.

STANDARD: 44.973 – 44.983 mm
(1.7706 – 1.7710 in)

SERVICE LIMIT: 44.920 mm (1.7685 in)

If the measurement is less than the service limit, replace the crankshaft (page 15-4).




CRANKSHAFT MAIN JOURNAL O.D.

Measure the main journal O.D. of the crankshaft.

STANDARD: 39.984 – 40.000 mm
(1.5742 – 1.5748 in)

SERVICE LIMIT: 39.930 mm (1.5720 in)

If the measurement is less than the service limit, replace the crankshaft (page 15-4).




CRANKSHAFT THRUST WASHER THICKNESS

Measure the crankshaft thrust washer thickness.

STANDARD: 0.95 – 1.05 mm
(0.037 – 0.041 in)

SERVICE LIMIT: 0.8 mm (0.03 in)

If the measurement is less than the service limit, replace the crankshaft thrust washer (page 15-4).



CONNECTING ROD BIG END SIDE CLEARANCE


Measure the clearance between the connecting rod big end and crankshaft using a feeler gauge.

STANDARD: 0.2 – 0.4 mm (0.008 – 0.016 in)

SERVICE LIMIT: 1.000 mm (0.0394 in)

If the measurement is more than the service limit, replace the connecting rod (page 15-4) and recheck the clearance.

If the clearance is still more than the service limit with the new connecting rod, replace the crankshaft (page 15-4).



CONNECTING ROD BIG END I.D.

Set the connecting rod lower and connecting rod bearings to the connecting rod upper and tighten the connecting rod bolts to the specified torque.


TORQUE: 22 N·m (2.2 kgf·m, 16 lbf·ft)

Measure the connecting rod big end I.D.

**STANDARD: 44.988 – 45.012 mm
(1.7712 – 1.7721 in)**

SERVICE LIMIT: 45.050 mm (1.7736 in)

If the measurement is more than the service limit, replace the connecting rod bearings (page 15-4).


**CONNECTING ROD BIG END OIL CLEARANCE**

Clean all oil from the crank pin, connecting rod big end surface and connecting rod bearings.

Place a piece of plastigauge on the crank pin, install the connecting rod upper, the connecting rod lower and the connecting rod bearings, and tighten the connecting rod bolts to the specified torque.

TORQUE: 22 N·m (2.2 kgf·m, 16 lbf·ft)

- Do not rotate the crankshaft while the plastigauge is in place.




Remove the connecting rod and measure the plastigauge.

**STANDARD: 0.005 – 0.039 mm
(0.0002 – 0.0015 in)**

SERVICE LIMIT: 0.070 mm (0.0028 in)

If the clearance is more than the service limit, replace the connecting rod bearings (page 15-4) and recheck the clearance.

If the clearance is still more than the service limit with the new connecting rod bearings, replace the crankshaft (page 15-4).

**CAMSHAFT CAM HEIGHT**

Measure the cam height of the camshaft.

STANDARD:

IN: 29.506 – 29.706 mm (1.1617 – 1.1695 in)


EX: 29.410 – 29.610 mm (1.1579 – 1.1657 in)

SERVICE LIMIT:

IN: 29.36 mm (1.156 in)

EX: 29.26 mm (1.152 in)

If the measurement is less than the service limit, replace the camshaft (page 15-4).



CRANKCASE


CAMSHAFT O.D.

Measure the camshaft O.D. of the camshaft.

STANDARD: 16.982 – 17.000 mm
(0.6686 – 0.6693 in)

SERVICE LIMIT: 17.100 mm (0.6732 in)

If the measurement is less than the service limit, replace the camshaft (page 15-5).




DECOMPRESSOR WEIGHT

Check for worn and weakened weight return spring (1).

If the spring is worn or weakened, replace the weight return spring.

Check that the decompressor weight (2) moves smoothly.

If the decompressor weight does not move correctly, replace the camshaft (page 15-5).




VALVE LIFTER I.D.

Measure the valve lifter I.D.

STANDARD: 6.010 – 6.040 mm
(0.2366 – 0.2378 in)

SERVICE LIMIT: 6.070 mm (0.2390 in)

If the measurement is more than the service limit, replace the valve lifter (page 15-8).




VALVE LIFTER SHAFT O.D.

Measure the valve lifter shaft O.D.

STANDARD: 5.970 – 6.000 mm
(0.2350 – 0.2362 in)

SERVICE LIMIT: 5.940 mm (0.2339 in)


If the measurement is less than the service limit, replace the valve lifter shaft (page 15-8).



CRANKSHAFT OIL SEAL REPLACEMENT (CRANKCASE COVER SIDE)

LOCATION

CRANKSHAFT OIL SEAL
(38 x 58 x 9 mm)



CRANKSHAFT OIL SEAL (38 x 58 x 9 mm)

Remove the crankcase cover (page 15-2).

Remove the oil seal (1) from the crankcase cover (2).

Apply oil to the outer surface of a new oil seal.


Drive the new oil seal in the position as shown using the special tools.


TOOLS:

Driver handle 15 x 135L (3) 07749-0010000

Oil seal driver attachment
60 mm (4) 07GAD-PG40100

Apply grease to the lip of a new oil seal.



CRANKCASE**CRANKSHAFT/GOVERNOR ARM
SHAFT OIL SEAL REPLACEMENT
(CRANKCASE SIDE)****LOCATION****CRANKSHAFT OIL SEAL (38 x 58 x 9
mm)**

Remove the crankshaft (page 15-4).

Remove the oil seal (1) from the crankcase (2).

Apply oil to the outer surface of a new oil seal.


Drive the new oil seal in the position as shown using the special tools.

TOOLS:

Driver handle 15 x 135L (3) 07749-0010000

**Oil seal driver attachment
60 mm (4) 07GAD-PG40100**

Apply grease to the lip of a new oil seal.



GOVERNOR ARM SHAFT OIL SEAL (10 x 16 x 5 mm)

Remove the governor arm shaft (page 15-4).

Remove the oil seal (1) from the crankcase (2).

Apply oil to the outer surface of a new oil seal.


Drive the new oil seal until it is fully seated on the end using the special tools.

TOOLS:

Driver handle 15 x 135L (3) 07749-0010000

Pilot 17 mm (4) 07746-0040400

Apply grease to the lip of a new oil seal.





MEMO



16. TECHNICAL FEATURES

HIGH-COMPRESSION ENGINE 16-2

TECHNICAL FEATURES

HIGH-COMPRESSION ENGINE

OUTLINE

The GX630/GX630R/GX660/GX660R/GX690/GX690R engines have more combustion efficiency and cylinder cooling capability than previous models. This results in increased the compression (increased to 9.3 from 8.3) and higher engine output.

FEATURE


Combustion efficiency and intake/exhaust efficiency improvement

Combustion efficiency improvement: The S/V ratio (Surface Volume ratio of the combustion chamber) and resulting thermal efficiency have been increased by making the combustion chamber hemispherical.


The offset distance of the spark plug position has been decreased and the equality of the flame propagation has been increased by moving the spark plug closer to the center of the combustion chamber.

Intake/exhaust efficiency improvement: Arranging the valves in a radial pattern allows the cylinder to have smoother intake and exhaust ports, and the port angle has been narrowed.

NEW GX630/GX630R/GX660/GX660R/GX690/GX690R:



PREVIOUS MODEL:





Cooling efficiency improvement

The cylinder block has been integrated with the cylinder head. It eliminates the use of the low thermal conductivity steel cylinder head bolts and stainless-steel cylinder head gaskets. Tubes are placed on the outside of the cylinder for push rod passages, allowing the cylinder block to be thinner and increase cooling efficiency.

NEW GX630/GX630R/GX660/GX660R/GX690/GX690R:

PREVIOUS MODEL:



TECHNICAL FEATURES

Knocking avoidance

Knocking tends to occur when the compression ratio is increased, and the engine can be damaged by gas vibration and high temperature in the combustion chamber.

The GX630/GX630R/GX660/GX660R/GX690/GX690R engines are equipped with the C.D.I ignition coil that sets the optimum ignition timing in accordance with the engine speed to prevent knocking.

The ignition coil also is equipped with the engine speed limiter and an oil alert function that shuts down the engine if it senses signal from the oil level switch.



MEMO





17. WIRING DIAGRAMS

2.7A CHARGE COIL / REMOTE CONTROL
TYPE..... 17-2

2.7A CHARGE COIL / CONTROL BOX
TYPE..... 17-2

17A CHARGE COIL / REMOTE CONTROL
TYPE..... 17-3

17A CHARGE COIL / CONTROL BOX
TYPE.....17-3

26A CHARGE COIL / REMOTE CONTROL
TYPE.....17-4




WIRING DIAGRAMS

2.7A CHARGE COIL / REMOTE CONTROL TYPE

| | | | |
|----|--------|----|-------------|
| Bl | Black | Br | Brown |
| Y | Yellow | O | Orange |
| Bu | Blue | Lb | Light blue |
| G | Green | Lg | Light green |
| R | Red | P | Pink |
| W | White | Gr | Gray |

COMBINATION SWITCH

| | | | | | |
|-----|-----|-----|-----|----|----|
| | IGN | GND | BAT | LO | ST |
| OFF | | | | | |
| ON | ○ | ○ | ○ | ○ | |
| ST | ○ | ○ | ○ | ○ | ○ |




2.7A CHARGE COIL / CONTROL BOX TYPE


| | | | |
|----|--------|----|-------------|
| Bl | Black | Br | Brown |
| Y | Yellow | O | Orange |
| Bu | Blue | Lb | Light blue |
| G | Green | Lg | Light green |
| R | Red | P | Pink |
| W | White | Gr | Gray |

COMBINATION SWITCH


| | | | | | |
|-----|-----|-----|-----|----|----|
| | IGN | GND | BAT | LO | ST |
| OFF | | | | | |
| ON | ○ | ○ | ○ | ○ | |
| ST | ○ | ○ | ○ | ○ | ○ |



17A CHARGE COIL / REMOTE CONTROL TYPE



17A CHARGE COIL / CONTROL BOX TYPE




WIRING DIAGRAMS

26A CHARGE COIL / REMOTE CONTROL TYPE

| | | | |
|----|--------|----|-------------|
| Bl | Black | Br | Brown |
| Y | Yellow | O | Orange |
| Bu | Blue | Lb | Light blue |
| G | Green | Lg | Light green |
| R | Red | P | Pink |
| W | White | Gr | Gray |

COMBINATION SWITCH

| | IGN | GND | BAT | LO | ST |
|-----|-----|-----|-----|----|----|
| OFF | | | | | |
| ON | ○ | ○ | ○ | ○ | |
| ST | ○ | ○ | ○ | ○ | ○ |



INDEX

| | | | |
|---|-------|---|-------|
| AIR CLEANER CHECK/CLEANING | 3-5 | HIGH-COMPRESSION ENGINE | 16-2 |
| AIR CLEANER REMOVAL/INSTALLATION | 6-3 | HOUR METER INSPECTION | 11-5 |
| AIR CLEANER REPLACEMENT | 3-6 | | |
| AUTO THROTTLE SOLENOID INSPECTION | 11-3 | IDLE SPEED CHECK/ADJUSTMENT | 3-8 |
| AUTO THROTTLE SOLENOID REMOVAL | 7-5 | IGNITION COIL REMOVAL/INSTALLATION | 9-4 |
| AUTO THROTTLE SOLENOID/GOVERNOR ARM INSTALLATION | 7-6 | | |
| | | LOWER SHROUD REMOVAL/INSTALLATION | 5-5 |
| BEFORE TROUBLESHOOTING | 4-2 | LUBRICATION & SEAL POINT | 2-5 |
| BREATHER COVER INSTALLATION | 15-6 | LUBRICATION SYSTEM DIAGRAM | 13-2 |
| BREATHER DISASSEMBLY/ASSEMBLY | 15-5 | | |
| BRUSH REPLACEMENT | 10-8 | MAINTENANCE SCHEDULE | 3-2 |
| | | MAINTENANCE STANDARDS | 2-2 |
| | | MAXIMUM SPEED ADJUSTMENT | 7-3 |
| | | | |
| CAMSHAFT INSTALLATION | 15-5 | OIL FILTER REPLACEMENT | 3-4 |
| CARBURETOR BODY CLEANING | 6-7 | OIL LEVEL SWITCH INSPECTION | 11-3 |
| CARBURETOR DISASSEMBLY/ASSEMBLY | 6-6 | OIL PRESSURE SWITCH INSPECTION | 11-3 |
| CARBURETOR INSPECTION | 6-8 | OIL PRESSURE TEST | 13-3 |
| CARBURETOR REMOVAL/INSTALLATION | 6-5 | OIL PUMP INSPECTION | 13-4 |
| CHARGE COIL INSPECTION | 8-7 | | |
| CHARGE COIL REMOVAL/INSTALLATION | 8-6 | PERFORMANCE CURVES | 1-4 |
| COMBINATION SWITCH INSPECTION | 11-4 | PILOT SCREW REMOVAL/INSTALLATION | 6-7 |
| COMBUSTION CHAMBER CLEANING | 3-10 | PISTON DISASSEMBLY/ASSEMBLY | 14-6 |
| COMPONENT LOCATION | 11-2 | PISTON INSTALLATION | 14-3 |
| CONTROL BOX DISASSEMBLY/ASSEMBLY | 7-10 | PTO DIMENSIONAL DRAWINGS | 1-9 |
| CONTROL BOX REMOVAL/INSTALLATION | 7-8 | | |
| COOLING FAN/FLYWHEEL REMOVAL/ INSTALLATION | 8-4 | REGULATOR/RECTIFIER INSPECTION | 8-8 |
| CRANKCASE COVER REMOVAL/INSTALLATION | 15-2 | REGULATOR/RECTIFIER SYSTEM INSPECTION | 8-7 |
| CRANKCASE COVER/CYLINDER BARREL/PISTON/ CONNECTING ROD/CRANKSHAFT/CAMSHAFT INSPECTION | 15-8 | | |
| CRANKSHAFT OIL SEAL REPLACEMENT (CRANKCASE COVER SIDE) | 15-13 | SERIAL NUMBER LOCATION | 1-2 |
| CRANKSHAFT OIL SEAL REPLACEMENT (CRANKCASE SIDE) | 14-14 | SIDE MOUNT MUFFLER REMOVAL/ INSTALLATION | 12-3 |
| CRANKSHAFT/GOVERNOR ARM SHAFT OIL SEAL REPLACEMENT (CRANKCASE SIDE) | 15-14 | SPARK ARRESTER CLEANING | 3-7 |
| CRANKSHAFT/PISTON REMOVAL/INSTALLATION | 15-4 | SPARK PLUG CHECK/ADJUSTMENT | 3-6 |
| CYLINDER DISASSEMBLY/ASSEMBLY | 14-5 | SPARK PLUG REPLACEMENT | 3-7 |
| CYLINDER INSTALLATION | 14-3 | SPARK TEST | 9-5 |
| CYLINDER/PISTON INSPECTION | 14-6 | STARTER MOTOR DISASSEMBLY/ASSEMBLY | 10-4 |
| CYLINDER/PISTON REMOVAL | 14-2 | STARTER MOTOR INSPECTION | 10-5 |
| | | STARTER MOTOR REMOVAL/INSTALLATION | 10-3 |
| | | SYSTEM DIAGRAM | |
| DIMENSIONAL DRAWINGS | 1-7 | CHARGING SYSTEM | 8-2 |
| DIMENSIONS AND WEIGHTS SPECIFICATIONS | 1-2 | FUEL SYSTEM | 6-2 |
| | | IGNITION SYSTEM | 9-2 |
| | | STARTING SYSTEM | 10-2 |
| | | | |
| ENGINE MOUNT DIMENSIONAL DRAWING | 1-11 | THROTTLE CABLE INSTALLATION | 7-9 |
| ENGINE OIL CHANGE | 3-4 | TOOLS | 2-6 |
| ENGINE OIL LEVEL CHECK | 3-3 | TOP MOUNT MUFFLER MOUNTING STUD BOLT REPLACEMENT | 12-5 |
| ENGINE SPECIFICATIONS | 1-3 | TORQUE VALUES | 2-4 |
| EXHAUST PIPE STUD BOLT REPLACEMENT | 12-5 | TRUBLESHOOTING | 4-2 |
| | | CHARGING SYSTEM | 8-3 |
| FAN COVER REMOVAL/INSTALLATION | 5-2 | FUEL SYSTEM | 6-2 |
| FUEL FILTER REPLACEMENT | 3-10 | IGNITION SYSTEM | 9-2 |
| FUEL PUMP REMOVAL/INSTALLATION | 6-4 | STARTING SYSTEM | 10-2 |
| FUEL TUBE CHECK | 3-11 | TUBE ROUTING | 2-13 |
| | | | |
| GOVERNOR ARM INSTALLATION | 7-3 | VALVE CLEARANCE CHECK/ADJUSTMENT | 3-8 |
| GOVERNOR ARM/CONTROL REMOVAL/ INSTALLATION | 7-2 | VALVE LIFTER DISASSEMBLY/ASSEMBLY | 15-8 |
| GOVERNOR SPRING INSTALLATION | 7-4 | VALVE SEAT RECONDITIONING | 14-13 |
| GOVERNOR/OIL PUMP/OIL FILTER DISASSEMBLY/ ASSEMBLY | 15-7 | | |
| | | WIRING DIAGRAM | |
| HARNESS ROUTING | 2-8 | 17A CHARGE COIL / CONTROL BOX TYPE | 17-3 |
| HIGH MOUNT MUFFLER REMOVAL/ INSTALLATION | 12-2 | 17A CHARGE COIL / REMOTE CONTROL TYPE | 17-3 |
| | | 2.7A CHARGE COIL / CONTROL BOX TYPE | 17-2 |
| | | 2.7A CHARGE COIL / REMOTE CONTROL TYPE | 17-2 |
| | | 26A CHARGE COIL / REMOTE CONTROL TYPE | 17-4 |