

RF/MICROWAVE

**Antenna**

**TAIWANGAST INC.**

2F, No.27, Jhong-Rong St., Sin-Jhuang City, Taipei County 242, Taiwan

TEL. 886 2 8994 1601, FAX. 886 2 8994 1602

sales@rfconnector.com.tw, www.rfconnector.com.tw

# General Information


<b>SMA</b>	<b>Subminiature Connectors Screw Lock</b>	<b>50 Ω</b>	<b>18 GHz</b>
<b>SMB</b>	<b>Subminiature Connectors</b>	<b>50 Ω</b>	<b>4 GHz</b>
	<b>Snap Lock</b>	<b>75 Ω</b>	<b>3 GHz</b>
<b>MCX</b>	<b>Microax Connectors</b>	<b>50 Ω</b>	<b>6 GHz</b>
	<b>Snap Lock</b>	<b>75 Ω</b>	<b>3 GHz</b>
<b>MMCX</b>	<b>Miniature Microax Connectors Snap Lock</b>	<b>50 Ω</b>	<b>6 GHz</b>
<b>N</b>	<b>Coaxial Connectors</b>	<b>50 Ω</b>	<b>11 GHz</b>
	<b>Screw Lock</b>	<b>75 Ω</b>	<b>1.5 GHz</b>
<b>TNC</b>	<b>Coaxial Miniature Connectors</b>	<b>50 Ω</b>	<b>11 GHz</b>
	<b>Screw Lock</b>	<b>75 Ω</b>	<b>1 GHz</b>
<b>BNC</b>	<b>Coaxial Miniature Connectors</b>	<b>50 Ω</b>	<b>4 GHz</b>
	<b>Bayonet Lock</b>	<b>75 Ω</b>	<b>1 GHz</b>
<b>FME</b>	<b>Coaxial Miniature Connectors Screw Lock</b>	<b>50 Ω</b>	<b>3 GHz</b>
<b>F</b>	<b>Coaxial Connectors Screw Lock</b>	<b>75 Ω</b>	<b>1 GHz</b>
<b>1.6/5.6</b>	<b>Coaxial Connectors Screw Lock</b>	<b>75 Ω</b>	<b>1 GHz</b>
<b>7/16</b>	<b>Coaxial Connectors Screw Lock</b>	<b>50 Ω</b>	<b>7.5 GHz</b>
<b>Adaptors</b>	<b>Between Series</b>		

## **TAIWANCAST INC.**

2F, No.27, Jhong-Rong St., Sin-Jhuang City, Taipei County 242, Taiwan

TEL. 886 2 8994 1601, FAX. 886 2 8994 1602, sales@rfconnector.com.tw, www.rfconnector.com.tw

# RF Connector Number Legend




## TAIWANCAST INC.

2F, No.27, Jhong-Rong St., Sin-Jhuang City, Taipei County 242, Taiwan

TEL. 886 2 8994 1601, FAX. 886 2 8994 1602, sales@rfconnector.com.tw, www.rfconnector.com.tw

# RF Adapter Number Legend




## TAIWANCAST INC.

2F, No.27, Jhong-Rong St., Sin-Jhuang City, Taipei County 242, Taiwan

TEL. 886 2 8994 1601, FAX. 886 2 8994 1602, sales@rfconnector.com.tw, www.rfconnector.com.tw

# RF Cable Assembly Number Legend



## TAIWANCAST INC.

2F, No.27, Jhong-Rong St., Sin-Jhuang City, Taipei County 242, Taiwan

TEL. 886 2 8994 1601, FAX. 886 2 8994 1602, sales@rfconnector.com.tw, www.rfconnector.com.tw

# ANTENNA



## **TAIWANCAST INC.**

2F, No.27, Jhong-Rong St., Sin-Jhuang City, Taipei County 242, Taiwan

TEL. 886 2 8994 1601, FAX. 886 2 8994 1602, sales@rfconnector.com.tw, www.rfconnector.com.tw