Signal Booster Installation Gulde



MobilePro®

Dual-Band Wireless Cellular / PCS Smart Technology™ Signal Booster with Built-in Antenna

Contents:

How it Works	1
Installation Overview - Vehicle	2
Installation Overview - In-Building	3
Vehicle Installation	
Alternative Mounting Options	
In-Building Installation	
Powering Up a Wilson Electronics Signal Booster	
Understanding the Signal Booster Lights	
Warnings and Recommendations	
About Wilson Electronics	
Guarantee and Warranty	
Signal Booster Specifications Back (

Note: This manual contains important safety and operating information. Please read and follow the instructions in this manual. Failure to do so could be hazardous and result in damage to your signal booster.




Installation Instructions for the Following Wilson Electronics Signal Booster:


MobilePro® Dual-Band Wireless Smart Technology™ Signal Booster

Model # 271220 FCCID: PWO271220SA IC: 4726A-271220SA Model # 271240 FCCID: PWO271240SA IC: 4726A-271240SA

The term "IC" before the radio certification number only signifies that Industry Canada technical specifications were met.



Optional Accessories & Antennas



How it Works


Your new Wilson Electronics Signal Booster has been carefully engineered to significantly improve the performance of your cell phone or cellular data card in mobile and in-building applications. Together with an outside antenna, the signal booster's state-of-the-art technology is designed to increase your signal up to 20 times, reduces dropped calls, and increase data communication rates needed for 3G technologies.


The outside antenna will collect the cell tower signal and send it through the coax cable to the signal booster. The signal is then boosted and sent through the built-in inside antenna. Your cellular device then communicates with the improved signal. When the cellular device transmits, the signal goes through the inside antenna, is boosted by the signal booster and broadcasted back to the cell tower through the outside antenna.

Wilson Electronics manufactures a wide variety of outside antennas to help you customize your signal booster for your specific application. Several are shown above. See your dealer or visit www.WilsonElectronics.com.

Before Getting Started


This guide will help you properly install Wilson Electronics MobilePro Dual-Band Wireless Signal Booster. It is important to read through all of the installation steps for your particular application prior to installing any equipment. Read through the instructions, visualize where all the equipment will need to be installed and do a soft installation before mounting any equipment. If you do not understand the instructions in full, contact the free U.S. Wilson Electronics Technical Support at 866-294-1660.






See detailed instructions on page 4

An in-building accessory kit is available if your kit did not contain the necessary equipment, from Wilson Electronics. Various kits are available, visit www.WilsonElectronics.com to see the selection of in-building accessory kits.






See detailed instructions on page 6

Installing a Wilson Electronics Outside Antenna on a Vehicle

To receive the best cell signal, select a location in the center of the vehicle's roof 12 inches away from any other antennas and windows and free of obstructions.







The outside antenna must be installed vertically. Signal performance will be degraded if the antenna is not vertical.

The antenna cable may be run through the door to the signal booster.



Warning: The outside antenna and signal booster must have a separation of at least 8 inches from all persons during normal operation.

For a more professional looking installation, run the antenna cable under the door seal. Carefully pull down the door seal. Run the cable through the seal and push the seal back into place. This prevents constant wear and tear on the cable as the door opens and closes.

Route the cable from the outside antenna and attach it to the connector labeled "ANTENNA" on the signal booster.

Installing a Wilson Electronics MobilePro® Signal Booster in a Vehicle



The Wilson Electronics MobilePro Signal Booster is designed for installation on the dashboard of your vehicle, using the supplied adhesive bracket. Attach the bracket in a suitable location.

NOTE: Allow the adhesive on the bracket to set for 24 hours before mounting your MobilePro Signal Booster to the bracket. Also, Be sure to select a location for the signal booster that does not inhibit your ability to operate the vehicle safely.

Once you have installed the bracket, attach the MobilePro Signal Booster by aligning the hole on the back with the hook on the bracket. Grasping the sides of the signal booster, slide it downward approximately 1/4 inch into place.

Alternative Signal Booster Installation for Weak Signal Areas



The Wilson Electronics MobilePro Signal Booster performs better the closer it is to the cell phone (with minimum 8-inch separation). Thus, if you regularly drive through particularly weak signal areas, you should consider installing the signal booster on the back of the driver's side headrest.

To do so, attach a strip of Velcro (available at most hardware or fabric stores) to the back of the signal booster and adhere the matching strip to the back of headrest. Visually align the strips of Velcro and press the signal booster against the headrest so that it is held in place by the Velcro.

Run the cable from the outside antenna and attach it to the SMA connector labeled "antenna" on the signal booster. Be sure that the cable does not interfere with your ability to operate the vehicle safely.

Alternative Mounting Options for your MobilePro®



Adjustable Desk Mount (901137)



Gooseneck Suction Cup Crade Mount (901120)



Cup Holder Cradle Mount (901130)

* Also available together in the Home/Office Accessory Kit - 859972

MobilePro* Home/Office Accessory Kit

The MobilePro® Home /Office
Accessory Kit contains components
needed for improving the MobilePro®
signal power at homes, offices,
hotel rooms and airports.



Desktop Antenna *(301208)



AC Power Supply *(859969)



Antenna Window Mount *(901128)

Installing a Wilson Electronics Outside Antenna in a Building

Follow the specific antenna instructions included with the outside antenna (sold separately except for certain kits). These instructions assume that you are using a Wilson Electronics magnet-mount or mini-magnet mount antenna and the optional suction-cup window bracket.

To receive the best signal, select a window on the side of your building where your outside signal is the strongest.





Attach the suction-cup bracket to the inside of a window so that the cable will reach the signal booster location. Place the bracket as high on the window as possible for best performance.



Warning: The outside antenna must have a separation of at least 8 inches from all persons during normal operation.

Once the bracket is in place, attach the magnet base of the antenna to the flat surface of the bracket. **Note:** The antenna must be installed vertically. Signal performance will be degraded if the antenna is not vertical.

Installing the Wilson Electronics MobilePro® Signal Booster in a Building



The Wilson Electronics MobilePro Signal Booster may be placed in any convenient indoor location, such as a desk or tabletop. The closer the cell phone or laptop data card is to the signal booster (with its built-in inside antenna), the better the performance will be.

Attaching the Antenna

Once you have selected the location for the signal booster, run the cable from the outside antenna and attach it to the connector labeled "antenna" on the signal booster. **Note:** The signal booster and the outside antenna must have a minimum separation of 8 feet to prevent oscillation.

Powering up the Wilson Electronics MobilePro® Signal Booster



Carefully insert the USB power cable.





IMPORTANT: Do not power up the signal booster unless the outside antenna cable is attached to signal booster.

In a Vehicle

Make sure the outside antenna cable is connected before powering up the signal booster.

Connect the mini-USB plug on the power cable to the signal booster port marked by the USB symbol. Connect the other end of the power cable to the USB port on the vehicle power supply and insert the adapter into the vehicle power outlet of your vehicle. (If you are using a laptop to power your signal booster, insert the other end of the power cable into a USB port on the laptop and power up the laptop.)

The signal booster may remain on all the time. However, leaving the signal booster on in a vehicle when it is not running can discharge the battery in a day or two.

In a Building

Make sure the outside antenna cable is connected before powering up the signal booster.

Connect the mini-USB plug on the AC adapter cable to the signal booster port marked by the USB symbol. Connect the other end of the cable to a standard AC power outlet. (If you are using a computer to power your signal booster, use the supplied USB cable.)



Warning: Use only Wilson Electronics power supplies.

Understanding the Signal Booster Lights

If the light turns red, an oscillation has been detected and the signal booster has powered down. The outside antenna needs to be moved farther from the built-in antenna in the signal booster. In a vehicle installation, move the outside antenna on the roof of the car to the rear of the car, but at least 8-12 inches from the rear or side windows. In a building installation, move the signal booster farther from the outside antenna. Remove power from the signal booster and reinstall power - this resets the signal booster.

If the light is now green, the signal booster is working properly. If the red light is still on, move the antenna farther away and repeat the process.

In a vehicle, always use a magnet-mount or roof-mount antenna. Do not use a glassmount antenna, as oscillation may cause continuous shut-down of the signal booster.

Warnings and Recommendations

Warning: Do not plug the signal booster directly into the cell phone or

cellular data card using an antenna adapter. It will damage the

cell phone or cellular data card.

Warning: Do not plug in the power supply until the outside antenna cable

is attached to the signal booster.


Warning:

RF Safety: The outside antenna must be installed with a separation of at least 8 inches from any of the vehicle's occupants or nearby persons and must not be located or operating in conjunction with any other antenna or signal booster. All roof-mount antennas should be centrally located on the roof of the vehicle. Use of this cellular signal booster with antennas other than those illustrated could be hazardous. Before using other antennas, contact Wilson Electronics

Technical Support at 886-294-1660.

Warning:

Separation of inside and outside antennas is very important: In a vehicle, the metal roof acts as a barrier and helps shield the two antennas from each other, preventing oscillation. If the vehicle has a sunroof, it is important to keep the outside antenna at least 12 inches from the edge of the sunroof. This prevents the signal booster from overloading or oscillating.





About Wilson Electronics

Wilson Electronics, Inc. has been a leader in the wireless communications industry for over 40 years. The company designs and manufactures signal boosters, antennas and related components that significantly improve cellular telephone signal reception and transmission in a wide variety of applications, mobile, in-building, and M2M.

With extensive experience in antenna and signal booster research and design, the company's engineering team uses a state-of-the-art testing laboratory, including an anechoic chamber and network analyzers, to fine-tune antenna designs and performance. For its signal boosters, Wilson Electronics uses a double electrically insulated RF enclosure and cell tower simulators for compliance testing.

Wilson Electronics signal boosters feature patent Smart Technology™ that enables them to automatically adjust their power based on cell tower requirements. By detecting and preventing oscillation (feedback), signal overload and interference with other users, these Smart Technology™ signal boosters improve network cell phone areas without compromising carrier systems.

All products are engineered and assembled in the company's 55,000-square-foot headquarters in St. George, Utah. Wilson Electronics has product dealers in all 50 states as well as in countries around the world.



30-Day Money-Back Guarantee

All Wilson Electronics products are protected by Wilson Electronics 30-day money-back guarantee. If, for any reason, the performance of any product is not acceptable, simply return the product directly to the reseller with a dated proof of purchase.

1-Year Warranty

Wilson Electronics signal boosters are warranted for one (1) year against defects in workmanship and/or materials. Warranty cases may be resolved by returning the product directly to the reseller with a dated proof of purchase.

Signal Boosters may also be returned directly to the manufacturer at the consumer's expense, with a dated proof of purchase and a Returned Material Authorization (RMA) number supplied by Wilson Electronics. Wilson Electronics shall, at its option, either repair or replace the product. Wilson Electronics will pay for delivery of the repaired or replaced product back to the original consumer if within the continental USA.

This warranty does not apply to any signal boosters determined by Wilson Electronics to have been subjected to misuse, abuse, neglect, or mishandling that alters or damages physical or electronic properties.

RMA numbers may be obtained by phoning Technical Support at 866-294-1660.

Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of this device.

Disclaimer: The information provided by Wilson Electronics, Inc. is believed to be complete and accurate. However, no responsibility is assumed by Wilson Electronics, Inc. for any business or personal losses arising from its use, or for any infringements of patents or other rights of third parties that may result from its use.

Copyright © 2011 Wilson Electronics, Inc. All rights reserved.

One or more of the following U.S. Patent numbers may apply to the Signal Booster in this product – D596,614; D596,615; D563,381;7,729,669; 7,486,929; 7,729,656; 7,409,186; 7.783.318; 7.684.838; 12.714.994.

Signal Booster Specifications

	Dual-Band Specifications	
Model Number	271240	Model Number
Connector	SMA Female	Connector
Impedance (input/output)	50 ohms	Impedance (input/output)
Dimensions	5.2 X 2.7 X 1.2 inch or 13.2 X 6.9 X 3.1 cm	Dimensions
Weight	3 oz or 83 Grams	Weight
Frequency	824-894 MHz / 1850-1990 MHz	Frequency
Daceband Cain (nominal)		'Passband Gain (nominal)

		Dual-Band	Dual-Band Specifications
Model Number		2.	271240
Connector		SMA	SMA Female
Impedance (input/output)		20	50 ohms
Dimensions		5.2 X 2.7 X 1.2 inch	1.2 inch or 13.2 X 6.9 X 3.1 cm
Weight		3 oz or	3 oz or 83 Grams
Frequency		824-894 MHz	824-894 MHz / 1850-1990 MHz
'Passband Gain (nominal)			
	800 MHz uplink	40 dB (typical)	40 dB (typical) / 46 dB (maximum)
8	800 MHz downlink	42 dB (typical)	42 dB (typical) / 49 dB (maximum)
	1900 MHz uplink	44 dB (typical)	44 dB (typical) / 50 dB (maximum)
191	1900 MHz downlink	43 dB (typical)	43 dB (typical) / 50 dB (maximum)
² 20 dB Bandwidth (nominal)			
800 MHz	800 MHz (uplink/downlink)	47 MHz / 45	47 MHz / 45 MHz (maximum)
1900 MHz	1900 MHz (uplink/downlink)	101 MHz / 87	101 MHz / 87 MHz (maximum)
Power output for single cell phone (uplink)	link)	800 MHz	1900 MHz
	CDMA	24.6 dBm	21.8 dBm
	GSM	25.2 dBm	20.8 dBm
	EDGE	25.3 dBm	21.8 dBm
	WCDMA	23.0 dBm	20.9 dBm
3Power output (uplink) for multiple	Number of	Maxim	Maximum Power ³
cell phones:	cell phones	800 MHz	1900 MHz
	2	21.4 dBm	18.9 dBm
	3	17.9 dBm	15.4 dBm
	4	15.4 dBm	12.9 dBm
	co	13.5 dBm	11.0 dBm
	9	11.9 dBm	9.4 dBm
Power output for single received channel (downlink)	nel (downlink)	800 MHz	1900 MHz
	CDMA	12.9 dBm	11.1 dBm
	GSM	12.1 dBm	11.0 dBm
	EDGE	12.0 dBm	10.8 dBm
	WCDMA	10.3 dBm	11.5 dBm
*Power output for multiple received channels (downlink). The maximum		Maxim	Maximum Power³
power is reduced by the number of channels:	Number of channels	800 MHz	1900 MHz
	2	10.5 dBm	8.7 dBm
	8	7.0 dBm	5.1 dBm
	4	4.5 dBm	2.6 dBm

20 dB Bandwidth (non Power output for single	power output (up link) real phones:	Power output for single	Power output for multi- channele (downlink), to power is reduced by the of channels.
3301 East Dese	ret Drive. S	St. Geora	e. UT 84790
OCC Edot DCCC	iot Bilvo, c	or. Occorg	0, 01 01/00

For additional Technical Support visit www.WilsonElectronics.com or email at: tech@wilsonelectronics.com

Local: 435-673-5021

Nominal gain is the maximum gain at any frequency in the passband.

Power Requirements Noise Figure (typical)

Nominal bandwidth is the difference between two frequencies that are adjacent to the passband where the amplification is 20 dB

tower than the passible and and any experience of the critical control and control and any experience of the critical control and control

an attenuator at the output of the device. The maximum powerfor 2 or more simultaneous signals will be reduced by 6 dB every time the number of signals is doubled.

Signal Booster Specifications

Dual-Band Specifications

40 dB (typical) / 50 dB (maximum) 824-894 MHz / 1850-1990 MHz

²20 dB Bandwidth (nominal)

Phone: 866-294-1660

www.twitter.com/WilsonCellular

3 oz or 83 Grams SMA Female 50 ohms 271220

-20 db bandwidth (nominal)			
800 MHz	800 MHz (uplink/downlink)	43 MHz / 45 M	43 MHz / 45 MHz (maximum)
1900 MHz	1900 MHz (uplink/downlink)	90 MHz / 89 M	90 MHz / 89 MHz (maximum)
Power output for single cell phone (uplink)	plink)	800 MHz	1900 MHz
	CDMA	31.4 dBm	30.1 dBm
	GSM	26.9 dBm	26.3 dBm
	EDGE	26.0 dBm	25.1 dBm
	WCDMA	31.3 dBm	30.9 dBm
	AMPS	26.6 dBm	
3.4Power output (uplink) for multiple	Number of	Maximun	Maximum Power ³
cell phones:	cell phones	800 MHz	1900 MHz
	2	18.8 dBm	18.5 dBm
	3	15.3 dBm	14.9 dBm
	4	12.8 dBm	12.4 dBm
	2	10.9 dBm	10.5 dBm
	9	9.3 dBm	8.9 dBm
Power output for single received channel (downlink)	nnel (downlink)	800 MHz	1900 MHz
	CDMA	5.6 dBm	1.8 dBm
	GSM	0.7 dBm	-2.7 dBm
	EDGE	-2.5 dBm	-6.4 dBm
	WCDMA	-2.8 dBm	-1.0 dBm
	AMPS	-2.6 dBm	
^{3,} Power output for multiple received channels (downlink). The	A social	Maximun	Maximum Power ³
number of channels:	channels	800 MHz	1900 MHz
	2	7.0 dBm	0.2 dBm
	8	3.5 dBm	-3.4 dBm
	4	1.0 dBm	-5.9 dBm
	2	-1.0 dBm	-7.8 dBm
	9	-2.6 dBm	-9.4 dBm
Noise Figure (typical)		3 dB n	3 dB nominal
Isolation)6 <	> 90 dB
Power Requirements		2-8 V	5-8 V DC, 0.5A

Nominal gain is the maximum gain at any frequency in the passband.
 Nominal bandwidth is the difference between two frequencies that are adjacent to the passband where the amplification is 20 dB

5 - 8 V DC, 0.5A 3 dB nominal > 90 dB

0.7 dBm

2.5 dBm

tower there bestead any efficiency. One of the requestes is every frame the season and the other is higher of the reduction of the reduction

Fax: 435-656-2432

www.facebook.com/WilsonCellular